



Toshiba DK40 Quick Reference Instructions

1
2

--

•

Bookmarks

[Download this manual](#)

Quick Links



TOSHIBA DK40, DK40i, DK280 & DK424 QUICK REFERENCE VOICE MAIL INSTRUCTIONS

How to activate your personal voice mail box

- . Press flashing MSG button and follow the instructions given by the Toshiba Tutorial

How to check new voice mail messages from your own phone MSG light flashing

- . Press MSG button
- . Enter your security code and press #
- . Follow the system prompts

How to check saved voice mail messages

- . Press Intercom button
- . Press 850
- . Press *

- . Enter your security code and press #
- . Follow the system prompts

How to check your voice mail messages from outside the building

- .
- . Call the main number (or the Back Door Number if applicable) and ask to be transferred to the voice mail
- . When you hear the System Announcement
- . Press *
- . Enter your mail box number and press #
- . Enter your security code and press #
- . Follow the system prompts

How to change your personal greeting in your voice mail box

- .
- . Press Intercom button
- . Press 850
- . Press *
- . Enter your mail box number and press #
- . Enter your security code and press #
- . Wait 5 seconds
- . Press 3
- . Press 1
- . Press 1 (Greeting 1)
- . Follow the system prompts and record your greeting

[Next Page](#)

1

2

Related Manuals for Toshiba DK40

[Telephone System Toshiba Strata DK40 Programming Manual](#)

(378 pages)

[Telephone Toshiba Strata DK40 Installation & Maintenance Manual](#)

(360 pages)

[IP Phone Toshiba Strata DK 2000-series User Manual](#)

Toshiba digital telephone user guide (164 pages)

[IP Phone Toshiba DK User Manual](#)

Includes lcd, add-on module, and direct station selection console (163 pages)

[IP Phone Toshiba CT User Manual](#)

Includes lcd, add-on module, and direct station selection console (136 pages)

[Telephone Toshiba Strata DK User Manual](#)

Electronic telephone (134 pages)

[Handsets Toshiba Strata AirLink User Manual](#)

Integrated wireless handset (132 pages)

[Handsets Toshiba Strata AirLink User Manual](#)

Integrated wireless handset (131 pages)

[Handsets Toshiba Strata AirLink Integrated Wireless Handset User Manual](#)

Toshiba integrated wireless handset user guide (131 pages)

[Cordless Telephone Toshiba Strata DK User Manual](#)

Cordless digital telephone (107 pages)

[Telephone Toshiba Strata DK System Administration Manual](#)

(60 pages)

[IP Phone Toshiba Strata DK User Manual](#)

Digital single line telephone (60 pages)

[Telephone System Toshiba Strata DK14 System Administrator Manual](#)

Strata dk digital business telephone systems (56 pages)

[Telephone Toshiba Strata DK User Manual](#)

Standard telephone (50 pages)

[Telephone Toshiba Strata DK14 Quick Reference Manual](#)

Strata dk digital business telephone systems (13 pages)

[Telephone Toshiba Strata DK EKT-Series Quick Reference Manual](#)

Digital business telephone systems electronic telephone (7 pages)

Summary of Contents for Toshiba DK40

[Page 1](#) TOSHIBA DK40, DK40i, DK280 & DK424 QUICK REFERENCE VOICE MAIL INSTRUCTIONS

How to activate your personal voice mail box . Press flashing MSG button and follow the instructions given by the Toshiba Tutorial How to check new voice mail messages from your own phone MSG light flashing .

[Page 2](#) Toshiba DK40, DK40i, DK280 & DK424 Quick Reference Voice Mail Instructions How to record Auto Attendant Greeting (Mail Box 990 - Security Code 990 - Greeting 1) . Press Intercom button . Press 850 . Press * . Enter user ID (990) and # .

This manual is also suitable for:

[Dk40iDk280Dk424](#)