




Asus Lyra MAP-AC2200 Quick Start Manual

1
2

•


Bookmarks

Available languages



Quick Links

[Download this manual](#)



1

Connect Primary Lyra to Modem

Unplug your cable / DSL modem*.

Remove the battery if it has one.

* If you are using DSL for internet, you will need a username/password from your Internet service provider (ISP) to properly configure your router.

Connect your modem to Lyra with the network cable provided.

Power on your cable / DSL modem, and check your cable / DSL modem LED lights to ensure the connection is active. Plug in the power adapter to Lyra and wait until the LEDs turn to solid white to ensure that your Lyra is ready for setup.

Primary Lyra
Colors of Lyra



Light Cyan

Everything is good!

Red

Loss connection to the primary Lyra. Move it closer.

F13319_Lyra_one-page_QSG.indb 1



1

2



1



2

Setup your Lyra WiFi system

Download the free ASUS Lyra app.

Launch the ASUS Lyra app on your mobile device, and follow the instructions in just a few minutes.

* Make sure your device supports BLE, Bluetooth 4.0 or above.



Connect PC/NB to your Lyra via WiFi "ASUS_XX_AMAPS".

Open a web browser. You will be redirected to the ASUS Setup Wizard. If not, navigate to <http://router.asus.com>

Orange

Loss connection to the Internet. Please check the cable connected with your modem.

Solid White

Lyra is ready for setup. It will start blinking when setting up with the app.

Random Breathing

Lyra is booting up or applying settings.

3

Adding other Lyra to current network

Launch Lyra app and click the "+" icon on the upper right corner, then choose Add Lyra to current network and follow the instructions to complete.

Primary Lyra

Press the Pairing button on the Primary Lyra until the LED starts to blink green light.

Press the Pairing button on the second Lyra until the LED starts to blink green light, then turns solid light cyan, indicating the pairing process is completed.



* Pairing feature only works with the Primary Lyra device connecting to modem.

* While setting up through Web GUI, ensure that you pair other Lyra
hub(s) with the primary Lyra using the Pairing button.
E13319 / First Edition/ August 2017



Primary Lyra
15/09/17 15:13

[Next Page](#)

1

2

Related Manuals for Asus Lyra MAP-AC2200

[Wireless Access Point Asus Lyra MAP-AC2200 Quick Install Manual](#)

Tri-band wi-fi system (70 pages)

[Microphone system Asus Lyra MAP-AC2200 Quick Start Manual](#)

Tri-band wi-fi system (60 pages)

[Wireless Router Asus Lyra MAP-AC2200 Quick Start Manual](#)

Tri-band wi-fi system (2 pages)

[Wireless Router Asus RT-N13U User Manual](#)

Wireless n router with all-in-one printer server (61 pages)

[Wireless Router Asus RT-N12 Series Manual](#)

(5 pages)

[Wireless Router Asus Lyra Trio MAP-AC1750 Manual](#)

(56 pages)

[Wireless Router Asus Lyra Voice Quick Start Manual](#)

Wireless-ac2200 tri band gigabit router (52 pages)

[Wireless Router Asus RT-BE92U Quick Start Manual](#)

Be9700 tri-band wifi 7 router (2 pages)

[Wireless Router Asus DSL-N66U User Manual](#)

Dual-band wi-fi adsl/vdsl modem router (70 pages)

[Wireless Router Asus RT-N53 User Manual](#)

Dual-band wireless-n router (58 pages)

[Wireless Router Asus ROG Rapture GT-AXE16000 Quick Start Manual](#)

Quad-band gaming router (2 pages)

[Wireless Router Asus RT-AX82U Quick Start Manual](#)

Ax5400 dual band wi-fi router (208 pages)

[Wireless Router Asus RT-AX3000 User Manual](#)

Dual band (136 pages)

[Wireless Router ASUS RT-N14U User Manual](#)

Wireless-n300 router (74 pages)

[Wireless Router Asus RT-N56U User Manual](#)

Extreme performance in style dual-band wireless-n gigabit router (72 pages)

[Wireless Router Asus ZenWiFi AX XT8 Quick Start Manual](#)

Ax6600 tri band wifi router (176 pages)

Summary of Contents for Asus Lyra MAP-AC2200

[Page 1](#) METHOD 1 Through App Remove the battery if it has one. Download the free ASUS Lyra app. Launch Lyra app and click the “+” icon on the upper * If you are using DSL for internet, you will right corner, then choose Add Lyra to current network...

[Page 2](#) Ouvrez l'application Lyra et cliquez sur l'icône “+” située en haut à droite, puis sélectionnez Ajouter l'appareil Lyra au Téléchargez l'application gratuite ASUS Lyra. * Si vous utilisez le DSL pour accéder à Internet, réseau actuel et suivez les instructions pour terminer.