



# Asus VZ239H User Manual



1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31

--

•

## Table of Contents

- 

## Troubleshooting

•

## Bookmarks

## Quick Links

[1 Using the Control Buttons](#)

[Download this manual](#)





VZ239 Series  
**ASUS**  
LCD Monitor

*User Guide*

## Table of Contents

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Asus VZ239H

[Monitor Asus VZ239HE-W User Manual](#)

(31 pages)

[Monitor Asus VZ239 Series User Manual](#)

(31 pages)

[Lcd monitor Asus MX32VQ Series User Manual](#)

(26 pages)

[Lcd monitor Asus DV201 User Manual](#)

Dt lcd monitor (24 pages)

[Lcd monitor Asus PA32UC User Manual](#)

Pa32u series (34 pages)

## Summary of Contents for Asus VZ239H

[Page 1](#) VZ239 Series LCD Monitor User Guide...

[Page 2](#) Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

### [Page 3: Table Of Contents](#)

Table of Contents Notices .....iv Safety Information .....v Care & Cleaning .....vi Takeback Services .....vii Welcome! .....1-1 Package Contents ..... 1-1 Assembling the Monitor Base ..... 1-2 Connect Cables .....1-3 1.4.1 Rear of the LCD Monitor .....1-3 Monitor Introduction .....

### [Page 4: Notices](#)

Notices Federal Communications Commission Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: • This device may not cause harmful interference, and • This device must accept any interference received including interference that may cause undesired operation.

### [Page 5: Safety Information](#)

Safety Information • Before setting up the monitor, carefully read all the documentation that came with the package. • To prevent fire or shock hazard, never expose the monitor to rain or moisture. • Never try to open the monitor cabinet. The dangerous high voltages inside the monitor may result in serious physical injury.

### [Page 6: Care & Cleaning](#)

Care & Cleaning • Before you lift or reposition your monitor, it is better to disconnect the cables and power cord. Follow the correct lifting techniques when positioning the monitor. When lifting or carrying the monitor, grasp the edges of the monitor. Do not lift the display by the stand or the cord. • Cleaning.

### [Page 7: Takeback Services](#)

These documents are not part of the standard package. Takeback Services ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for our customers to be able to responsibly recycle our products, batteries and other components as well as the packaging materials.

## [Page 8: Welcome](#)

® Thank you for purchasing the ASUS LCD monitor! The latest widescreen LCD monitor from ASUS provides a crisper, broader, and brighter display, plus a host of features that enhance your viewing experience. With these features, you can enjoy the convenience and delightful visual...

## [Page 9: Assembling The Monitor Base](#)

Turn the screw clockwise to secure the base. Then adjust the monitor to the angle that is most comfortable for you. • We recommend that you cover the table surface with soft cloth to prevent damage to the monitor. ASUS LCD Monitor VZ239 Series...

## [Page 10: Connect Cables](#)

Connect Cables 1.4.1 Rear of the LCD Monitor HDMI HDMI VZ239H VZ239N HDMI HDMI VZ239Q Speakers VGA port Control buttons Audio-IN port Kensington Lock DC-IN port HDMI port DVI port DisplayPort Chapter 1: Product Introduction...

## [Page 11: Monitor Introduction](#)

The QuickFit function contains several options of common grid pattern, paper size, and photo size. See page 1-6 for details. Input Button (for VZ239H/VZ239Q models only): Switch the input source. Auto Adjust Button (for VZ239N model only): Automatically perform Auto Adjust (only available for VGA input).

[Page 12](#) Close Button: • Exit the OSD menu. Menu Button: • Enter the OSD menu. Power Button/Power Indicator: • Press this button to turn the monitor on/off. • The color definition of the power indicator is as the table below. Status Description White Amber...

## [Page 13: Quickfit Function](#)

Paper size: Provides users to view their documents in real size on the screen. Photo size: Provides photographers and other users to accurately view and edit their photos in real size on the screen. 8x10 ASUS LCD Monitor VZ239 Series...

## [Page 14: 2.1 Adjusting The Monitor](#)

2.1 Adjusting the Monitor • For optimal viewing, we recommend that you look at the full face of the monitor, then adjust the monitor to the angle that is most comfortable for you. • Hold the stand to prevent the monitor from falling while changing its angle.

## [Page 15: Osd \(On-Screen Display\) Menu](#)

Select to return to previous menu or to accept and return to previous menu. ASUS LCD Monitor VZ239 Series...

## [Page 16: Osd Function Introduction](#)

3.1.2 OSD Function Introduction Splendid This function contains eight sub-functions that you can select for your preference. Each mode has the Reset selection, allowing you to maintain your setting or return to the preset mode. VZ239 Splendid Standard Mode VGA 1920 x 1080 @ 60Hz Scenery mode Standard Mode Theater Mode...

[Page 17](#) • When Blue Light Filter is activated, the default settings of Standard Mode will be automatically imported. • Between Level 1 to Level 3, the Brightness function is user-configurable. • Level 4 is optimized setting. It is compliance with TUV Low Blue Light Certification. The Brightness function is not user-configurable. ASUS LCD Monitor VZ239 Series...

[Page 18](#) Color Select the image color you like from this function. VZ239 Color Standard Mode VGA 1920 x 1080 @ 60Hz Brightness Contrast Saturation Color Temp. Skin Tone Brightness: Adjust the brightness level. The adjusting range is • from 0 to 100. Contrast: Adjust the contrast level.

[Page 19](#) Standard Mode VGA 1920 x 1080 @ 60Hz Sharpness Trace Free Aspect Control VividPixel ASCR Position Focus Auto Adjust VZ239Q VZ239 Image Standard Mode VGA 1920 x 1080 @ 60Hz Sharpness Trace Free Aspect Control VividPixel ASCR Adaptive-Sync Position More (Page 1/2) ASUS LCD Monitor VZ239 Series...

[Page 20](#) • 4:3 is only available when the input source is in 4:3 format. • OverScan is only available for HDMI input. VividPixel: ASUS Exclusive Technology that brings lifelike • visuals for crystal-clear and detail-oriented enjoyment. The adjusting range is from 0~100. ASCR: Select ON or OFF to enable or disable dynamic contrast •...

[Page 21](#) Input Select Select the input source. VZ239H VZ239 Input Select Standard Mode VGA 1920 x 1080 @ 60Hz HDMI VZ239N VZ239 Input Select Standard Mode VGA 1920 x 1080 @ 60Hz ASUS LCD Monitor VZ239 Series...

[Page 22](#) VZ239Q VZ239 Input Select Standard Mode VGA 1920 x 1080 @ 60Hz HDMI DisplayPort System Setup Adjust the system configuration. VZ239H VZ239 System Setup Standard Mode VGA 1920 x 1080 @ 60Hz Splendid Demo Mode Volume ECO Mode OSD Setup Language Key Lock...

[Page 23](#) Power Key Lock All Reset (Page 2/2) VZ239N VZ239 System Setup Standard Mode VGA 1920 x 1080 @ 60Hz Splendid Demo Mode ECO Mode OSD Setup Language Key Lock Information Power Indicator More (Page 1/2) ASUS LCD Monitor VZ239 Series...

[Page 24](#) VZ239 System Setup Standard Mode VGA 1920 x 1080 @ 60Hz Back Power Key Lock All Reset (Page 2/2) VZ239Q VZ239 System Setup Standard Mode VGA 1920 x 1080 @ 60Hz Splendid Demo Mode Volume DisplayPort Stream ECO Mode OSD Setup Language Key Lock More...

[Page 25](#) Power Key Lock All Reset (Page 2/2) Splendid Demo Mode: Activate the demo mode for the • Splendid function. Volume (for VZ239H/VZ239Q models only): Adjust the volume • level. DisplayPort Stream (for VZ239Q model only): Select DP 1.1 or • DP 1.2.

[Page 26](#) Shortcut Assign the specific function to the two shortcut keys. VZ239H/VZ239Q VZ239 Shortcut Standard Mode VGA 1920 x 1080 @ 60Hz Shortcut 1 Blue Light Filter Shortcut 2 Splendid Brightness Auto Adjust Contrast Color Temp. Volume GamePlus (Shortcut 1) VZ239...

[Page 27](#) Shortcut 1: Assign a function to the Shortcut Key1. • Available options: Blue Light Filter, Splendid, Brightness, Auto Adjust, Contrast, Color Temp., Volume (for VZ239H/ VZ239Q models only), and GamePlus. The default setting is Brightness. Shortcut 2: Assign a function to the Shortcut Key2.

[Page 28](#) Counter (for VZ239Q model only). Then press the button to confirm the selection. Press the button repeatedly to exit the OSD menu. Press the assigned Shortcut Key1 or Shortcut Key2 to activate the GamePlus main menu. GamePlus Main Menu VZ239H/VZ239N VZ239Q GamePlus GamePlus Crosshair Timer FPS Counter Crosshair...

## [Page 29: Specifications](#)

TCO 7.0, GEMS, EPEAT Silver, RoHS(China RoHS, J-Moss), WEEE, ErP( Energy Saving Only), CU \*Specifications subject to change without notice. \*\* measuring a screen brightness of 200 nits without audio/ USB/ Card reader connection. 3-15 ASUS LCD Monitor VZ239 Series...

## [Page 30: Troubleshooting \(Faq\)](#)

Troubleshooting (FAQ) Problem Possible Solution Power LED is not ON • Press the button to check if the monitor is turned • Check if the adapter and power cord are properly connected to the monitor and the power outlet. • Check the Power Indicator function in the OSD menu.

## [Page 31: Supported Timing List](#)

SVGA 832x624@75Hz 1152 x 667 49.714 74.533 57.27 \* Modes not listed in the table may not be supported. For optimal resolution, we recommend that you choose a mode listed in the table above. 3-17 ASUS LCD Monitor VZ239 Series...

This manual is also suitable for:

[Vz239nVz239q](#)