



Whirlpool 215WP User Manual

1
2
3
4

--

•

Bookmarks

--

[Download this manual](#)

Quick Links




assage bathtub

Notice only under the surfing function on ,the heating function can be launched , and control by the preset temperature .Press (of temperature will flicker ,then the preset temperature can be changed by pressing within 30℃--42℃(default 38℃)When the water temperature

reach to the preset temperature ,it will turn into constant temperature .

4 Waterfall function

Press " "or" "to select the waterfall icon ,as shown to the right :



5 Ozone function Configuration Options


Press " "or" "to select the ozone icon ,as shown to the right :



Notice the work timing is 15 minutes .

6 Lamp

Press " "or" "to select the lamp icon ,as shown to the right :



7

Drainage function after power off:

Ensure that the main power supply is not cut-off.
the drainage magnetic valve will automatically startup and shut-off after 30 minutes.

.Items For Attention

6

- 1 The system must be erected by qualified technical person and the leakage switch shall be mounted in place of easy control .
- 2 It must be connected firmly during erection .In the case of loss due to improper earthling ,the manufacturer will not assume any responsibility .
- 3 The motor must be erected flatly and stably and the shell shall be firmly earthed .
- 4 The whole set is usually under standby state. If it is not used please pull off the master power switch.
- 5 During erection, it is required to consider load capacity of power supply circuit, otherwise it may influence the normal working of the system or cause accident.

6 During erection, all the electric appliances and electric parts shall be provided with moisture resistant measures.

) 2 seconds ,the number

(It will be tur ned off aut om at ical ly ever y 60m inut es .)




To press OK for ON or OFF

To press OK for ON or OFF

To press OK for ON or OFF after turning off the control panel, for long time,

Page 7 of 7

User's Guide



MODEL:WP-215

Model:215WP

SIZE:1820X1210X590mm

[Next Page](#)

1
2
3
4

Related Manuals for Whirlpool 215WP

[Bathtubs Whirlpool MT-RT1804 Product Information](#)

Massage bathtub (4 pages)

[Bathtubs Whirlpool MT-RT1802 Product Information](#)

Massage bathtub (4 pages)

[Bathtubs Whirlpool ARIEL ARL-702 Installation Manual](#)

(6 pages)

[Bathtubs Whirlpool SALAMANCA Product Information](#)

Massage bathtub (4 pages)

[Bathtubs Whirlpool RIHO User Manual](#)

(68 pages)

Summary of Contents for Whirlpool 215WP

[Page 1](#) (It will be turned off automatically every 60 minutes.) Read this manual before proceeding with installation of the bathtub and keep it with the other accompanying documents. This manual is valid for the installation of tubs both with and without whirlpool. Press " "or"...

[Page 2](#) Massage bathtub Massage bathtub 4. Panel description □ Install the diagram Right left connect the power supply Screen Confirm ON/OFF 5. Operation □ Plane chart Exchange switch 1 □ ON /OFF □ insert the plug ,press () to switch on the power .The screen will Sprinkler Cold and hot show□...

[Page 3](#) Massage bathtub Massage bathtub 1. Features(371) □ 1 □ Automatic testing water level by microcomputer. 1 □ Electricity parameter 2 □ Surfing function . 3 □ Bubble bath massage function . Rated voltage Rated power Reference circuit voltage Rated electric current 4 □ External thermostat function □ Configuration Options □ 220VAC 2750W <4A 5 □ Underwater light .

[Page 4](#) Massage bathtub Massage bathtub Bathtub User's Guide 6. 6 Check whether have break on pipe and water way periodically. 6. 7 Please check whether the release is fall off or breakage on wire, switch, connector plugs so that repair in time.