

Indoor Unit - Sanyo SPW-X253G56 Service Manual

Split system

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72

| |
|--|
| |
|--|

•

Table of Contents

-

Troubleshooting

•

Bookmarks



3-1

Indoor Unit


1 1 1 1 1 SPW-X253G56, SPW-X363G56, SPW-X483G56

3 3-1 Indoor Unit

- Electric Wiring Diagram **① SPW-X253G56, SPW-X363G56, SPW-X483G56**

1
5
1
2
1
5
TH1
5P(WHT)
2P(RED)
Controller (CR-X363GS)
5P(WHT)

- Electric Wiring Diagram



2P(WHT)
E
SUP
PRY
1
3
5

1
2
1
2
3 4

Terminal Plate(4P)
To Outdoor Unit
Power Supply
Earth
Terminal
Remote
Control
Switch

1
12
1
12
12P(WHT)
2P(WHT)
3P(BLU)
3P(RED)

SEC
DP
FS
1
2
1
3


DP
S
P
TR
FS
Earth
Terminal

W 854-2-5268-493-00-2 (X253G56, X363G56, X483G56)

- 34 -

3. Electrical data

DPH
LM
S
1 2 3 4
P




3 4
Connector
4P(WHT)
DPH
LM
3P(RED)
3P(GRN)
FM
7P(WHT)
3P(WHT)
COM
M H L
49FMI

1
3
5
7
1
3
C
P
1 2 3 4 5 6 7 8 9
1
2 3 4 5 6 7 8 9
S

3-1 Indoor Unit

① SPW-X253G56, SPW-X363G56, SPW-X483G56

• Electric Wiring Diagram



W 854-2-5268-493-00-2 (X253G56, X363G56, X483G56)

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
31
32
33
34
35
36
37
38

Quick Links:

[Unit Specifications](#)

[\(A\) Indoor Unit](#)

[\(B\) Outdoor Unit](#)

[Outdoor Unit](#)

[Troubleshooting](#)

Related Manuals for Sanyo SPW-X253G56

[Air Conditioner Sanyo SPW-T253G56 Service Manual](#)

Split system air conditioner (71 pages)

[Air Conditioner Sanyo SPW-D253G56 Service Manual](#)

Split system air conditioner (66 pages)

[Air Conditioner Sanyo SPW-X483GH56 Installation Instruction](#)

Eco multi system air conditioner (91 pages)

[Air Conditioner Sanyo SPW-X253GH56 Service Manual](#)

Split system (105 pages)

[Air Conditioner Sanyo SPW-C256VH Technical Data & Service Manual](#)

4-way air discharge semi-concealed wall-mounted ceiling-mounted concealed-duct (517 pages)

[Air Conditioner Sanyo Big PACi 18 Series Technical Data & Service Manual](#)

Big pack i dc inverter (275 pages)

[Air Conditioner Sanyo SPW-XR253GH56 Technical Data & Service Manual](#)

(223 pages)

[Air Conditioner Sanyo 2-WAY ECO-i SPW-C0705DXHN8 Service Manual](#)

Multi system (143 pages)

[Air Conditioner Sanyo SPW-XR254EH56 Installation And Operation Manual](#)

Dc inverter air conditioner (40 pages)

[Air Conditioner Sanyo Mini ECO-i SPW-ASR74GXH56\(A/B\) Installation Instructions Manual](#)

System air conditioner (49 pages)

[Air Conditioner Sanyo SPW-UMR74EXH56 Technical Data & Service Manual](#)

Split system air conditioner (38 pages)

[Air Conditioner Sanyo ECO G SGP-EGW190M2G2W Brochure & Specs](#)

Gas driven vrf m series (9 pages)

[Air Conditioner Sanyo SPW-C1155DXHN8 Technical Data & Service Manual](#)

2-way eco-i multi system (242 pages)

[Air Conditioner Sanyo SPW-C483GYH8 Service Manual](#)

Eco multi system (235 pages)

[Air Conditioner Sanyo SPW-CR1503GDYH8 Technical Data & Service Manual](#)

W-eco multi system series (377 pages)

[Air Conditioner Sanyo SPW-CR363GVH8 Service Manual](#)

(262 pages)

Related Content for Sanyo SPW-X253G56

[SAP-K71GJHA Changing Address Of Remote Control Unit In Indoor Unit](#)

Sanyo SAP-K71GJHA

[MINI ECO-i XHX1252 Indoor Unit Setting Mode](#)

Sanyo MINI ECO-i XHX1252

[Mini ECO-i CHXR03652 Indoor Unit Electronic Control Valve Control](#)

Sanyo Mini ECO-i CHXR03652

[SAP-C302AH-S Changing Address Of Remote Control In Indoor Unit](#)

Sanyo SAP-C302AH-S

[C2432A Indoor Unit](#)

Sanyo C2432A

[ECO-i AHX0752 Indoor Unit](#)

Sanyo ECO-i AHX0752

[MINI ECO-i SPW-CR365GXH56B Serial-Parallel I/O Unit For Each Indoor Unit \(Acc-Sp1Ag\(B\)\)](#)

Sanyo MINI ECO-i SPW-CR365GXH56B

[SAP-CMRV3143GJH Indoor Unit](#)

Sanyo SAP-CMRV3143GJH

This manual is also suitable for:

[Spw-x253gs56Spw-x303g56Spw-x303gs56Spw-x363g56Spw-x363gs56Spw-x483g56](#) ... [Show all](#)