

Audio I/O Connections - Asus ROG STRIX H370-F GAMING User Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96

--

•

[Table of Contents](#)

•

Bookmarks



2.2.2

Audio I/O connections

Audio I/O ports

Connect to Headphone and Mic

Connect to Stereo Speakers

Connect to 2-channel Speakers

ROG STRIX H370-F GAMING

2-15



Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
48
49
50
51
52
53
54
55

Quick Links:

[Motherboard Layout](#)

[System Memory](#)

[Onboard Leds](#)

[DIMM Installation](#)

Related Manuals for Asus ROG STRIX H370-F GAMING

[Motherboard Asus Rog Strix H370-I Gaming Manual](#)

(89 pages)

[Motherboard Asus PRIME H370-PLUS Manual](#)

(36 pages)

[Motherboard Asus PRIME H370-PLUS Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME B360-PLUS Manual](#)

(28 pages)

[Motherboard Asus TUF H370-PRO GAMING Manual](#)

(40 pages)

[Motherboard Asus PRIME H370-A Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H370-A Manual](#)

(36 pages)

[Motherboard Asus H370 MINING MASTER Manual](#)

(25 pages)

[Motherboard Asus PRIME H370M-PLUS Manual](#)

(40 pages)

[Motherboard Asus PRIME H370M-PLUS User Manual](#)

(40 pages)

[Motherboard Asus TUF H310-PLUS GAMING Manual](#)

(27 pages)

[Motherboard Asus TUF H310M-PLUS GAMING R2.0 Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-D R2.0 Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-E R2.0 Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-K R2.0 Manual](#)

(27 pages)

[Motherboard Asus H310A-EM-A Manual](#)

Industrial motherboard (77 pages)

Related Content for Asus ROG STRIX H370-F GAMING

[TUF GAMING Z590-PLUS Audio I/O Connections](#)

Asus TUF GAMING Z590-PLUS

[MAXIMUS VII HERO Audio I/O Connections](#)

Asus MAXIMUS VII HERO

[STRIX Z270H GAMING Audio I/O Connections](#)

Asus STRIX Z270H GAMING

[PRIME Z590-V Audio I/O Connections](#)

Asus PRIME Z590-V

[ROG MAXIMUS XII EXTREME Audio I/O Connections](#)

Asus ROG MAXIMUS XII EXTREME

[Pro WS W680-ACE Audio I/O Connections](#)

Asus Pro WS W680-ACE

[ROG MAXIMUS XII Z490 APEX Audio I/O Connections](#)

Asus ROG MAXIMUS XII Z490 APEX

[TUF X470-PLUS GAMING Audio I/O Connections](#)

Asus TUF X470-PLUS GAMING