

Advanced Mode - Asus ROG STRIX H370-F GAMING User Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96

--

•

[Table of Contents](#)

•

Bookmarks



3.2.1

Advanced Mode

The Advanced Mode provides advanced options for experienced end-users to configure the BIOS settings. The figure below shows an example of the Advanced Mode. Refer to the following sections for the detailed configurations.

The default screen for entering the BIOS setup program can be changed. Refer to the Setup Mode item in section Boot menu for details.

Configuration fields

Pop-up Menu

Menu bar

Language

MyFavorite(F3)

Menu items

General help



ROG STRIX H370-F GAMING

Qfan Control(F6)

EZ Tuning Wizard(F11)

Go back to EZ Mode Hot Keys

Last modified settings

Search(F9)

Scroll bar

AURA ON/OFF(F4)

Search on the FAQ

Displays a quick overview
of the system status

3-3

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

[1](#)
[...](#)
[54](#)
[55](#)
[56](#)
[57](#)
[58](#)
[59](#)
[60](#)
[61](#)

Quick Links:

[Motherboard Layout](#)

[System Memory](#)

[Onboard Leds](#)

[DIMM Installation](#)

Related Manuals for Asus ROG STRIX H370-F GAMING

[Motherboard Asus Rog Strix H370-I Gaming Manual](#)

(89 pages)

[Motherboard Asus PRIME H370-PLUS Manual](#)

(36 pages)

[Motherboard Asus PRIME H370-PLUS Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME B360-PLUS Manual](#)

(28 pages)

[Motherboard Asus TUF H370-PRO GAMING Manual](#)

(40 pages)

[Motherboard Asus PRIME H370-A Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H370-A Manual](#)

(36 pages)

[Motherboard Asus H370 MINING MASTER Manual](#)

(25 pages)

[Motherboard Asus PRIME H370M-PLUS Manual](#)

(40 pages)

[Motherboard Asus PRIME H370M-PLUS User Manual](#)

(40 pages)

[Motherboard Asus TUF H310-PLUS GAMING Manual](#)

(27 pages)

[Motherboard Asus TUF H310M-PLUS GAMING R2.0 Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-D R2.0 Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-E R2.0 Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-K R2.0 Manual](#)

(27 pages)

[Motherboard Asus H310A-EM-A Manual](#)

Industrial motherboard (77 pages)

Related Content for Asus ROG STRIX H370-F GAMING

[PRIME X570-PRO Advanced Mode](#)

Asus PRIME X570-PRO

[STRIX Z270F GAMING Advanced Mode](#)

Asus STRIX Z270F GAMING

[B450M-A/CSM Advanced Mode](#)

Asus B450M-A/CSM

[MAXIMUS VII HERO Advanced Mode](#)

Asus MAXIMUS VII HERO

[STRIX Z270H GAMING Advanced Mode](#)

Asus STRIX Z270H GAMING

[PRIME B250M-J Advanced Mode](#)

Asus PRIME B250M-J

[H110M-K X Advanced Mode](#)

Asus H110M-K X

[PRIME H310M-C/PS R2.0 Advanced Mode](#)

Asus PRIME H310M-C/PS R2.0