


Exit Menu - Asus Prime H310M-C Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17


18
19
20
21
22
23
24
25
26
27
28



•

•

Bookmarks



Exit menu

The Exit menu items allow you to load the optimal default values for the BIOS items, and save or discard your changes to the BIOS items.

A screenshot of the BIOS Exit menu. The menu is displayed on a dark blue background with white text. The items listed are: 'Load Optimized Defaults', 'Save Changes & Reset', 'Discard Changes & Exit', and 'Launch EFI Shell from USB drives'. The 'Load Optimized Defaults' item is highlighted with a light blue background. The 'Launch EFI Shell from USB drives' item is highlighted with a light grey background.

Load Optimized Defaults
Save Changes & Reset
Discard Changes & Exit
Launch EFI Shell from USB drives

Load Optimized Defaults

This option allows you to load the default values for each of the parameters on the Setup

menus. When you select this option or if you press <F5>, a confirmation window appears.

Select OK to load the default values.

Save Changes & Reset

Once you are finished making your selections, choose this option from the Exit menu to ensure the values you selected are saved. When you select this option or if you press <F10>,

a confirmation window appears. Select OK to save changes and exit.

Discard Changes & Exit

This option allows you to exit the Setup program without saving your changes. When you

select this option or if you press <Esc>, a confirmation window appears. Select OK to discard

changes and exit.

Launch EFI Shell from USB drives

This option allows you to attempt to launch the EFI Shell application (shellx64.efi) from one of the available USB devices.

2-4

Exit

Exit system setup without saving any changes.

:Select Screen

: Select Item

Enter: Select

+/-: Change Opt.

F1:

F2:

F5:

F10: Save & Exit

ESC: Exit

Chapter 2: BIOS information

[General Help](#)
[Previous Values](#)
[Optimized Defaults](#)

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
19
20
21
22
23
24
25
26

Quick Links:

[Motherboard Overview](#)

Related Manuals for Asus Prime H310M-C

[Motherboard Asus PRIME H310M-C R2.0 Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-C R2.0/CSM Quick Start Manual](#)

(2 pages)

[Motherboard Asus H310M-C/HDMI R2.0 Quick Start Manual](#)

(2 pages)

[Motherboard Asus H310M-C/HDMI Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H310M-CS R2.0 Manual](#)

(25 pages)

[Motherboard Asus PRIME H310M-CS R2.0 Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H310M-C/PS R2.0 Manual](#)

(54 pages)

[Motherboard Asus PRIME H310M-E Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-A R1.0 Instruction Manual](#)

(29 pages)

[Motherboard Asus PRIME H310M-K Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-F R2.0 Manual](#)

(25 pages)

[Motherboard Asus TUF H310M-PLUS GAMING R2.0 Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-D R2.0 Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-A R2.0 Manual](#)

(29 pages)

[Motherboard Asus PRIME H310M-K R2.0 Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M2 R2.0 Manual](#)

(26 pages)

Related Content for Asus Prime H310M-C

[ROG RAMPAGE V EDITION 10 Exit Menu](#)

Asus ROG RAMPAGE V EDITION 10

[Q170A-IM-A Exit Menu](#)

Asus Q170A-IM-A

[Z13PE-D16 Exit Menu](#)

Asus Z13PE-D16

[WS X299 SAGE Exit Menu](#)

Asus WS X299 SAGE

[Pro A620M-C-CSM Exit Menu](#)

Asus Pro A620M-C-CSM

[PRIME H310M-A R1.0 Exit Menu](#)

Asus PRIME H310M-A R1.0

[H110M-P/DVI Exit Menu](#)

Asus H110M-P/DVI

[PRIME X570-PRO Exit Menu](#)

Asus PRIME X570-PRO

This manual is also suitable for:

[Prime h310m-c/csm](#)