



Asus A2C User Manual

1
2
3
4
5
6
7

--

•

Bookmarks

--

[Download this manual](#)

Quick Links



ASUS Win Flash User's Guide

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus A2C

[Software Asus NB Probe User Manual](#)

Asus nb probe software: user guide (8 pages)

[Laptop Asus A2D User Manual](#)

Drivers and utilities (120 pages)

[Laptop Asus A3G Hardware User Manual](#)

Asus a3g: user guide (76 pages)

[Laptop Asus Notebook PC Hardware User Manual](#)

Notebook pc (76 pages)

[Laptop Asus E1701b Hardware User Manual](#)

Asus notebook pc hardware user's manual (76 pages)

[Laptop Asus A2D Hardware User Manual](#)

Asus a2d: user guide (74 pages)

[Laptop Asus A2K Hardware User Manual](#)

Asus a2k: user guide (74 pages)

[Laptop Asus E2224 User Manual](#)

Asustek computer notebook pc user's manual (72 pages)

[Laptop Asus 1 E1309 Hardware User Manual](#)

Asus laptop - notebook pc user manual (70 pages)

[Software Asus A3Ac User Manual](#)

(9 pages)

[Software Asus A3Ac User Manual](#)

(8 pages)

[Software Asus Power 4 Gear User Manual](#)

Asus power 4 gear software: user guide (8 pages)

[Software Asus Power 4 Phone User Manual](#)

Telephone terminal emulation utility (6 pages)

[Software Asus A3Ac User Manual](#)

(6 pages)

[Software Asus Splendid User Manual](#)

Asus splendid software: user guide (5 pages)

[Software Asus A3Ac User Manual](#)

(4 pages)

Summary of Contents for Asus A2C

[Page 1](#) ASUS Win Flash User's Guide...

[Page 2](#) Chapter 1 ASUS Win Flash ...1 Introduction ...1 How to upgrade BIOS ...1 Contents...

[Page 3: How To Upgrade Bios](#)

Please verify the exact model and download the latest BIOS file for your Notebook from ASUS Download Site. Please ensure that you have installed ASUS Win Flash Utility before using update procedure. You may install the program via Driver & Utility CD if you cannot find the program

from Start ->...

[Page 4](#) Select and open the updated BIOS image file 3. Please confirm the loaded BIOS information as displayed in the following image...

[Page 5](#) 4. Press Flash to initialize BIOS updating procedure 5. Press "Exit" when procedure completes Check out 1. Model 2. Version Follow this message and flash your BIOS easily...

[Page 6](#) 6. Please reboot the system Assuming that you have successfully flashed the BIOS file, press F2 to enter BIOS setup page when ASUS white logo appears during system Boot-up procedure 7. After entering BIOS setup page, please go to Exit sub-menu and choose "Load Optimal Defaults".

This manual is also suitable for:

A2dcA2dA2gA2hA2kA2l ... [Show all](#)