



# Switches And Status Indicators; Switches - Asus F5GL Hardware Manual



|                   |  |
|-------------------|--|
| 1                 |  |
| Table Of Contents |  |
| 2                 |  |
| 3                 |  |
| 4                 |  |
| 5                 |  |
| 6                 |  |
| 7                 |  |
| 8                 |  |
| 9                 |  |
| 10                |  |
| 11                |  |
| 12                |  |
| 13                |  |
| 14                |  |
| 15                |  |
| 16                |  |
| 17                |  |

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71

|  |  |
|--|--|
|  |  |
|--|--|

•


•

Bookmarks

|  |
|--|
|  |
|--|








# 3

---

Getting Started

## Switches and Status Indicators

Switches



Instant Fun PLUS



Pressing this button will launch a media player application to view DVDs, VCDs, videos, photos (in My Documents\My Pictures), or television programs (when equipped with a TV tuner); or listen to music CDs or files.

## Power4 Gear+ Key

The Power4 Gear+ button toggles power savings between various power saving modes. The power saving modes control many aspects of the Notebook PC to maximize performance versus battery time.

When you are using an AC power adapter, Power4 Gear+ will switch between modes in the AC power mode segment. When you remove the AC adapter, Power4 Gear+ will switch between modes

in the battery (DC) mode segment. When you remove or apply the AC adapter, Power4 Gear+ will au-

tomatically shift you up or down into the proper mode segment (AC or DC).

## Battery Mode

### AC Mode

## Internet Launch Key

Pressing this button will launch your Internet browser application while Windows is running.

## Touchpad Lock Key

Pressing this button will lock (disable) the built-in touchpad. Locking the touchpad will prevent you from

accidentally moving the cursor while typing and is best used with an external mouse (pointing device).

To unlock (enable) the touchpad, simply press this button again.

[Previous Page](#)  
[Next Page](#)

1  
...  
27  
28  
29  
30  
31  
32  
33  
34

## Related Manuals for Asus F5GL

[Laptop Asus F5M Manual](#)

(70 pages)

[Software Asus A3Ac User Manual](#)

(8 pages)

[Laptop Asus F50GX Hardware Manual](#)

(88 pages)

[Laptop Asus X75A User Manual](#)

(116 pages)

[Laptop Asus R403C User Manual](#)

User's manual for english edition (116 pages)

[Laptop Asus A550CA E-Manual](#)

User's manual for english edition (128 pages)

[Laptop Asus A550DP E-Manual](#)

User's manual for english edition (110 pages)

[Laptop Asus A552EA E-Manual](#)

X552 series 15.6"; x452 series 14.0" (128 pages)

[Laptop Asus A451CA E-Manual](#)

User's manual for english edition (114 pages)

[Laptop Asus F5Z Hardware User Manual](#)

Asus f5z notebook (85 pages)

[Laptop Asus X553M User Manual](#)

(9 pages)

[Laptop Asus E502M E-Manual](#)

(114 pages)

[Laptop Asus X552W E-Manual](#)

(118 pages)

[Laptop Asus X540L E-Manual](#)

(112 pages)

[Laptop Asus X555B E-Manual](#)

(116 pages)

[Laptop Asus VivoBook F512DA Series Tips And Frequently Asked Questions](#)

(2 pages)

## Related Content for Asus F5GL

[E5946 Switches And Status Indicators](#)

ASUS E5946

[E3108 Switches And Status Indicators](#)

Asus E3108

## [Notebook PC Switches And Status Indicators](#)

ASUS Notebook PC

### [E4168 Switches And Status Indicators](#)

ASUS E4168

### [G56JR Switches And Status Indicators](#)

Asus G56JR

### [N46JV Switches And Status Indicators](#)

Asus N46JV

### [A52JV Switches And Status Indicators](#)

Asus A52JV

### [A95VB Switches And Status Indicators](#)

Asus A95VB

This manual is also suitable for:

[F5sl](#)[F5sr](#)[Pro50sr](#)[Pro50v](#)[Pro50vl](#)[Pro55gl](#) ... [Show all](#)