

Table Of Contents - Asus Prime H270-PRO Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

Table Of Contents

38

--


•

[Table of Contents](#)

•

Bookmarks

--



Contents

[Safety Information](#)

..... iv

[About This Guide](#)

..... iv

[Package Contents](#)

..... vi

[Prime H270-Pro Specifications Summary](#)

vi

Chapter 1:

1.1	
Before You Proceed	1-1
1.2	
Motherboard Overview	1-1
1.3	
Central Processing Unit (Cpu)	1-10
1.4	
System Memory	1-11
Chapter 2:	
2.1	
Managing And Updating Your Bios	2-1
2.2	
Bios Setup Program	2-6
2.3	
Exit Menu	2-11
Appendix	
Notices	
	A-1
Asus Contact Information	
	A-4
Product Introduction	
BIOS information	

[Previous Page](#)
[Next Page](#)

1
2
3
4
5
6
7

Quick Links:

[Motherboard Overview](#)

[Connectors/Jumpers/Slots/Led](#)

[Layout Contents](#)

[System Memory](#)

Related Manuals for Asus Prime H270-PRO

[Motherboard Asus Prime H270-Plus User Manual](#)

(36 pages)

[Motherboard Asus STRIX H270F GAMING User Manual](#)

(113 pages)

[Motherboard Asus STRIX H270F GAMING Manual](#)

(113 pages)

[Motherboard Asus STRIX H270F GAMING Quick Start Manual](#)

(2 pages)

[Motherboard Asus STRIX H270I GAMING Manual](#)

(75 pages)

[Motherboard Asus PRIME H270M-PLUS Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H270M-PLUS Manual](#)

(37 pages)

[Motherboard Asus H81-PLUS User Manual](#)

H81-plus user's manual (73 pages)

[Motherboard ASUS H81M-V3 User Manual](#)

(50 pages)

[Motherboard Asus Rog Strix H370-I Gaming Manual](#)

(89 pages)

[Motherboard Asus PRIME H410M-D Manual](#)

(28 pages)

[Motherboard Asus Prime H510M User Manual](#)

(34 pages)

[Motherboard Asus PRIME H310M-K Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-DASH Manual](#)

(27 pages)

[Motherboard Asus PRIME H410I-PLUS Manual](#)

(30 pages)

[Motherboard Asus PRIME H610T2-CSM D4 User Manual](#)

(33 pages)

Related Content for Asus Prime H270-PRO

[PRIME A620-PLUS WIFI6 Package Contents](#)

[Asus PRIME A620-PLUS WIFI6](#)

[PRIME Z270-K Table Of Contents](#)

[Asus PRIME Z270-K](#)

[Z170-P Table Of Contents](#)

[Asus Z170-P](#)

[PRIME Z270-P Table Of Contents](#)

[Asus PRIME Z270-P](#)

[PRIME Z370-P Table Of Contents](#)

[Asus PRIME Z370-P](#)

[970 PRO GAMING/AURA Table Of Contents](#)

[Asus 970 PRO GAMING/AURA](#)

[Pro WS X570-ACE Table Of Contents](#)

[asus Pro WS X570-ACE](#)

[PRIME Z390-P Table Of Contents](#)

[Asus PRIME Z390-P](#)