



Whirlpool W10353374B Installation Instructions Manual

Electric cooktop

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16

-

[Table of Contents](#)

•

Bookmarks

--


Available languages

EN

FR

Quick Links

[Download this manual](#)



ELECTRIC COOKTOP INSTALLATION INSTRUCTIONS

INSTRUCTIONS D'INSTALLATION DE LA TABLE

COOKTOP SAFETY	1
INSTALLATION REQUIREMENTS	2
Tools and Parts	2
Location Requirements	2
Electrical Requirements	3
INSTALLATION INSTRUCTIONS	4
Prepare Cooktop for Installation	4
Install Cooktop	4
Make Electrical Connection	6
Attach Cooktop to Countertop	8

[Complete Installation](#)8

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.

This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING."

These words mean:

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

IMPORTANT:

Save for local electrical inspector's use.

IMPORTANT :

À conserver pour consultation par l'inspecteur local des installations électriques.

W10353374B

DE CUISSON ÉLECTRIQUE

Table of Contents / Table des matières

COOKTOP SAFETY

Your safety and the safety of others are very important.

[SÉCURITÉ DE LA TABLE DE CUISSON](#) 9

[EXIGENCES D'INSTALLATION](#)..... 9

[Outils et pièces](#)..... 9

[Exigences d'emplacement](#)..... 9

[Spécifications électriques](#) 11

[INSTRUCTIONS D'INSTALLATION](#) 12

[Préparation de la table de cuisson pour l'installation](#)..... 12

[Installation de la table de cuisson](#)..... 12

[Raccordement électrique](#)..... 14

[Fixation de la table de cuisson au plan de travail](#)..... 16

[Achever l'installation](#) 16

You can be killed or seriously injured if you don't immediately follow instructions.

You can be killed or seriously injured if you don't follow instructions.



[Next Page](#)

1
2
3
4
5

Summary of Contents for Whirlpool W10353374B

[Page 1: Table Of Contents](#)

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed. IMPORTANT: Save for local electrical inspector's use. IMPORTANT : À conserver pour consultation par l'inspecteur local des installations électriques. W10353374B...

[Page 2: Installation Requirements](#)

INSTALLATION REQUIREMENTS Tools and Parts Location Requirements IMPORTANT: Observe all governing codes and ordinances. Gather the required tools and parts before starting installation. When installing cooktop, use minimum dimensions given. Read and follow the instructions provided with any tools listed here.

[Page 3: Electrical Requirements](#)

Cabinet Dimensions Electrical Requirements IMPORTANT: If installing a range hood or microwave hood WARNING combination above the cooktop, follow the range hood or microwave hood combination installation instructions for dimensional clearances above the cooktop surface. Electrical Shock Hazard Disconnect power before servicing. Use 8 gauge copper wire.

[Page 4: Installation Instructions](#)

■ The cooktop is rated 120/240 volt. Some models have a ■ A UL listed or CSA approved conduit connector must be neutral (white) wire. provided at each end of the power supply cable (at the cooktop and at the junction box). A listed conduit connector ■...

[Page 5](#) Installing Brackets Before Placing Cooktop in Cutout Installing Brackets After Placing Cooktop in Cutout 1. Using 2 or more people, place the cooktop upside down on a 1. Using 2 or more people, place cooktop right side up into the covered surface using the foam end posts from the cutout.

[Page 6: Make Electrical Connection](#)

Make Electrical Connection WARNING 4-Wire Cable from Power Supply to 4-Wire Cable from Cooktop IMPORTANT: Use the 4-wire cable from power supply where local codes do not permit connecting the frame-ground conductor to the neutral (white) junction box wire. Electrical Shock Hazard Disconnect power before servicing.

[Page 7](#) 3-Wire Cable from Power Supply to 4-Wire Cable from 4-Wire Cable from Power Supply to 3-Wire Cable from Cooktop Cooktop IMPORTANT: Use the 3-wire cable from power supply where IMPORTANT: Use the 4-wire cable from power supply where local codes permit connecting the frame-ground conductor to local codes do not permit connecting the frame-ground the neutral (white) junction box wire: conductor to the neutral (white) junction box wire:...

[Page 8: Attach Cooktop To Countertop](#)

3-Wire Cable from Power Supply to 3-Wire Cable from Attach Cooktop to Countertop Cooktop NOTE: This section applies only if you are using clamping brackets. IMPORTANT: Use the 3-wire cable from power supply where local codes permit connecting the frame-ground conductor to the neutral (white) junction box wire: ½...

[Page 9: Sécurité De La Table De Cuisson](#)

SÉCURITÉ DE LA TABLE DE CUISSON Votre sécurité et celle des autres est très importante. Nous donnons de nombreux messages de sécurité importants dans ce manuel et sur votre appareil ménager. Assurez-vous de toujours lire tous les messages de sécurité et de vous y conformer. Voici le symbole d'alerte de sécurité.

[Page 10](#) ■ La table de cuisson doit être installée à l'écart des zones de forts courants d'air, telles que fenêtres, portes et événements ou Dimensions du placard ventilateurs de chauffage puissants. La table de cuisson doit être installée à un endroit pratique dans la cuisine. IMPORTANT : En cas d'installation d'une hotte ou d'un ensemble hotte/micro-ondes au-dessus de la cuisinière, suivre ■...

[Page 11: Spécifications Électriques](#)

Spécifications électriques Avant d'établir la connexion électrique : AVERTISSEMENT Pour installer la table de cuisson correctement, il faut établir le type de raccords électriques que l'on utilisera et suivre les instructions indiquées ici. ■ L'appareil doit être alimenté uniquement par un circuit monophasé...

[Page 12: Instructions D'installation](#)

INSTRUCTIONS D'INSTALLATION Préparation de la table de cuisson pour Installation de la table de cuisson l'installation Style 1 : Table de cuisson sur four encastré sous comptoir IMPORTANT : Ne pas utiliser de brides de fixation. AVERTISSEMENT 1. À l'aide d'au moins 2 personnes, placer la table de cuisson dans l'ouverture en orientant la bonne surface vers le haut.

[Page 13](#) Installation des brides avant de positionner la table de Installation des brides après avoir positionné la table de cuisson dans l'ouverture cuisson dans l'ouverture. 1. À l'aide de deux personnes ou plus, placer la table de 1. À l'aide d'au moins 2 personnes, placer la table de cuisson cuisson à...

[Page 14: Raccordement Électrique](#)

Raccordement électrique AVERTISSEMENT Câble à 4 conducteurs depuis le point de distribution jusqu'au câble à 4 conducteurs depuis la table de cuisson IMPORTANT : Si les codes locaux ne permettent pas le raccordement du conducteur de liaison à la terre au conducteur neutre (blanc) dans le boîtier de connexion, utiliser le câble à...

[Page 15](#) Câble à 3 conducteurs depuis le point de distribution Câble à 4 conducteurs depuis le point de distribution jusqu'au câble à 4 conducteurs depuis la table de jusqu'au câble à 3 conducteurs depuis la table de cuisson cuisson IMPORTANT : Utiliser le câble à 3 conducteurs depuis le point IMPORTANT : Si les codes locaux ne permettent pas le de distribution lorsque les codes locaux en vigueur permettent le raccordement du conducteur de liaison à...

[Page 16: Fixation De La Table De Cuisson Au Plan De Travail](#)

été achetée. 8/14 ® /™ ©2014. Used under license in Canada. All rights reserved. Printed in U.S.A. W10353374B Utilisé sous licence au Canada. Tous droits réservés. Imprimé aux É.-U.