



Toshiba RAS-B10 Owner's Manual

Split type

- 1
- 2
- 3
- 4
- 5
- 6

--

•

Bookmarks

[Download this manual](#)

Quick Links



OWNER'S MANUAL
TOSHIBA

AIR CONDITIONER (SPLIT TYPE)

For general public use

Indoor unit

RAS-B10, 13, 16, 22N3KV2-E1

Outdoor unit

RAS-10, 13N3AV2-E1

RAS-16, 22N3AV2-E

111065514

TOSHIBA

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba RAS-B10

[Air Conditioner Toshiba 16N3KV2-E1 Installation Manual](#)

(276 pages)

[Air Conditioner Toshiba 16N3KVP Series Owner's Manual](#)

(105 pages)

[Air Conditioner Toshiba RAS-B10 Series Installation Manual](#)

(68 pages)

[Air Conditioner Toshiba 24N3KV2 Series Owner's Manual](#)

(26 pages)

[Air Conditioner Toshiba RAS-B07 Installation Manual](#)

Air conditioner (split type) (20 pages)

[Air Conditioner Toshiba RAS-B10 Owner's Manual](#)

Split type; r32 or r410a inverter (20 pages)

[Air Conditioner Toshiba RAS-\(B\)10UFV Series Installation Manual](#)

Split type indoor unit outdoor unit (13 pages)

[Air Conditioner Toshiba RAS-B10 SERIES Installation Manual](#)

(10 pages)

[Air Conditioner Toshiba RAS-05, RAS-07 Installation Manual](#)

Inverter (274 pages)

[Air Conditioner Toshiba RAS-10 Installation Manual](#)

(32 pages)

[Air Conditioner Toshiba RAS-10 Installation Manual](#)

(28 pages)

[Air Conditioner Toshiba RAS-10 Owner's Manual](#)

Split type (8 pages)

[Air Conditioner Toshiba RAS-07 Owner's Manual](#)

Air conditioner (split type) (8 pages)

[Air Conditioner Toshiba RAS-10 NAH Series Owner's Manual](#)

(5 pages)

[Air Conditioner Toshiba RAS-10 Series Owner's Manual](#)

Indoor and outdoor unit (5 pages)

[Air Conditioner Toshiba RAS-10 Owner's Manual](#)

(4 pages)

Summary of Contents for Toshiba RAS-B10

[Page 1](#) ENGLISH OWNER'S MANUAL AIR CONDITIONER (SPLIT TYPE) For general public use
Indoor unit RAS-B10, 13, 16, 22N3KV2-E1 Outdoor unit RAS-10, 13N3AV2-E1 RAS-16, 22N3AV2-E
1110655144...

[Page 2: Precautions For Safety](#)

PRECAUTIONS FOR SAFETY The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual. Store this owner's manual in a location where it can be easily accessed when needed. Be sure to read this owner's manual carefully before operating. It is recommended that maintenance be performed by a specialist when the

unit has been operated for a long time.

[Page 3](#) When the air-conditioning unit does not cool or warm, there may be a leakage of refrigerant. Please consult the supplying retail dealership. The refrigerant used in the air-conditioning unit is safe. It will not leak under normal operating conditions but if it leaks into the room and contacts a heat source such as a heater, or stove, it may cause a harmful reaction.

[Page 4](#) "ONE- TOUCH" of the button. If you prefer other settings you can select from the 4 TIMER (Yellow) many other operating functions of your Toshiba unit. 5 OPERATION (Green) 6 RESET button Press : Start the operation.

[Page 5](#) Setting Daily Timer OPERATION AND PERFORMANCE Press : Set the ON timer. Press 1. Three-minute protection feature: To prevent the unit from being activated for 3 minutes when suddenly restarted or switched to ON. 2. Preheating operation: Warm up the unit for 5 minutes before blowing warm air.

[Page 6](#) Information according to EMC Directive 2004/108/EC (Name of the manufacturer) TOSHIBA CARRIER (THAILAND) CO., LTD. (Address, city, country) 144/9 MOO 5, BANGKADI INDUSTRIAL PARK, TIVANON ROAD, TAMBOL BANGKADI, AMPHUR MUANG, PATHUMTHANI 12000, THAILAND. (Name of the Importer/Distributor in EU) TOSHIBA CARRIER UK LTD.

This manual is also suitable for:

131622n3kv2-e1Ras-1013n3av2-e1ras-1622n3av2-e