



# Building Your Pc System; Cpu Installation - Asus TUF GAMING H470-PRO Manual



1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62

---

•

[Table of Contents](#)

•

## Bookmarks







# Basic Installation

## 2.1

### Building your PC system

The diagrams in this section are for reference only. The motherboard layout may vary with models, but the installation steps are the same for all models.

#### 2.1.1



# CPU installation

- Ensure that you install the correct CPU designed for LGA1200 socket only. DO NOT install a CPU designed for LGA1155, LGA1156, and LGA1151 sockets on the LGA1200 socket.

- ASUS will not cover damages resulting from incorrect CPU installation/removal, incorrect CPU orientation/placement, or other damages resulting from negligence by the user.

## TUF GAMING H470-PRO



2-1

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
30  
31  
32  
33  
34  
35  
36  
37

## Related Manuals for Asus TUF GAMING H470-PRO

[Motherboard Asus TUF GAMING H470-PRO \(WI-FI\) Manual](#)

(64 pages)

[Motherboard Asus TUF GAMING H470-PRO WI-FI Manual](#)

(20 pages)

[Motherboard Asus TUF GAMING H470-PRO WI-FI Quick Start Manual](#)

(2 pages)

[Motherboard Asus TUF GAMING H470-PRO Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H470-PLUS Manual](#)

(32 pages)

[Motherboard Asus PRIME H470-PLUS Quick Start Manual](#)

(2 pages)

[Motherboard Asus ROG STRIX H470-I GAMING Manual](#)

(62 pages)

[Motherboard Asus Prime H470M-PLUS Manual](#)

(32 pages)

[Motherboard Asus PRIME H470M-PLUS Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H410M-A Manual](#)

(28 pages)

[Motherboard Asus PRIME H410M-D Manual](#)

(28 pages)

[Motherboard Asus Prime H410M-R User Manual](#)

(28 pages)

[Motherboard Asus PRIME H410M-E Manual](#)

(28 pages)

[Motherboard Asus PRIME H410M-K R2.0 Manual](#)

(32 pages)

[Motherboard Asus PRIME H410I-PLUS Manual](#)

(30 pages)

[Motherboard Asus Pro H410T Manual](#)

(28 pages)

## Related Content for Asus TUF GAMING H470-PRO

[MAXIMUS VII HERO Building Your Pc System](#)

Asus MAXIMUS VII HERO

[STRIX Z270H GAMING Building Your Pc System](#)

Asus STRIX Z270H GAMING

[PRIME Z590-V Building Your Pc System](#)

Asus PRIME Z590-V

[ROG MAXIMUS XII EXTREME Building Your Pc System](#)

Asus ROG MAXIMUS XII EXTREME

[Pro WS W680-ACE Building Your Pc System](#)

Asus Pro WS W680-ACE

[ROG MAXIMUS XII Z490 APEX Building Your Pc System](#)

Asus ROG MAXIMUS XII Z490 APEX

[TUF X470-PLUS GAMING Building Your Pc System](#)

Asus TUF X470-PLUS GAMING

[PRIME X570-P Building Your Pc System](#)

Asus PRIME X570-P