

Package Contents - Asus 4G-AX56 Quick Start Manual


Dual band 4g lte router

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142












•

[Table of Contents](#)

•

Bookmarks


Available languages

-  EN
-  FR
-  DE
-  ES
-  IT
-  NL
-  PT
-  PL
- 



SE

RU



More



Package contents

Package contents

4G-AX56

Ethernet cable



A quick look at 4G-AX56

A quick look at 4G-AX56

Signal LEDs

Mobile Broadband LED

WAN (Internet) LED

5GHz LED

2.4GHz LED

Power LED



Power adapter



Quick Start Guide

Reset button

WPS button


DCIN port

Power On/Off

WAN (Internet) port

LAN ports 1 ~ 4

3



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
2
3
4
5
6
7

Quick Links:

[Package Contents](#)

Related Manuals for Asus 4G-AX56

[Wireless Router Asus 4G-AX56 User Manual](#)

Dual band 4g lte router (106 pages)

[Network Router Asus 4G-N12 Quick Start Manual](#)

Mobile broadband wireless lte router (50 pages)

[Network Router Asus 4G-AC55U Quick Start Manual](#)

Dual-band wireless-ac1200 lte modem router (54 pages)

[Network Router Asus 4G-AC53U Quick Start Manual](#)

(170 pages)

[Network Router Asus 4G-AC53U Quick Start Manual](#)

Wireless-ac750 lte modem router (52 pages)

[Network Router Asus 4G-AC53U Quick Start Manual](#)

Wireless-ac750 lte modem router (52 pages)

[Network Router Asus 4G-N12 B1 Quick Start Manual](#)

Wireless-n300 lte modem router (148 pages)

[Network Router Asus 4G-AC68U User Manual](#)

Dual-band wireless-ac1900 lte modem router (149 pages)

[Network Router Asus 4G-AC86U Quick Start Manual](#)

Wireless-ac2600 cat.12 lte router (143 pages)

[Network Router Asus TUF-AX3000 V2 Quick Start Manual](#)

Tuf gaming ax3000 v2 dual band wifi 6 router (2 pages)

[Network Router Asus TUF GAMING AX4200 User Manual](#)

(137 pages)

[Network Router Asus RT-AX88U Quick Start Manual](#)

Wireless-ax6000 dual band gigabit router (136 pages)

[Network Router Asus RT-AX88U Quick Start Manual](#)

Wireless-ax6000 dual band gigabit router (224 pages)

[Network Router Asus RT-AX86U PRO User Manual](#)

Wireless-ax5700 dual-band gigabit router (130 pages)

[Network Router Asus RT-N66U Dark Knight User Manual](#)

Dual-band wireless-n900 gigabit router (70 pages)

[Network Router Asus RT-AC58U User Manual](#)

Wireless-ac1300 dual band gigabit router (124 pages)

Related Content for Asus 4G-AX56

[RT-AX86U Package Contents](#)

Asus RT-AX86U

[TUF Gaming AX5400 Package Contents](#)

Asus TUF Gaming AX5400

[ZenWiFi XD4 PLUS Package Contents](#)

Asus ZenWiFi XD4 PLUS

[RT-AC66W Package Contents](#)

Asus RT-AC66W

[RT-AC1300G PLUS Package Contents](#)

Asus RT-AC1300G PLUS

[RT-N12E/C1 Package Contents](#)

Asus RT-N12E/C1

[RT-N10 LX Package Contents](#)

Asus RT-N10 LX

[RT-N65R Package Contents](#)

Asus RT-N65R