

Bios Menu Screen - Asus PRIME H310M-R R2.0 Manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13


14

15

16

17

18
19
20
21
22
23
24
25



•

•

Bookmarks



•
•
•
•

BIOS menu screen

Menu bar 

Main

BIOS Information
BIOS Version
Build Date and Time



ME Firmware Version
Processor Information
Brand String
CPU Speed
Total Memory
Memory Frequency

System Date
System Time
Access Level
Security

Sub-menu item


Chapter 2: BIOS information

The BIOS setup screens shown in this section are for reference purposes only, and may not exactly match what you see on your screen.

Visit the ASUS website at www.asus.com to download the latest BIOS file for this motherboard.

If the system becomes unstable after changing any BIOS setting, load the default settings to ensure system compatibility and stability. Select the Load Optimized Defaults item under the Exit menu or press hotkey F5.

If the system fails to boot after changing any BIOS setting, try to clear the CMOS and reset the motherboard to the default value. See section Motherboard overview for information on how to erase the RTC RAM.



Administrator
Configuration fields
General Help
Choose the default
language
: Select Screen
:
Select Item
Enter: Select
+/-: Change Opt.
F1:
General Help
F2:
Previous Values
F5:
Optimized Defaults
F10: Save & Exit
ESC: Exit
2-2



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
16
17
18
19
20
21
22
23

Quick Links:

[Table of Contents](#)

[Prime H310M-R R2.0 Specifications Summary](#)

[Motherboard Overview](#)

[Bios Setup Program](#)

[Chapter 2: Bios Information](#)

[Bios Menu Screen](#)

Related Manuals for Asus PRIME H310M-R R2.0

[Motherboard Asus PRIME H310M-R R2.0 Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H310M-E Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-A User Manual](#)

(29 pages)

[Motherboard Asus PRIME H310M-A R1.0 Instruction Manual](#)

(29 pages)

[Motherboard Asus Prime H310M-C Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-C R2.0 Manual](#)

(28 pages)

[Motherboard Asus TUF H310M-PLUS GAMING R2.0 Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-DASH Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-A R2.0 Manual](#)

(29 pages)

[Motherboard Asus PRIME H310M-E R2.0 Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-K R2.0 Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-AT R2.0 Manual](#)

(29 pages)

[Motherboard Asus PRIME H310M-CS R2.0 Manual](#)

(25 pages)

[Motherboard Asus PRIME H310M2 R2.0 Manual](#)

(26 pages)

[Motherboard Asus H310M-IM-A Manual](#)

(66 pages)

[Motherboard Asus PRIME H310M-C/PS R2.0 Manual](#)

(54 pages)

Related Content for Asus PRIME H310M-R R2.0

[P5KPL-E Bios Menu Screen](#)

Asus P5KPL-E

[PRIME H510T2-CSM R2.0 Bios Menu Screen](#)

Asus PRIME H510T2-CSM R2.0

[B250M-C PRO Bios Menu Screen](#)

Asus B250M-C PRO

[PRIME H610M-C/PS D4 Bios Menu Screen](#)

Asus PRIME H610M-C/PS D4

[Pro A520M-C II Bios Menu Screen](#)

Asus Pro A520M-C II

[Pro Q570M-C Bios Menu Screen](#)

Asus Pro Q570M-C

[Pro B760M-C Bios Menu Screen](#)

Asus Pro B760M-C

[WS C621E SAGE Series Bios Menu Screen](#)

Asus WS C621E SAGE Series

Save PDF