




# Expansion Card Installation - Asus MBD2738 Manual



1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92



•

[Table of Contents](#)

•

## Bookmarks







## 2.1.8

### Expansion card installation

To install PCIe x16 cards

To install PCIe x1 cards

Chapter 2: Basic Installation

2-10



Microchip

## Table of Contents

[Previous Page](#)  
[Next Page](#)

1  
...  
43  
44  
45  
46  
47  
48  
49  
50

## Related Manuals for Asus MBD2738

[Motherboard Asus ROG STRIX B450-E Gaming Manual](#)

(92 pages)

[Motherboard Asus CROSSHAIR User Manual](#)

Crosshair english edition user's manual (174 pages)

[Motherboard Asus M5A99FX PRO R2.0 Manual](#)

Amd socket am3+ (178 pages)

[Motherboard Asus M4N82 - Deluxe Motherboard - ATX User Manual](#)

Nvidia nforce 980a sli chipset (128 pages)

[Motherboard Asus M5A97 LE R2.0 Guía De Inicio Rápido](#)

(12 pages)

[Motherboard Asus M5A97 R2.0 Guía De Inicio Rápido](#)

(12 pages)

[Motherboard Asus M5A97 R2.0 User Manual](#)

(152 pages)

[Motherboard Asus M5A78L-M LE Quick Start Manual](#)

(14 pages)

[Motherboard Asus M5A78L-M LX Plus Manual](#)

M5a78l-m lx series (66 pages)

[Motherboard Asus MAXIMUS VI GENE User Manual](#)

Maximus vi gene user's manual (192 pages)

[Motherboard Asus M5A97 EVO R2.0 User Manual](#)

Amd 970/sb950 chipset (178 pages)

[Motherboard Asus M2N68-LA User Manual](#)

(22 pages)

[Motherboard ASUS Maximus VIII Hero User Manual](#)

(194 pages)

[Motherboard Asus MAXIMUS VIII EXTREME User Manual](#)

(226 pages)

[Motherboard Asus maximus viii formula User Manual](#)

(218 pages)

[Motherboard Asus MAXIMUS IX FORMULA Manual](#)

(114 pages)

## Related Content for Asus MBD2738

[TUF GAMING Z590-PLUS Expansion Card Installation](#)

Asus TUF GAMING Z590-PLUS

[MAXIMUS VII HERO Expansion Card Installation](#)

Asus MAXIMUS VII HERO

[STRIX Z270H GAMING Expansion Card Installation](#)

Asus STRIX Z270H GAMING

[PRIME Z590-V Expansion Card Installation](#)

Asus PRIME Z590-V

[ROG MAXIMUS XII EXTREME Expansion Card Installation](#)

Asus ROG MAXIMUS XII EXTREME

[Pro WS W680-ACE Expansion Card Installation](#)

Asus Pro WS W680-ACE

[ROG MAXIMUS XII Z490 APEX Expansion Card Installation](#)

Asus ROG MAXIMUS XII Z490 APEX

[TUF X470-PLUS GAMING Expansion Card Installation](#)

Asus TUF X470-PLUS GAMING

This manual is also suitable for:

[Rog strix b450-e gaming173847](#)