



Sanyo DVD-HP62 Service Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19

20

• PAGE

1

OF 20 GO

•

[Table of Contents](#)

•

Bookmarks

[Download this manual](#)

Quick Links



Service Manual

CONTENTS

Laser beam safety precaution	1
Exploded View (Packing & Accessories)	2
Exploded View (Cabinet & Chassis)	3
Parts List	4
Schematic Diagram	6
Wiring Diagram	22
Wiring Connection	30


All manuals and user guides at all-guides.com

Portable DVD Player

FILE NO.

DVD-HP62

(XE)



PRODUCT CODE No.

137 130 02

SM

REFERENCE No.

5810758

[Next Page](#)

1
2
3
4
5

Related Manuals for Sanyo DVD-HP62

[Portable DVD Player Sanyo DVD-HP62 Service Manual](#)

(20 pages)

[Portable DVD Player Sanyo DVD-L77 Instruction Manual](#)

Dvd/video cd/cd player with stereo radio and 6.2" widescreen lcd dvd boomer (15 pages)

[Portable DVD Player Sanyo DVD-L77 Instruction Manual](#)

Dvd boomer dvd/video cd/cd player with stereo radio and 6.2" widescreen lcd (15 pages)

[Portable DVD Player Sanyo DVD-L70 Instruction Manual](#)

Portable lcd tv/dvd player (56 pages)

[Portable DVD Player Sanyo DVD-HP42 Service Manual](#)

(19 pages)

[Portable DVD Player Sanyo DVD-HP42 Service Manual](#)

(19 pages)

[Portable DVD Player Sanyo DVD-HP42 Service Manual](#)

(19 pages)

[Portable DVD Player Sanyo MCD-DV595M/XE Service Manual](#)

Dvd portable radio cassette recorder (22 pages)

Summary of Contents for Sanyo DVD-HP62

[Page 1: Table Of Contents](#)

All manuals and user guides at all-guides.com FILE NO. DVD-HP62 Service Manual Portable DVD Player (XE) CONTENTS Laser beam safety precaution 1 PRODUCT CODE No. 137 130 02 Exploded View (Packing & Accessories)2 Exploded View (Cabinet & Chassis) 3 Parts List

[Page 2: Laser Beam Safety Precaution](#)

All manuals and user guides at all-guides.com LASER BEAM SAFETY PRECAUTION • Pickup that emits a laser beam is used on this CD section. CAUTION : USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

[Page 3: Exploded View \(Packing & Accessories\)](#)

All manuals and user guides at all-guides.com EXPLODED VIEW (PACKING & ACCESSORIES) - 2 - ...

[Page 4: Exploded View\(Cabinet & Chassis\)](#)

All manuals and user guides at all-guides.com EXPLODED VIEW(CABINET & CHASSIS) - 3 -...

[Page 5: Parts List](#)

All manuals and user guides at all-guides.com PARTS LIST PRODUCT SAFETY NOTICE EACH PRECAUTION IN THIS MANUAL SHOULD BE FOLLOWED DURING SERVICING. COMPONENTS IDENTIFIED WITH THE IEC SYMBOL IN THE PARTS LIST AND THE SCHEMATIC DIAGRAM DESIGNATE COMPONENTS IN WHICH SAFETY ! ! ! CAN OF SPECIAL SIGNIFICANCE.

[Page 6](#) All manuals and user guides at all-guides.com REF.NO. PART NO. DESCRIPTION
REF.NO. PART NO. DESCRIPTION D0004 645 081 8813 DIODE SK34 LED01 645 068 5163 LED

F0001 645 081 9063 FUSE Q0002 645 068 5125 TRANSISTOR 3906 IC004 645 081 8806
TRANSISTOR SI9435A Q0003 645 075 8461 TRANSISTOR AO3407 IC005...

[Page 7: Schematic Diagram](#)

All manuals and user guides at all-guides.com SCHEMATIC DIAGRAM (MAIN-1) This is a basic schematic diagram. - 6 - - 7 -...

[Page 8](#) All manuals and user guides at all-guides.com SCHEMATIC DIAGRAM (MAIN-2) This is a basic schematic diagram. - 8 - - 9 -...

[Page 9](#) All manuals and user guides at all-guides.com SCHEMATIC DIAGRAM (MAIN-3) This is a basic schematic diagram. - 10 - - 11 -...

[Page 10](#) All manuals and user guides at all-guides.com SCHEMATIC DIAGRAM (MAIN-4) This is a basic schematic diagram. - 12 - - 13 -...

[Page 11](#) All manuals and user guides at all-guides.com SCHEMATIC DIAGRAM (MAIN-5) This is a basic schematic diagram. - 14 - - 15 -...

[Page 12](#) All manuals and user guides at all-guides.com SCHEMATIC DIAGRAM (MAIN-6) This is a basic schematic diagram. - 16 - - 17 -...

[Page 13](#) All manuals and user guides at all-guides.com SCHEMATIC DIAGRAM (DVD KEY) SCHEMATIC DIAGRAM (BATTERY CHARGE) - 18 - - 19 -...

[Page 14](#) All manuals and user guides at all-guides.com SCHEMATIC DIAGRAM (MONITOR MAIN) 0.1uF R272 R250 560 R236 680K 380PF R238 330K C254 C215 0.1uF R240 R231 0.1uF R242 C234 C217 C232 C203 0.82uH 0.01uF 1000P 18uH C219 1000 100PF R233 0.1uF NJM2107F C216 0.1uF...

[Page 15: Wiring Diagram](#)

All manuals and user guides at all-guides.com WIRING DIAGRAM (DVD MAIN A SIDE) - 22 - - 23 - ...

[Page 16](#) All manuals and user guides at all-guides.com WIRING DIAGRAM (DVD MAIN B SIDE) - 24 - - 25 -...

[Page 17](#) All manuals and user guides at all-guides.com WIRING DIAGRAM (BATTERY CHARGE) WIRING DIAGRAM (DVD KEY) - 26 - - 27 -...

[Page 18](#) All manuals and user guides at all-guides.com WIRING DIAGRAM (MONITOR MAIN) - 28 - - 29 -...

[Page 19: Wiring Connection](#)

All manuals and user guides at all-guides.com WIRING CONNECTION - 30 -...

[Page 20](#) All manuals and user guides at all-guides.com SANYO Electric Co., Ltd. Osaka, Japan Jun / '05 Printed in Japan...