



Asus SDRW-08U5S-U Quick Installation Manual

External slim dvd-writer

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19

20

21

•

Troubleshooting

•

Bookmarks

--

[Download this manual](#)

Quick Links



External Slim DVD- Writer

Q

Quick Installation Guide

English

Ελληνικά

Español

한국어

Eesti

Български

Suomi

Česky

Français

Dansk

Magyar

Deutsch

Bahasa Indonesia

Model / нормативная модель : SDRW-08U5S-U

2018

Computer Inc.

SDRW-08U5S-U

Italiano

Norsk

Polski

Қазақ

Português

Lietuvių

Română

Latviski

Русский

Bahasa Malaysia

Slovensky

Nederlands

Slovenščina

In 35 Languages

Svenska

한국어

Türkçe

(Kurulum Kılavuzu)

Tiếng Việt

Українська

عربي

فارسی

1

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus SDRW-08U5S-U

[DC Drives Asus SDRW-08D2S-U Quick Installation Manual](#)

Optical drive (28 pages)

[Storage Asus SDRW-08D2S-U Quick Installation Manual](#)

(10 pages)

[Blu-ray Drive Asus SDRW-S1 Quick Start Manual](#)

External usb dvd / blu-ray writer with sound card (124 pages)

[Blu-ray Drive Asus SDRW-08U7M-U Quick Installation Manual](#)

External slim dvd-writer (19 pages)

[Blu-ray Drive Asus SBW-06D5H-U Quick Installation Manual](#)

External slim blu-ray drive (21 pages)

[Blu-ray Drive Asus SBC-06D2X-U Quick Installation Manual](#)

External slim (21 pages)

[Blu-ray Drive Asus Turbo Drive BW-16D1H-U Quick Installation Manual](#)

External blu-ray writer (21 pages)

[Blu-ray Drive Asus BW-16D1X-U Quick Installation Manual](#)

External blu-ray writer (19 pages)

[Blu-ray Drive Asus BW-12D1S-U Quick Installation Manual](#)

External blu-ray writer (21 pages)

[Blu-ray Drive Asus BW-16D1X-U Quick Installation Manual](#)

External 16x blu-ray writer (36 pages)

[Blu-ray Drive Asus TurboDrive BW-16D1H-U PRO Quick Installation Manual](#)

External 16x blu-ray writer external blu-ray writer (22 pages)

[Blu-ray Drive Asus BW-14D1XT Datasheet](#)

Optical disc drive internal blu-ray writer (2 pages)

Summary of Contents for Asus SDRW-08U5S-U

[Page 1](#) Tiếng Việt Český Français Latviski Русский Українська عربي Dansk Magyar Bahasa Malaysia Slovensky فارسی Deutsch Bahasa Indonesia Nederlands Slovenščina Model / нормативная модель : SDRW-08U5S-U V 7.6 Published June 2018 Copyright © 2018 ASUSTeK Computer Inc. All Rights Reserved. 15060-0CW20500...

[Page 2: Safety Information](#)

Safety Information • Do not place damaged discs inside the device. A damaged disc may break while in use and damage the device. • Use of any controls, adjustments, or procedures other than those specified in this manual may result to hazardous radiation exposure. •...

[Page 3: Australia Statement Notice](#)

○ ○ ○ ○ goods fail to be of acceptable quality and the failure does not amount to a major failure. If you require assistance please call ASUS Customer Service 1300 2787 88 繁體中文 ○ ○ ○ ○ ○...

[Page 4](#) Compliance Statement of Innovation, Science and Economic Development Canada (ISED) This device complies with Innovation, Science, and Economic Development Canada licence exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including

Page 5 Поместите оптический привод на устойчивую Поставьте оптическое устройство на стабилна поверхность. повърхност. Place the optical drive on a stable surface.
Примечание: Вы можете заложить оптический ЗАБЕЛЕЖКА: Можете да поставите оптический привод горизонтально на ровную поверхность устройства горизонтално върху стабилна или използвайте встроена подставка, чтобы повърхност...

Page 7

Đặt ổ đĩa quang trên bề mặt cố định. Оптикалық жетекті қалыпты бетке қойыңыз.

LƯU Ý: Bạn có...

Page 9 Az optikai meghajtót csatlakoztassa a számítógéphez. Menyambungkan optical drive pada komputer. Conectarea drive-ului optic la computerul dvs. Pripojte optický mechaniku ku svojmu počítaču. A. A mellékelt USB kábelt csatlakoztassa a A. Sambungkan kabel USB Y yang disertakan pada A. Conectați legătura cablului USB Y la computerul dvs. A.

Page 11 Убедитесь, что система обнаружила Уверете се, че системата е открила външното външен оптичен привод. оптично устройство. Ensure that your system detects the external optical drive. Для проверки наличия оптического привода в Проверка дали оптичното устройство е открито чрез диспетчере устройств: Device Manager (Диспетчер...

Page 14 Safely Remove the External Optical Drive. The external optical drive supports Plug & Play. To safely remove the drive: A. From the taskbar of your computer, click the Safely Remove Hardware icon (). B. On the pop-up message, click Safely Remove Hardware and Eject Media. C.

Page 15 Безопасное извлечение внешнего Безопасно премахване на външно Poista ulkoinen optinen asema. Αφαίρεστε με ασφάλεια την εξωτερική οπτική οπтического привода. оптично устройство модабд. Ulkoinen optinen asema tukee Plug & Play Внешний оптический привод поддерживает Външното оптично устройство поддържа -ominaisuutta. Noudata alla olevia vaiheita H...

Page 16 Tanggalkan Pemacu Optik Luaran Dengan Trygg fjerning av den eksterne optiske Varno odstranite zunanji optični gonilnik. Ta bort den externa optiska enheten på Selamat. stasjonen. Zunanji optični gonilnik podpira funkcijo »vstavi in ett säkert sätt. Pemacu optik luaran menyokong Palam & Den eksterne optiske stasjonen støtter Plug &...

Page 17 000000000000000000 0000000000 00000000000000000000000000 00000000000000
000000 000000 00000000000000000000000000 00000000000000000000000000 A. 00000000000000000000
00 000 00 00 00000000) 0000000000 0000000000“0000000000 B. 0000000000000000 { 00000000000000 00
0“0 0000000000“USB 0000000 00000000000000 } 0000000000 0000000000“0000000000 0000000000000000 { 0
0000000000000000 000 000000000000000000 } 000000000000 00 : 0000000000000000 LED 0 00000000 USB Y 0000
0000000000 0000000000000000...

Page 18: Troubleshooting

2. Check if the USB Y cable is connected properly. See Step 2 Connect the optical drive to your computer for details. 3. Turn on your computer. NOTE For more technical service, contact your retailer or the ASUS Technical Support. Dépannage Fehlerbehebung Si votre ordinateur ne parviens pas à...

Page 19 Para serviço mais técnico, contacte υποστήριξη, επικοινωνήστε με το κατάστημα palvelua ota yhteys myyjääsi tai ASUS-yhtiön informacji technicznych, skontaktuj się o seu vendedor ou o Suporte técnico ASUS. λιανικής πώλησης ή την Τεχνική Υποστήριξη της tekniseen tukeen. ze sprzedawcą lub z pomocą techniczną...

Page 20 Қосымша техникалық *tehnčno podpora*. thuật, hãy liên hệ với cửa hàng bán sản phẩm *қызмет алу үшін сатушыға немесе* hoặc Bộ phận hỗ trợ kỹ thuật của ASUS. ASUS компаниясының техникалық қолдау қызметіне хабарласыңыз. **□□□□□ □ □□ □ □** Sorun Giderme **□□...**

[Page 21](#) SDRW-08U5S-U For a superior burning experience...