

Reference Information - Toshiba 21S04B Service Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51

--

•

[Table of Contents](#)

•

Bookmarks



2. Reference Information

2-1 Tables of Abbreviations and Acronyms

A	
Ah	
Å	
dB	
dBm	
°C	
°F	
°K	
F	
G	
GHz	
g	

H	
Hz	
h	
ips	
kWh	
kg	
kHz	
kΩ	
km	
km/h	
kV	
kVA	
kW	

I	
---	--

MHz	
-----	--

Table 2-1 Abbreviations

Ampere	
Ampere-hour	
Angstrom	
Decibel	
Decibel Referenced to One	
Milliwatt	
Degree Celsius	
Degree Fahrenheit	
degree Kelvin	
Farad	
Gauss	
Gigahertz	
Gram	
Henry	
Hertz	
Hour	
Inches Per Second	
Kilowatt-hour	
Kilogram	
Kilohertz	
Kilohm	
Kilometer	
Kilometer Per Hour	
Kilovolt	
Kilovolt-ampere	
Kilowatt	
Liter	
Megahertz	
MV	
Megavolt	
MW	
Megawatt	
MΩ	
Megohm	

m	
Meter	
μA	
Microampere	
μF	
Microfarad	
μH	
Microhenry	
μm	
Micrometer	
μs	
Microsecond	
μW	
Microwatt	
mA	
Milliampere	
mg	
Milligram	
mH	
Millihenry	
ml	
Milliliter	
mm	
Millimeter	
ms	
Millisecond	
mV	
Millivolt	
nF	
Nanofarad	
Ω	
Ohm	
pF	
Picofarad	
lb	
Pound	
rpm	
Revolutions Per Minute	
rps	
Revolutions Per Second	
s	
Second (Time)	
V	
Volt	
VA	
Volt-ampere	
W	
Watt	
Wh	

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
3
4
5
6
7
8
9
10

Related Manuals for Toshiba 21S04B

[TV Toshiba 21S23D Service Manual](#)

Colour television (41 pages)

[TV Toshiba CPBRO2005Eu Catalog](#)

Home cinema catalogue 2005-6 (21 pages)

[TV Toshiba 21SZ5TM Service Manual](#)

(32 pages)

[TV Toshiba 21CS2TR Service Manual](#)

S3e chassis (52 pages)

[TV Toshiba 21CSZ7DR Service Manual](#)

S3es chassis (56 pages)

[TV Toshiba 21SZ2E Service Manual](#)

S3es chassis (70 pages)

[TV Toshiba 21S23B2 Owner's Manual](#)

(32 pages)

[TV Toshiba 21S23N Service Manual](#)

(41 pages)

[TV Toshiba 21SZ5E1 Service Manual](#)

(28 pages)

[TV Toshiba 21E88 Service Manual](#)

Color television (69 pages)

[TV Toshiba 21AZ5VX Service Manual](#)

Toshiba s0es chassis colour television service manual (38 pages)

[TV Toshiba 21VZ3E Service Manual](#)

(30 pages)

[TV Toshiba 21V53G Manual](#)

(21 pages)

[TV Toshiba 2152 DB Service Manual](#)

(6 pages)

[TV Toshiba Nicam 2173DB Owner's Manual](#)

Digital stereo colour television with fasttext (20 pages)

[TV Toshiba 2132DS Owner's Manual](#)

Colour televisio with stereo & text (20 pages)

Related Content for Toshiba 21S04B

[42 UL23 Series Safety Information](#)

Toshiba 42 UL23 Series

[32 W22 Series Safety Information](#)

Toshiba 32 W22 Series

[65 XL9C Series Safety Information](#)

Toshiba 65 XL9C Series

[43 UA23 Series Safety Information](#)

Toshiba 43 UA23 Series

[50UA2063DG Safety Information](#)

Toshiba 50UA2063DG

[70 QF5D Series Safety Information](#)

Toshiba 70 QF5D Series

[32 WF2F Series Safety Information](#)

Toshiba 32 WF2F Series

[21N21B On Screen Information](#)

Toshiba 21N21B

This manual is also suitable for:

[21s04d21s04f21s04i21s04n](#)