



# Toshiba D-R5SC Service Manual

Dvd video recorder



1

2

3

4

Table Of Contents

5

6

7

8

9

10

11

12

13

14

15

16

17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33

--

•

[Table of Contents](#)

•

## Bookmarks

[Download this manual](#)

## Quick Links





# SERVICE MANUAL **TOSHIBA**

The above models are classified as green products (\*1), as indicated by the underlined serial numbers. This Service Manual describes replacement parts for the green products.

When

repairing these green product(s), use the part(s) described in this manual and lead-free solder (\*2).

For (\*1) and (\*2), see the next page.

All manuals and user guides at [all-guides.com](http://all-guides.com)

**DVD VIDEO RECORDER**   

FILE NO. 810-200602GR

DIGITAL VIDEO

 **SPATIALIZER**® 

# D-R5SC TOSHIBA

# D-R5SU

Mar.,2006 GREEN



[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Toshiba D-R5SC

### [DVD Recorder Toshiba D-R5SC Owner's Manual](#)

Toshiba dvd video recorder owner's manual d-r5su, d-r5sc (58 pages)

### [DVR Toshiba D-R5SU Owner's Manual](#)

(58 pages)

### [DVD Player Toshiba SD-3108 Owner's Manual](#)

(54 pages)

### [DVR Toshiba D-R5SC Service Manual](#)

(33 pages)

### [DVR Toshiba D-R5 Specification Sheet](#)

Toshiba digital video recorder specification sheet (2 pages)

### [DVR Toshiba D-R560KU Owner's Manual](#)

D-r560ku user's guide (117 pages)

### [DVR Toshiba DR570KU Owner's Manual](#)

Dr570ku user's guide (118 pages)

### [DVR Toshiba D-R550KU Owner's Manual](#)

D-r550ku user's guide (115 pages)

### [DVR Toshiba D-R550 Owner's Manual](#)

Dvd video recorder (125 pages)

### [DVR Toshiba DR570KU Owner's Manual](#)

Toshiba dr570ku dvd video recorder owner's manual (123 pages)

### [DVR Toshiba D-R560KU Service Manual](#)

(72 pages)

### [DVR Toshiba D-RW2SU Owner's Manual](#)

D-rw2su user's guide (157 pages)

### [DVR Toshiba DR420KU Owner's Manual](#)

Dvd video recorder (111 pages)

### [DVR Toshiba DR430KU Owner's Manual](#)

Dvd video recorder (110 pages)

### [DVR Toshiba DR20KB Owner's Manual](#)

Dr20 dvd recorder (76 pages)

### [DVR Toshiba D-R1SB Service Manual](#)

(49 pages)

## Summary of Contents for Toshiba D-R5SC

**Page 1** FILE NO. 810-200602GR SERVICE MANUAL DIGITAL VIDEO DVD VIDEO RECORDER D-R5SC D-R5SU The above models are classified as green products (\*1), as indicated by the underlined serial numbers. This Service Manual describes replacement parts for the green products. When repairing these green product(s), use the part(s) described in this manual and lead-free solder (\*2).

**Page 2** Hazardous Substances. From July 1, 2006, the RoHS Directive will prohibit any marketing of new products containing the restricted substances. Increasing attention is given to issues related to the global environmental. Toshiba Corporation recognizes environmental protection as a key management tasks, and is doing its utmost to enhance and improve the

quality and scope of its environmental activities.

[Page 3](#) All manuals and user guides at all-guides.com LASER BEAM CAUTION LABEL When the power supply is being turned on, you may not remove this laser cautions label. If it removes, radiation of a laser may be received. PREPARATION OF SERVICING Pickup Head consists of a laser diode that is very susceptible to external static electricity.

[Page 4](#) All manuals and user guides at all-guides.com SAFETY NOTICE SAFETY PRECAUTIONS LEAKAGE CURRENT CHECK Measure the AC voltage across the 1500  $\Omega$  resistor. Plug the AC line cord directly into a 120V AC outlet (do not use an isolation transformer for this check). Use an The test must be conducted with the AC switch on and AC voltmeter, having 5000  $\Omega$ ...

### [Page 5: Table Of Contents](#)

All manuals and user guides at all-guides.com CONTENTS 1. LOCATION OF MAIN PARTS 1-1. Location of Main Parts 1-2. Location of PC Boards 2. WIRING CONNECTION DIAGRAM 3. PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM 4. BLOCK DIAGRAMS 4-1. MPEG & SYSTEM Block Diagram 4-2.

### [Page 6: Location Of Main Parts](#)

All manuals and user guides at all-guides.com 1. LOCATION OF MAIN PARTS 1-1. Location of Main Parts RAM DRIVE Fig. 1-1-1 1-2. Location of PC Boards Power Switch PC board Digital PC board AV Tuner Unit PC board DV/AV Input PC board Front Display PC board Power PC board Fig.

### [Page 7: Wiring Connection Diagram](#)

All manuals and user guides at all-guides.com 2. WIRING CONNECTION DIAGRAM After the servicing is complete, return the wiring to its original state by using the diagram below as a reference. AV Tuner Unit PC board W301 W303 Digital PC board W104 Tape W802...

### [Page 8: Printed Wiring Board And Schematic Diagram](#)

All manuals and user guides at all-guides.com 3. PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM W802 CN802 FLAT WIRE 2.54 9P CN302 ON/OFF 5V ON/OFF 5V +3.3 V +3.3 V +3.3 V +3.3 V Power AV-TUNER ON/OFF 5V ON/OFF 5V AP+12 V AP+12 V AN-12 V AN-12 V...

### [Page 9: Block Diagrams](#)

All manuals and user guides at all-guides.com 4. BLOCK DIAGRAM 4-1. MPEG & SYSTEM Block Diagram 128M SDRAM Digital Audio Out WM8776 IC504 J502 IC514 IC502 128M SDRAM 128M SDRAM L OUT IC507 Video FRONT 4558 R OUT 128M SDRAM Video IC503 32M FLASH...

### [Page 10: Power Supply Block Diagram](#)

All manuals and user guides at all-guides.com 4-2. Power Supply Block Diagram T101 D301 C301 D101-D104 C105 RECTIFIER TRANS 12V SW AP+12V RECTIFIER SMOOTHING SMOOTHING Q101 D201 C201 SW IC RECTIFIER +32V 32V SW SMOOTHING IC101 D403 D404 L101 3.3V ADJUST CONTROL IC AC FILTER...

### [Page 11: Circuit Diagrams](#)

All manuals and user guides at all-guides.com 5. CIRCUIT DIAGRAMS 5-1. Power Supply Circuit Diagram Fig. 5-5-1...

### [Page 12: Front Display & Power Switch Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-2. Front Display & Power Switch Circuit Diagram JC102 U102 L108 SW101 SW102 SW103 L109 L101 OPEN/CLOSE L108 CN105 SW104 SW105 SW106 L109 R126 R128 R130 CN104 PDHMS JC101 L102 AL\_F STOP PLAY GR5# GR6# AR\_F...

### [Page 13: Audio & Video Tuner Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-3. Audio & Video Tuner Circuit Diagram C . N 7 . 4 7 . 4 C . N Fig. 5-5-3...

## [Page 14: Digital Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-4. Digital Circuit Diagram Digital Circuit System Diagram ATAPI INTERFACE Video Output ATAPI INTERFACE VIDEO OUTPUT\_1 CVBS CVBS CVBS AUDIO\_OUT\_R +3.3V +3.3V AUDIO\_OUT\_L V\_GND AGND V\_GND 0R(0805) 75R/1% 75R/1% 75R/1% 75R/1% 75R/1% AUDIO OUTPUT MUTE- AUDIO\_OUT\_L...

## [Page 15: Audio Output Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-4-1. Audio Output Circuit Diagram J504 R280 GP1FAV51TK0F R281 SPDIF SP5V 2N3906 C102 R279 100pF C307 D15 BAT54S 47uF/16V BAT54S C308 0.1uF 220uF/16V A-12V A12V R288 R287 D20 BAT54S D18 BAT54S R285 R286 FB19 R290 100K...

## [Page 16: Decoder & Sdram Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-4-2. Decoder & SDRAM Circuit Diagram VDD\_DAC +1.8V +3.3V +3.3V 47uF/16V 47uF/16V 47uF/16V 47uF/16V +3.3V +1.8V RESET CIRCUIT RESET- RESET- IC510 NVMDA0 DAC\_BU NVMDA1 DAC\_RV ANALOG VIDEO OUTPUTS NVMDA2 DAC\_GY CVBS CVBS CVBS NVMDA3 DAC\_CVBS NVMDA4...

## [Page 17: Hdmi Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-4-3. HDMI Circuit Diagram J503 HDMI\_TYPE\_A +1.8V +3.3V TDMS\_D2+ FB25 TDMS\_D2\_SHIELD HD\_3.3V TDMS\_D2- TDMS\_D1+ FB26 TDMS\_D1\_SHIELD HD\_1.8V TDMS\_D1- TDMS\_D0+ +3.3V +1.8V TDMS\_D0\_SHIELD TDMS\_D0- TDMS\_CLK+ A12V HD\_+5V TDMS\_CLK\_SHIELD A12V IC515 TDMS\_CLK- L78L05/TO92 A12V R340 1.8K +3.3V HD\_+5V...

## [Page 18: Audio & Video Input Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-4-4. Audio & Video Input Circuit Diagram TP95 VGND AGND VGND IC518 CN507 TP72 9PIN + HOUSING C383 10nF TP73 R352 330R R349 AL\_FRONT I55\_CVBSIN C384 10nF C387 C385 10nF C386 TP74 CTLA 47uF/16V 0.1uF R356...

## [Page 19: 1394 Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-4-5. 1394 Circuit Diagram PHY\_PLL\_VCC PHY\_VCC +3.3V +1.5V IC505 ISODIR ISODIR ISOVALRX ISOVALRX ISORDY ISORDY ISOCLK PCI\_AD31 HSDIO\_CLK ISOCLK ISOSTART PCI\_AD30 HSDIO\_SYNC ISOSTART ISOVALTX PCI\_AD29 HSDIO\_DVALID/HSDIO\_EN ISOVALTX ERROR PCI\_AD28 HSDIO\_ERROR GBADR[9:0] GBADR[9:0] PCI\_AD27 DSSCLK27 GBDAT[15:0] ISOD0...

## [Page 20: Encoder & Sdram Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-4-6. Encoder & SDRAM Circuit Diagram +3.3V +1.8V +3.3V +1.8V +3.3V 47uF/16V 47uF/16V 47uF/16V IC506 4.7K ISOSTART ISOSTART ISOVALRX SBCLK ISOVALRX OSBCLK ISOVALTX SBVALID ISOVALTX OSBVALID ISODIR ISODIR OSBDAT SBDAT ISOCLK ISOCLK OSBREQ SBREQ ISORDY ISORDY...

## [Page 21: Atapi Interface Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-4-7. ATAPI Interface Circuit Diagram RP20 22RX4 22RX4 22RX4 RP19 22RX4 ATDD[0..15] TP43 TP44 TP45 TP46 TP47 TP48 TP49 TP50 TP51 DRVRST- CN504 HEADER 20X2 TP52 TP53 TP54 TP55 TP56 TP57 TP58 TP59 TP60 TP61 TP62...

## [Page 22: Power Supply Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-4-8. Power Supply Circuit Diagram TP15 IC508 LT1086-ADJ VOUT +1.8V C162 47uF/16V 0.1uF 121R/1% TP16 10uF/16V 0.1uF 47uF/16V 53.6R/1% 10uF/16V 47uF/16V 0.1uF TP90 CN509 TP91 DF1117-ADJ SOT-223 IC501 +1.5V 47uF/16V 47uF/16V 0.1uF R233 TP92 TP93 C246...

## [Page 23: Video Output Circuit Diagram](#)

All manuals and user guides at all-guides.com 5-4-9. Video Output Circuit Diagram C289 15pF C290 C291 150pF 150pF C292 15pF +3.3V C293 C294 150pF 150pF +3.3V V\_GND C295 15pF AGND V\_GND TP96 TP97 TP98 J501 C296 C297 FB13 150pF 150pF FB14 FB15 C298 15pF...



## [Page 24: Pc Boards](#)

All manuals and user guides at all-guides.com 6. PC BOARDS 6-1. DV/AV Input PC Board Fig. 6-6-1 DV/AV Input PC Board (Top side) Fig. 6-6-2 DV/AV Input PC Board (Bottom side) 6-2. Power Switch PC Board Fig. 6-6-3 Power Switch PC Board (Top side) Fig.

## [Page 25: Front Display Pc Board](#)

All manuals and user guides at all-guides.com 6-3. Front Display PC Board Fig. 6-6-5 Front Display PC Board (Top side) Fig. 6-6-6 Front Display PC Board (Bottom side)

## [Page 26: Av Tuner Unit Pc Board](#)

All manuals and user guides at all-guides.com 6-4. AV Tuner Unit PC Board Fig. 6-6-7 AV Tuner Unit PC Board (Top side) Fig. 6-6-8 AV Tuner Unit PC Board (Bottom side)

## [Page 27: Digital Pc Board](#)

All manuals and user guides at all-guides.com 6-5. Digital PC Board Fig. 6-6-9 Digital PC Board (Top side) Fig. 6-6-10 Digital PC Board (Bottom side)

## [Page 28: Exploded Views](#)

All manuals and user guides at all-guides.com 7. EXPLODED VIEWS 7-1. Packing Assembly A106 TC A101 A104 A105 A107 TU A101 A102 A103 Fig. 7-7-1...

## [Page 29: Chassis Assembly](#)

All manuals and user guides at all-guides.com 7-2. Chassis Assembly B101 W301 EU04 P801 EU01 EU02 W501 B001 Y001 Fig. 7-7-2...

## [Page 30: Parts List](#)

All manuals and user guides at all-guides.com 8. PARTS LIST: D-R5 Location TSB P/N Reference No. Description A101 AH930020 TDRAC10001A \* OWNER'S MANUAL (ENGLISH)TSB CODE (For SU,SC Version) AH930021 A102 TDRAC10003A \* QUICK SETUP GUIDE(1 PAGE)(ENGLISH) A103 AH910018 TRE900006XX \* REMOTE CONTROL A104 AH930022 TDRAC10002A...

[Page 31](#) All manuals and user guides at all-guides.com Location TSB P/N Reference No. Description MAIN UNIT ASS'Y AH910020 TQC000011XX @TRANSISTOR SOT-23 BAT54D(SMD) AH910020 TQC000011XX @TRANSISTOR SOT-23 BAT54D(SMD) AH910020 TQC000011XX @TRANSISTOR SOT-23 BAT54D(SMD) AH910020 TQC000011XX @TRANSISTOR SOT-23 BAT54D(SMD) AH910020 TQC000011XX @TRANSISTOR SOT-23 BAT54D(SMD) AH910020 TQC000011XX @TRANSISTOR SOT-23 BAT54D(SMD) AH910020 TQC000011XX @TRANSISTOR SOT-23 BAT54D(SMD)

[Page 32](#) All manuals and user guides at all-guides.com SPECIFICATIONS Power requirement during operation Power requirement at standby 1.3W Power supply 120V AC, 60 Hz Mass 3.5kg External dimension Width 430 x Height 62 x Depth 302mm Incoming channels TV : 2-69CH, Cable : 1-125CH Antenna input/output terminal VHF/UHF : 75Ω, RF Connector Signal system...

[Page 33](#) All manuals and user guides at all-guides.com 1-1, SHIBAURA 1-CHOME, MINATO-KU, TOKYO 105-8001, JAPAN...

This manual is also suitable for:

[D-r5su](#)