



# Sanyo AVM-27D6 Instruction Manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22

• PAGE

1
---

OF 22 GO

•

[Table of Contents](#)

•

## Bookmarks

## Quick Links

[1 Introduction](#)

[2 Video/Audio Connections](#)

[Download this manual](#)





All manuals and user guides at [all-guides.com](http://all-guides.com)

#### TABLE OF CONTENTS

[Introduction](#)  
[Safety Instructions](#)  
[Locations of Controls](#)  
[Use of Remote Control](#)  
[Antenna Connections](#)  
[Cable TV Connections](#)  
[Video/Audio Connections](#)  
[Basic Operation](#)  
[Basic Menu Operation](#)  
[Set-Up](#)  
[Antenna Selection](#)  
[Auto Channel Programming](#)  
[Manual Memory \(Add/Delete\)](#)  
[Fine Tuning](#)  
[Channel Guide](#)  
[Channel Guard](#)  
[Picture Adjustment](#)  
[P.STD Button](#)  
[Manual Adjustment](#)  
[Sound Adjustment](#)  
[S.STD Button](#)  
[Sound Menu](#)  
[MTS](#)  
[Clock/Timer](#)



[Functions](#)

[Picture-in-Picture \(AVM-27D11 only\)](#)

[Other Useful Functions](#)

[Reception Disturbance](#)

[Care and Maintenance](#)

[Troubleshooting Guide](#)

[Warranty](#)

1

2

3

4

5

6

7

8

10

11

13

21

24

28

32

34

38

39

39

40

41



[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Sanyo AVM-27D6

### [CRT TV Sanyo AVM-27D11 Instruction Manual](#)

Sanyo avm-27d11: user guide (22 pages)

### [TV Sanyo AVM-1309S, AVM-1901S, AVM-2509S Owner's Manual](#)

Color tv (44 pages)

### [TV Sanyo AVM-2550S Training Manual](#)

(75 pages)

### [TV Sanyo AVM-2751S Owner's Manual](#)

Sanyo owner's manual portable tv avm-2751s (52 pages)

### [TV Sanyo AVM-2751S Service Manual](#)

Remote control color television (26 pages)

### [TV Sanyo AVM2425 Owner's Manual](#)

Sanyo color tv owner's manual (2 pages)

### [TV Sanyo AVM2445 Owner's Manual](#)

Sanyo color tv owner's manual (18 pages)

### [TV Sanyo AVM-1420MA Service Manual](#)

Uoc tda9370 with ntsc/pal-m / pal-n (18 pages)

### [TV Sanyo AVM-2120MA Service Manual](#)

Remote control color television (17 pages)

### [TV Sanyo AVM-2058G Service Manual](#)

(32 pages)

### [TV Sanyo AVM-3259G Owner's Manual](#)

Sanyo owner's manual color tv avm-3259g (40 pages)

### [TV Sanyo AVM-3650G Owner's Manual](#)

Sanyo color tv owner's manual model no. avm-3259g avm-3650g (36 pages)

### [TV Sanyo AVM-3259S Owner's Manual](#)

Color tv (56 pages)

### [TV Sanyo AVM-3651G Service Manual](#)

Remote control color television (30 pages)

### [TV Sanyo AVM-3651G Owner's Manual](#)

Color tv (44 pages)

### [TV SANYO AVM-3660G Owner's Manual](#)

Color tv (20 pages)

## Summary of Contents for Sanyo AVM-27D6

### [Page 1: Table Of Contents](#)

All manuals and user guides at all-guides.com  
TABLE OF CONTENTS  
Introduction  
Safety  
Instructions  
Locations of Controls  
Use of Remote Control  
Antenna Connections  
Cable TV Connections  
Video/Audio Connections  
Basic Operation  
Basic Menu Operation  
Set-Up  
Antenna Selection  
Auto Channel Programming  
Manual Memory (Add/Delete)  
Fine Tuning  
Channel Guide  
Channel Guard...

### [Page 2: Introduction](#)

All manuals and user guides at all-guides.com  
INTRODUCTION  
SAFETY INSTRUCTIONS  
Congratulations on your purchase of this Sanyo MTS stereo television.  
ANTENNA  
The stereo

speakers are front-mounted at the left and right sides of the TV screen for better Unless your TV is connected to a Cable TV system or to a centralized antenna system, a good stereo effect, delivering a high audio output of 24 watts (total).

### [Page 3: Locations Of Controls](#)

All manuals and user guides at all-guides.com LOCATION OF CONTROLS USE OF THE REMOTE CONTROL FRONT Point to remote control sensor of the TV set. The maximum operable distance is approximately 20 feet from the remote control sensor, and not more than 30 to either side of center. The operation of the remote control is most effective when there is nothing between it and the remote control sensor.

### [Page 4: Antenna Connections](#)

All manuals and user guides at all-guides.com ANTENNA CONNECTION CABLE TV (CATV) CONNECTION ANTENNA A 75-ohm coaxial cable connector is built into the set for easy hookup. When connecting the 75 ohm coaxial cable to the set, screw the 75-ohm cable to the The antenna requirements for good color television reception are more important than those COAXIAL CABLE CONNECTOR.

### [Page 5: Video/Audio Connections](#)

All manuals and user guides at all-guides.com VIDEO/AUDIO CONNECTIONS Prior to making any connections to your TV set, be sure to turn the POWER off. For a more detailed understanding of each connection, it is recommended that you read the instruction manual for each connected component.

### [Page 6: Basic Operation](#)

All manuals and user guides at all-guides.com BASIC OPERATION BASIC MENU OPERATION icon is used as a cursor. 1. Press POWER button to turn the TV on. FIRST PREPARATIONS 2. Press MENU button and move the cursor to "SET UP" option and press VOL + button. Connect either Antenna or Cable TV according to "ANTENNA CONNECTION"...

### [Page 7: Set-Up](#)

All manuals and user guides at all-guides.com BASIC MENU OPERATION SET-UP ANTENNA SELECTION You can execute every operation by pressing CH buttons and VOL + / - buttons alternately. In this mode, you can change the broadcast mode between " TV " (for regular VHF/UHF If you learn one menu, you can easily operate other functions by viewing pictures.

### [Page 8: Auto Channel Programming](#)

All manuals and user guides at all-guides.com SET-UP SET-UP AUTO CHANNEL PROGRAMMING MANUAL MEMORY (channel add/delete) This function allows the channels to be memorized automatically to match the TV broadcasts 1. TO ADD A CHANNEL and cable channels in your area. If you want to add to the memory a channel the TV does not store during AUTO PROGRAM, follow these steps.

### [Page 9: Fine Tuning](#)

All manuals and user guides at all-guides.com SET-UP SET-UP FINE TUNING CHANNEL GUIDE If the reception is clear, you do not have to fine-tune the channel, as this is done automatically You can choose up to 5 channels and assign them to the Channel Guide (CH GUIDE). during auto program and manual memory.

### [Page 10: Channel Guard](#)

All manuals and user guides at all-guides.com SET-UP SET-UP CHANNEL GUARD CH GUIDE PRESETTING With this feature, you can protect your children from viewing violent or other inappropriate TV programs. 5. Press CH buttons to select characters for station name (if desired) and press VOL + / - I.D.

### [Page 11: Picture Adjustment](#)

All manuals and user guides at all-guides.com SET-UP PICTURE ADJUSTMENT CH GUARD SETTING/CANCELLING P.STD (Picture Standard) BUTTON 1. Press CH / buttons or number buttons to select the channel you wish to guard or cancel the guard. 2. Press MENU button and move the cursor to "SET UP" option; press VOL + button then the "SET UP"...

[Page 12](#) All manuals and user guides at all-guides.com PICTURE ADJUSTMENT PICTURE ADJUSTMENT CUSTOM (MANUAL) ADJUSTMENT If you select this mode, you can directly adjust "BRIGHTNESS" without "MENU" option. You can sequentially select and adjust one of five picture properties. e.g. : Bright. Adjustment by "PICTURE" button. Contrast, Brightness, Color, Sharpness or Tint.

### [Page 13: Sound Adjustment](#)

All manuals and user guides at all-guides.com SOUND ADJUSTMENT SOUND ADJUSTMENT S.STD (Sound Standard) BUTTON SOUND MENU You can sequentially select and adjust one of four sound properties. (BASS, TREBLE, There is a choice of five audio settings. By pressing the S.STD button, the five settings can be BALANCE and MTS) viewed in the sequence illustrated.

### [Page 14: Mts](#)

All manuals and user guides at all-guides.com SOUND ADJUSTMENT SOUND ADJUSTMENT 1) USING MTS BUTTON : METHOD 1 2) USING SOUND MENU : METHOD 2 Your TV set incorporates an MTS (Multichannel Television Sound) decoder to receive stereo Press the MENU button. Move the broadcasts and any accompanying SAP (Second Audio Program), such as a bilingual MENU cursor to SOUND by pressing the CH...

### [Page 15: Clock/Timer](#)

All manuals and user guides at all-guides.com CLOCK/TIMER CLOCK/TIMER CLOCK SLEEP TIMER : METHOD 1 You can set the television's clock so that the current time will be displayed when you press the You can select a sleep time period from 15 through 90 minutes. The television automatically MENU button on the remote control.

[Page 16](#) All manuals and user guides at all-guides.com CLOCK/TIMER CLOCK/TIMER ON/OFF TIMER Move the cursor to "ON TIME" by using The ON/OFF timer lets you use alarm and automatic off functions. buttons and press the VOL TIME + / - buttons to set the time. (Refer to \* CLOCK : AM 11 : 30 page 28)

### [Page 17: Functions](#)

All manuals and user guides at all-guides.com FUNCTIONS FUNCTIONS LANGUAGE 1. Press the MENU button. Move the cursor to FUNCTION by pressing the CH buttons. Make a selection by pressing the VOL + button. You can select language among ENGLISH, SPANISH, PORTUGUESE and FRENCH by pressing VOL + button.

### [Page 18: Picture-In-Picture \(Avm-27D11 Only\)](#)

All manuals and user guides at all-guides.com PICTURE-IN-PICTURE (PIP) PICTURE-IN-PICTURE (PIP) AVM-27D11 only AVM-27D11 only PIP OPERATION : 1. PIP ON/OFF In this mode, you can enjoy viewing two programs at the same time. Press PIP ON/OFF button on the remote control and then the PIP window will be The "PIP"...

[Page 19](#) All manuals and user guides at all-guides.com PICTURE-IN-PICTURE (PIP) PICTURE-IN-PICTURE (PIP) AVM-27D11 only AVM-27D11 only 3. PIP SIZE Also, you can use the TV/VIDEO button in the VIDEO mode. Press SIZE button and then the size of the PIP window will be toggled as shown below. VIDEO1 VIDEO1 VIDEO1...

### [Page 20: Other Useful Functions](#)

All manuals and user guides at all-guides.com OTHER USEFUL FUNCTIONS RECEPTION DISTURBANCE CCD : The most common types of television interference are as follows: This TV set incorporates a CCD (Closed Caption Decoder) to enable viewing closed captions and TEXT broadcasts. IGNITION : Closed caption and TEXT each has 2 channels (CH1 &...

### [Page 21: Troubleshooting Guide](#)

This warranty becomes void if the product's serial numbers are altered or removed or if Confirm there are no obstructions between the remote and the TV. any repair to the product is made other than by SANYO Canada Inc. or by an Make sure the power cord is plugged in.

[Page 22](#) All manuals and user guides at all-guides.com LIMITATIONS (a). SANYO Canada Inc. reserves the right to change or improve the design of the model of the product warranted hereunder without incurring any obligation to make any modifications to or to install any

improvement in or on the product.

This manual is also suitable for:

[Avm-27d11](#)