



# Whirlpool AKR 555/1/IX Manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11

--

•

[Table of Contents](#)

- 

Troubleshooting

•

## Bookmarks

[Download this manual](#)

### Quick Links



## IMPORTANT SAFETY INSTRUCTIONS

### YOUR SAFETY AND THAT OF OTHERS IS PARAMOUNT

This manual and the appliance itself provide important safety warnings, to be read and observed at all times.

This is the attention symbol, pertaining to safety, which alerts users to potential risks to themselves and others.

All safety warnings are preceded by the attention symbol and the following terms:



All safety warnings give specific details of the potential danger/warning present and indicate how to reduce risk of injury, damage and electric shock resulting

from [REDACTED] the following instructions:

- [REDACTED]
- [REDACTED] by a qualified technician, in compliance with the manufacturer's instructions and local safety regulations.

Do not [REDACTED] unless specifically stated in the user manual.

- [REDACTED]
- [REDACTED] the power supply before carrying out any installation work.

- Regulations require that the appliance is earthed. (not possible for class II hoods)

- The power cable must be long enough for connecting the appliance, once fitted in its housing, to the power supply socket.
- Do not pull the power supply cable in order to unplug the appliance.
- The electrical components must not be accessible to the user after installation.
- Do not touch the appliance with any wet part of the body and do not operate it when barefoot.
-  The appliance is not intended for use by persons (including children) with any physical, sensory or mental impairment, or without experience and knowledge of the appliance, unless supervised or previously instructed in its use by those responsible for their safety.
- Do not repair or replace any part of the appliance unless specifically indicated in the manual. All other maintenance services must be carried out by a qualified person.
-  When repairing or replacing any part of the appliance, do not damage electric connections and/or pipes:
-  Air vents must not be blocked.
- The manufacturer rejects all responsibilities for any damage caused by improper use or wrong settings.
- Appropriate maintenance and cleaning ensure the good working order and the best performance of the appliance. Regularly clean all stubborn surface dirt to avoid grease build up. Remove and clean or change the filter regularly.
- Never flame cook food (flambé) under the appliance. Using free flames might cause fire.
- The discharge air must not be discharged in ducts that are being used to discharge combustion fumes from gas heaters or heaters using any other combustible materials. The appliance must have its own dedicated discharge outlet. All national requirements of art. 7.12.1 of CEI EN 60335-2-31 must be strictly complied with.
- If the hood is being used at the same time as other appliances using gas or other combustible materials, the negative pressure of the room must not exceed 4 Pa (4x 10<sup>-5</sup> bars). For this reason ensure that the room is well ventilated.
- Do not leave frying pans unattended when frying, as the frying oil may catch fire.
- Before touching the light bulbs, ensure that they are cold.
- Do not use or leave the hood without the light bulb correctly fitted, as this may cause electric shock.
- The hood is not a worktop, therefore do not place any objects on top of it or overload it.
- During all installation and maintenance operations wear appropriate working gloves.
- This appliance is not suitable for outdoor use.

### **Scrapping of household appliances**

This appliance is manufactured with recyclable or reusable materials. Dispose of it in accordance with local waste disposal regulations. Before scrapping, cut off the power supply cable.

For further information on the treatment, recovery and recycling of household electrical appliances, contact your competent local authority, the collection service for household waste or the store where you purchased the appliance.

### **KEEP THIS BOOKLET FOR FUTURE CONSULTATION.**

**indicates a hazardous situation which, if not avoided, will cause serious injury.**

**Indicates a hazardous situation which, if not avoided, could cause serious injury.**

GB8

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Whirlpool AKR 555/1/IX

[Ventilation Hood Whirlpool AKR3000/IX Instruction Manual](#)

T- box hood (14 pages)

[Ventilation Hood Whirlpool AKR 507 IX Instruction On Mounting And Use Manual](#)

(7 pages)

[Ventilation Hood Whirlpool AKR5200/IX Instruction Manual](#)

(13 pages)

[Ventilation Hood Whirlpool AKR 551 JA User And Maintenance Manual](#)

(18 pages)

[Ventilation Hood Whirlpool AKR 551 JA Installation Manual](#)

(24 pages)

[Ventilation Hood Whirlpool AKR 918 IX Instructions For Use](#)

Extractor or filtering hood (4 pages)

[Ventilation Hood Whirlpool AKR 526 IX Installation Manual](#)

55cm flat screen hood in stainless steel akr 526 ix (7 pages)

[Ventilation Hood Whirlpool AKR 520 Installation Sheet](#)

(4 pages)

[Ventilation Hood Whirlpool AKR 550 IM Manual](#)

(9 pages)

[Ventilation Hood Whirlpool AKR 511 IX Instruction On Mounting And Use Manual](#)

(24 pages)

[Ventilation Hood Whirlpool AKR 509 IX Instruction On Mounting And Use Manual](#)

(21 pages)

[Ventilation Hood Whirlpool AKR5001/IX Health & Safety And Installation Manual](#)

(16 pages)

[Ventilation Hood Whirlpool AKR5100/IX Instruction Manual](#)

(12 pages)

[Ventilation Hood Whirlpool AKR 5390/1 IX Instructions For Use Manual](#)

(69 pages)

[Ventilation Hood Whirlpool AKR5101/IX Health & Safety, Use & Care And Installation Manual](#)

(16 pages)

[Ventilation Hood Whirlpool AKR628 IXS Instruction For Use & Installation Instructions](#)

Slim hood (10 pages)

## Summary of Contents for Whirlpool AKR 555/1/IX

**Page 1** IMPORTANT SAFETY INSTRUCTIONS YOUR SAFETY AND THAT OF OTHERS IS PARAMOUNT This manual and the appliance itself provide important safety warnings, to be read and observed at all times. This is the attention symbol, pertaining to safety, which alerts users

to potential risks to themselves and others. All safety warnings are preceded by the attention symbol and the following terms: DANGER: indicates a hazardous situation which, if not avoided, will cause serious injury.

## [Page 2: Preparing For Installation](#)

INSTALLATION After unpacking the appliance, check for any transport damage. In the event of problems, contact the dealer or your nearest After-sales Service. To prevent any damage, only remove the appliance from its polystyrene foam packaging at the time of installation.  
PREPARING FOR INSTALLATION WARNING: this is a heavy product;...

## [Page 3: Troubleshooting Guide](#)

TROUBLESHOOTING GUIDE The appliance does not work: • Check for the presence of mains electrical power and if the appliance is connected to the electrical supply. • Turn off the appliance and restart it to see if the fault persists. The hood's suction level is not sufficient: •...

## [Page 4: Maintenance](#)

MAINTENANCE - use safety gloves. CAUTION: - disconnect the appliance from the mains power supply. GREASE FILTERS Metal grease filters have an unlimited life and should be washed once a month either by hand or in a dishwasher at a low temperature and with a short cycle. Washing in a dishwasher can cause grease filters to turn white, but this in no way affects efficiency.

## [Page 5: Material Supplied](#)

MATERIAL SUPPLIED Remove all the components from the packets. Check that all the components are included. • Hood assembled with motor, lamps and grease filters installed. • Flues (2 parts) • Instructions for assembly and use • 1 assembly template •...

[Page 6](#) INSTALLATION - ASSEMBLY INSTRUCTIONS The instructions below, to be carried out in the order in which they are numbered, refer to the figures (with the same step numbers) given on the last pages of this manual. N.B.: The size and/or shape of the hood may differ from that illustrated, nonetheless the installation procedure remains the same. 1.

[Page 7](#) DESCRIPTION AND USE OF HOOD 1. Control panel. 2. Grease filters. 3. Halogen lamps. 4. Telescopic flue. Control panel Light : move the switch to the right or press the button to switch on. Extraction speed : move the switch to the right or press the next button to increase extraction speed.