



Asus ZenPower PD 10000 Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16

• PAGE

1

-

[Table of Contents](#)


•

Bookmarks

--

[Download this manual](#)


Quick Links



ET16537_ABTU020_Power_Bank_UM.indb 1
ET16537_ABTU020_Power_Bank_UM.indb 1



ZenPower PD 10000



ABTU020

June 2020

2020/8/6 11:13:25

2020/8/6 11:13:25



[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus ZenPower PD 10000

[Accessories Asus ZenPower PD 10000 Manual](#)

(58 pages)

[Accessories Asus ESC4000 G2 GPU Quick Start Manual](#)

Cache vault accessory kit (16 pages)

[Asus Active Stylus SA200H Manual](#)

(article)

[Asus Pen 2.0, SA203H - Active Stylus Manual](#)

(article)

[Accessories Asus ROG RYUO III ARGB Series Quick Start Manual](#)

(26 pages)

[Accessories Asus ABTU016 User Manual](#)

(75 pages)

[Accessories Asus Xtion Quick Start Manual](#)

(124 pages)

[Accessories asus Xtion User Manual](#)

(300 pages)

[Accessories Asus ABTU001 User Manual](#)

Quick charge power bank (52 pages)

[Accessories Asus Blitz Formula Installation](#)

Fusion block system (2 pages)

[Accessories Asus ABTU012 User Manual](#)

Credit card size 10050 mah (45 pages)

[Accessories Asus Xtion 2 Quick Start Manual](#)

(24 pages)

[Accessories Asus WS101 User Manual](#)

(116 pages)

[Accessories Asus ABTU012 User Manual](#)

Credit card size 10050mah (66 pages)

Summary of Contents for Asus ZenPower PD 10000

[Page 1](#) ET16537 First Edition June 2020 ZenPower PD 10000 繁體中文 ABTU020
ET16537_ABTU020_Power_Bank_UM.indb 1 ET16537_ABTU020_Power_Bank_UM.indb 1 2020/8/6
11:13:25 2020/8/6 11:13:25...

[Page 2](#) Table of Contents / 目錄 English3 繁體中文10
ET16537_ABTU020_Power_Bank_UM.indb 2 ET16537_ABTU020_Power_Bank_UM.indb 2 2020/8/6
11:13:25 2020/8/6 11:13:25...

[Page 3: Led Indications](#)

Getting to know your Power Bank Power button LED indicators USB Type-A USB Type-C®
(output) port (input/output) port LED indications Charging the Power Bank LED status Charge
Solid blue LED 1 LED 2 LED 3 LED 4 status Solid white 0% - 5% Blinking blue 5% - 25%...

[Page 4](#) Charging devices using the Power Bank Discharge LED 1 LED 2 LED3 LED 4 status
100% 76% - 99% 56% - 75% 26% - 55% 6%-25% 0% - 5% Error detected* Fast charging the

Power Bank Charge LED 1 LED 2 LED 3 LED 4 status 0% - 5% 5% - 25%...

[Page 5](#) Fast charging devices using the Power Bank Discharge LED 1 LED 2 LED3 LED 4 status 100% 76% - 99% 56% - 75% 26% - 55% 6%-25% 0% - 5% Error detected* To stop the Power Bank from blinking when an error has been detected, re-insert the cable into the Power Bank.

[Page 6: Specifications](#)

Specifications Rechargeable Li-Ion cell Cell type 35.2Wh Cell capacity Rated 5V/6200mAh; 9V/3300mAh; 12V/2400mAh capacity Charging 5°C - 40°C temperature 78.8mm x 55.8mm x 26mm Size 186 ± 5g Weight < 5.5 hrs with DC 5V via the bundled USB cable Charging time <...

[Page 7](#) NOTES: • When connected to your device, the Power Bank starts charging your device automatically. If not, press the power button on the Power Bank to charge your device. • Use the Power Bank in environments with temperatures ° ° between 25 C and 40 C to fast charge the mobile devices...

[Page 8: Safety Notices](#)

Rechargeable Battery Recycling Service in North America For US and Canada customers, you can call 1-800-822-8837 (toll-free) for recycling information of your ASUS products' rechargeable batteries. ET16537_AB TU020_Power_Bank_UM.indb 8 ET16537_AB TU020_Power_Bank_UM.indb 8 2020/8/6 11:13:28...

[Page 9: Fcc Compliance Information](#)

CAUTION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment. FCC COMPLIANCE INFORMATION Per FCC Part 2 Section 2.1077 Asus Computer International Responsible Party: Address: 48720 Kato Rd, Fremont CA 94538.

[Page 10](#) 0000 0000 LED 000 USB Type-A00 00000 USB Type-C000 / 000000 LED 00000 LED 00 000000 0000 0000 LED 1 LED 2 LED 3 LED 4 0000 0000 0% - 5% 0000 5% - 25% 0000 26% - 50% 0 0 0 0...

[Page 11](#) 000000000000 0000 LED 1 LED 2 LED3 LED 4 0000 100% 76% - 99% 56% - 75% 26% - 55% 6%-25% 0% - 5% 00 ** 0000000000 0000 LED 1 LED 2 LED 3 LED 4 0000 0000 0% - 5% 000 0...

[Page 12](#) 000000000000 0000 LED 1 LED 2 LED3 LED 4 0000 100% 76% - 99% 56% - 75% 26% - 55% 6%-25% 0% - 5% 00 ** 0000 USB 00000000 000 • 000000000000LED 00000 5 000000 00 • 000 USB 0000000000000000 000000000 5 00000000 ET16537_AB TU020_Power_Bank_UM.indb 12 ET16537_AB TU020_Power_Bank_UM.indb 12 2020/8/6 11:13:31...

[Page 13](#) 0000 00000 0000 35.2Wh 00000 5V/6200mAh9V/3300mAh 0000 12V/2400mAh 5°C - 40°C 0000 78.8mm x 55.8mm x 26mm 00 186 ± 5g 00 00 5V 2A 0 < 5.5 00 000000 USB 00 000 0 00 9V 2A 0 < 3.5 00 000000...

[Page 14](#) 000 • 0000000000000000000000 0000000000000000000000 00000000000 • 00000000 25°C - 40°C 00000000 00 PD 00 3.0 000000000000 • 000000000000000000 PD 00 3.0 0000000000 00000 25°C - 40°C 00000000 • 000000000000000000 • 0000000000000000000000 000 5V 000000000000 0000 000 00000000 000000000000 ET16537_AB TU020_Power_Bank_UM.indb 14 ET16537_AB TU020_Power_Bank_UM.indb 14 2020/8/6 11:13:32 2020/8/6 11:13:32...

[Page 15](#) 00000 USB 0000000000000000 000 • 0000000000000000000000 000000000000 • 0000000 0000000000000000 0000000000 • 000000000000000000000000 0000000000000000000000 • 0000000000000000 00000000 0000000000000000000000 40°C104 °F000000 000000000000000000000000 0000000000 000000 0000: 0000000000 0000000 0 0000000000 15 0 1 0 0000000000000000 0 https://www.asus.com/tw ET16537_AB TU020_Power_Bank_UM.indb 15 ET16537_AB TU020_Power_Bank_UM.indb 15 2020/8/6 11:13:32 2020/8/6 11:13:32...

[Page 16](#) 00000000000 0 0 0 000 00 000 00 (Pb) (Hg) (Cd) 00 00 (PBB) (PBDE) 00 0 0 0 0 0 0 0 000 0 0 0 0 0 0 000 00 00...

This manual is also suitable for:

Abtu020