



Toshiba B-FP800-AC-QM-S Owner's Manual

1	
Table Of Contents	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	

--

-

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks

--

[Download this manual](#)

Quick Links



TOSHIBA

AC Adapter

Owner's Manual

B-FP800-AC-QM-S

(FSP065-RBBN3)

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba B-FP800-AC-QM-S

[Adapter TOSHIBA B-EP800-DC48-QM-R Owner's Manual](#)

Toshiba dc adapter (3 pages)

[Adapter Toshiba B-EP800-AC-QM-R Owner's Manual](#)

Ac adapter (3 pages)

[Adapter Toshiba B-EP802-DC12-QM-R Owner's Manual](#)

(8 pages)

[Adapter Toshiba B-FP800-DCJA-QM-R Owner's Manual](#)

Dc jack plug adapter (10 pages)

[Adapter Toshiba VF-S15 Instruction Manual](#)

Option adapter (3 pages)

[Adapter Toshiba VF-S15 Instruction Manual](#)

Option adapter (2 pages)

[Adapter Toshiba TCB-DK01SS-E Owner's Manual](#)

Dyna-kit communication adapter (12 pages)

[Adapter Toshiba Canvio Cast User Manual](#)

(50 pages)

[Adapter Toshiba VF-S15 Instruction Manual](#)

Option adapter (2 pages)

[Adapter Toshiba 4400 Series Installation Instructions Manual](#)

Ups seismic adapter kit (12 pages)

[Adapter Toshiba WUS-G06G-JT User Manual](#)

802.11b/g wireless usb adapter (48 pages)

[Adapter Toshiba TCB-PCNT20E Installation Manual](#)

For air conditioner (7 pages)

[Adapter Toshiba Canvio Wireless Adapter User Manual](#)

(84 pages)

[Adapter Toshiba Sitecom CN-512 Full Manual](#)

Usb bluetooth adapter (78 pages)

[Adapter Toshiba TCB-SS1UU-E Owner's Manual](#)

Link (22 pages)

[Adapter Toshiba WLM-10UB1 Owner's Manual](#)

Usb wifi adapter for toshiba blu-ray disc/dvd player (2 pages)

Summary of Contents for Toshiba B-FP800-AC-QM-S

[Page 1](#) AC Adapter Owner's Manual B-FP800-AC-QM-S (FSP065-RBBN3)

[Page 2: Table Of Contents](#)

CONTENTS 1. Precautions.....	3	2. Accessories	6	3. Before Using.....	7
Before using this product	7	4. Connecting the AC adapter to the printer	7	5. Troubleshooting	8
Specifications.....	9	6. When Purchasing the Power Cable	10		
CONTENTS 1...					

[Page 3](#) 2 CONTENTS...

[Page 4: Precautions](#)

CE marking is the responsibility of Toshiba TEC Germany Imaging Systems GmbH, Carl-Schurz-Str. 7, 41460 Neuss, Germany. For a copy of the related CE Declaration of Conformity, please contact your dealer or Toshiba Tec Corporation. The full text of the EU declaration of conformity is available at the following internet address: <https://www.toshibatec.eu/support/environment/...>

[Page 5](#) Before using this product, please read this manual thoroughly and retain it for future reference. **WARNING! RISK OF ELECTRIC SHOCK DO NOT OPEN** ⚠ TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THE UNIT TO RAIN OR MOISTURE. ⚠ TO PREVENT ELECTRIC SHOCKS, DO NOT REMOVE COVER (OR BACK). This symbol is intended to alert the user to the presence of uninsulated "Dangerous voltage"...

[Page 6](#) Never use thinner or any other volatile solvent on the plastic covers. **CAUTION!** ⚠ This manual may not be copied in whole or in part without the prior written permission of Toshiba Tec Corporation. ⚠ The contents of this manual may be changed without notification.

[Page 7: Accessories](#)

2. Accessories [1] [2] Name Name Power cable Owner's Manual 6 2. Accessories...

[Page 8: Before Using](#)

Please follow the instructions below to use the B-FP800-AC-QM-S correctly. ⚠ The B-FP800-AC-QM-S is an AC adapter designed for charging the battery pack loaded in the B-FP2D series portable printers, not for directly supplying the power to the B-FP2D series portable printers.

[Page 9: Troubleshooting](#)

If you have any problems while using this product, please check the following point first. If a problem cannot be solved by taking actions described below, unplug the AC adapter and contact the dealer or an authorized Toshiba Tec service representative for assistance. Symptom Cause and resolution ⚠...

[Page 10: Specifications](#)

B-FP800-AC-QM-S (Model: FSP065-RBBN3) Input voltage 100 to 240V AC, 50/60 Hz DC19V, 3.42A Output voltage Application TOSHIBA Portable Printer B-FP2D Series Operating temperature 0°C to 40°C (32°F to 104°F) Operating humidity 20 to 80% (No condensation) Storage temperature -20°C to 60°C (-4°F to 140°F)

[Page 11: When Purchasing The Power Cable](#)

6. When Purchasing the Power Cable Certification Certification Country Agency Country Agency Country Agency mark mark Germany Sweden SEMKKO Australia Switzerla Austria Ireland NSAI Belgium CEBEC Italy ASTA Canada Japan METI Netherla Denmark DEMKO KEMA U.S.A. Finland Norway NEMKO Europe France...

[Page 12](#) AC Adapter Owner's Manual B-FP800-AC-QM-S 1-11-1, OSAKI, SHINAGAWA-KU, TOKYO, 141-8562, JAPAN PRINTED IN INDONESIA © 2019 Toshiba Tec Corporation All rights reserved Ver00 F E00133136...

This manual is also suitable for:

[Fsp065-rbbn3](#)

