

# Sanyo DS13204, DS19204, DS25204 Owner's Manual

Sanyo colortv owner's manual ds13204, ds19204, ds25204



1  
2  
3  
4  
5  
6

--


•

[Table of Contents](#)

•

## Bookmarks

Available languages



## Table of Contents

[1 On-Screen Menu Operation](#)

[2 V-Guide Operation](#)

[3 Care and Cleaning](#)

[4 Seguridad para Infantes](#)


[5 Especificaciones](#)

[6 Garantie Limitée D'un an](#)

[7 One-Year Limited Warranty](#)

[Download this manual](#)

See also: [Service Manual](#)



[Enlarged version](#)



## **BASIC SETUP AND CONNECTIONS**

1. Install batteries in remote control (2 AAA, not included).
2. Connect signal. (See illustration below.)
3. Plug in AC power cord.
4. Press the POWER key to turn on TV.
5. Follow on-screen instructions.

## **Model Nos. :**

### Color TV Owner's Manual

#### **POSITIONING THE TV**

Do not position the TV in a confined area. Allow space for normal air circulation around electronic parts.

#### **CHILD SAFETY**

Sanyo is committed to making home entertainment safe and enjoyable. Always use an appropriate table or stand when positioning your TV. Use appropriate brackets, braces, or straps to anchor your furniture in place. But NEVER screw anything directly to the television.

Do not place televisions on dressers, shelves, desks, carts, etc. where curious or excited children could pull, push, or otherwise cause the unit to fall and cause personal injury.

Never place toys or other items on top of the TV that could pique children's curiosity causing them to climb about the furniture.

Always use stands that are designed to support the size

and combined weight of your television and other electronic devices.

**IMPORTANT NOTE:**

Spent or discharged batteries must be recycled or disposed of properly in compliance with all applicable laws. For detailed information, contact your local County Solid Waste Authority.

UHF/VHF/CATV  
75Ω

# AS

\*

® Partner, Sanyo Manufacturing Corporation has determined

"As an E

S

ENERGY

TAR

® guidelines for energy efficiency."

that this product meets the E

S

ENERGY

TAR

## DS13204

## DS19204

## DS25204

[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Sanyo DS13204, DS19204, DS25204

### [TV Sanyo DS13204 Service Manual](#)

Remote control color television (30 pages)

### [TV Sanyo DS24205 Service Supplement Manual](#)

Remote control color television (30 pages)

### [TV Sanyo DS19204 Service Manual](#)

Remote control color television (30 pages)

### [CRT TV Sanyo DP19648 Owner's Manual](#)

Sanyo dp19648: user guide (48 pages)

### [CRT TV Sanyo DS25320 Owner's Manual](#)

Sanyo ds25320: owners manual (52 pages)

### [CRT TV Sanyo DS13390, DS19390, DS25390 Owner's Manual](#)

Sanyo owner's manual color tv ds13390, ds19390, ds25390 (44 pages)

### [CRT TV Sanyo DS24425 Owner's Manual](#)

Sanyo ds24425: owners manual (52 pages)

### [CRT TV Sanyo DS27425 Owner's Manual](#)

Sanyo ds27425: owners manual (55 pages)

### [CRT TV Sanyo HT27546 Owner's Manual](#)

Sanyo ht27546: instruction manual (25 pages)

### [CRT TV Sanyo DS32920 Owner's Manual](#)

Sanyo ds32920: owners manual (68 pages)

### [CRT TV Sanyo DS27910 Owner's Manual](#)

Sanyo ds27910: owners manual (68 pages)

### [CRT TV Sanyo DS31810 Owner's Manual](#)

Sanyo ds31810: owners manual (72 pages)

### [CRT TV Sanyo DS35520 Owner's Manual](#)

Sanyo ds35520: owners manual (68 pages)

### [CRT TV Sanyo DS2722 DS27225 Owner's Manual](#)

Sanyo color tv owner's manual (52 pages)

### [CRT TV Sanyo HT30746 Owner's Manual](#)

Sanyo ht30746: instruction manual (24 pages)

### [CRT TV Sanyo AVM-2550S, AVM-2759S Owner's Manual](#)

Sanyo color tv owner's manual avm-2550s, avm-2759s (48 pages)

## Summary of Contents for Sanyo DS13204, DS19204, DS25204

**Page 1** Do not position the TV in a confined area. Allow space for normal air circulation around electronic parts. CHILD SAFETY Sanyo is committed to making home entertainment safe and enjoyable. Always use an appropriate table or stand when positioning your TV. Use appropriate brackets, braces, or straps to anchor your furniture in place.

### **Page 2: On-Screen Menu Operation**

ON-SCREEN MENU OPERATION 1. Press MENU. 2. Use the L /M keys to highlight a feature. 3. Use the - /+ keys to choose an option. 4. Press MENU to exit. Items with submenus requires additional steps. Automatic Picture Adjustment 1.

### [Page 3: Seguridad Para Infantes](#)

ESPAÑOL Bienvenido al mundo SANYO Gracias por comprar un Televisor a Color Sanyo. Usted hizo una excelente selección por Funcionamiento, Estilo, Confiabilidad, y Precio. El TV esta diseñado con instrucciones de fácil ajuste y operación en pantalla. "Lea este manual antes ensamblar (o usar) este producto." ...

[Page 4](#) VI DE O IN VID EO IN AUDIO IN A UDI O IN P O W E R P O W E R POWER INPUT RESET MENU RECALL MUTE DISPLAY...

### [Page 5: Garantie Limitée D'un An](#)

Bienvenue dans l'univers de Sanyo Nous vous remercions d'avoir acheté un télécouleur Sanyo. Vous avez fait un choix excellent du point de vue du fonctionnement du style, de la fiabilité et du rapport qualité/prix. Ce télécouleur est fourni avec des instructions d'installation et de fonctionnement simples à...

### [Page 6: One-Year Limited Warranty](#)

WARRANTY APPLIES ONLY TO THE ORIGINAL PURCHASER, AND DOES NOT APPLY TO PRODUCTS USED FOR INDUSTRIAL OR COMMERCIAL PURPOSES. FOR ONE YEAR from the date of purchase, Sanyo Manufacturing Corporation will replace any defective TV. To insure proper warranty exchange, keep the original sales receipt for evidence of purchase.