

Table of Contents






Table of Contents

- 1 Important Safety Information
- 2 Safety Instructions
- 3 Installation
- 4 Cautions for Operation
- 5 Troubleshooting
- 6 Periodic Maintenance

Download this manual



□□ | Model

GR-B**3-165411BA**GR-A28MU / MS
GR-A25MU / MS
GR-B22MP

GR-A28HSZ
GR-A25HSA
GR-B22HU
GR-B31SU
GR-A25SU

Thank you very much for purchasing this TOSHIBA refrigerator.

Read this Owner's Manual and become completely familiar with the refrigerator before use in order to use this product safely and correctly.

Keep this Owner's Manual in a handy place for future reference.

Make sure that you received your warranty.

This manual is available in other format such as soft copy, please contact TOSHIBA Service Center when you need it.

REFRIGERATOR FREEZER

Owner's Manual For Home Use Only

Table of Contents





Related Manuals for Toshiba GR-B31MU

Refrigerator Toshiba GR-B31MU Owner's Manual

(12 pages)

Refrigerator Toshiba GR-Y12TPT Operating Instructions Manual

Toshiba gr-y12tpt refrigerator-freezer operating instructions (9 pages)

Refrigerator Toshiba GR-TG43MDZ Owner's Manual

(8 pages)

Refrigerator Toshiba GR-W77MD Owner's Manual

(8 pages)

Refrigerator Toshiba GR-WG66TDZ Owner's Manual

(13 pages)

Refrigerator Toshiba GR-R/RG68MDA Instruction Manual

(13 pages)

Refrigerator Toshiba GR-R25MPT Instruction Manual

For home use (8 pages)

Refrigerator Toshiba GR-EF46Z Owner's Manual

(17 pages)

Refrigerator Toshiba GR-RB440WE-DMM(02) Owner's Manual

(25 pages)

Refrigerator Toshiba GR-RF532WE-PGI(22) Owner's Manual

(23 pages)

Refrigerator Toshiba GR-AG48MDZ Owner's Manual

(12 pages)

Refrigerator Toshiba GR-TG46VPDZ Owner's Manual

(8 pages)

Refrigerator Toshiba GR-AG461TDZ Owner's Manual

(13 pages)

Refrigerator Toshiba GR-AG55TDZ Owner's Manual

(13 pages)

Refrigerator Toshiba GR-RB405WE-PM Series Owner's Manual

(34 pages)

Refrigerator Toshiba GR-RB449WE-PMJ(06) Owner's Manual

(167 pages)

Summary of Contents for Toshiba GR-B31MU

<u>Page 1</u> Keep this Owner's Manual in a handy place for future reference. • Make sure that you received your warranty. • This manual is available in other format such as soft copy, please contact TOSHIBA Service Center when you need it.

Page 2: Important Safety Information

When disposing the refrigerator Warning flammable refrigerant When the LED light is blown [] LED [][][] TOSHIBA Warning If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid Warning a hazard.

Page 3: Safety Instructions

SAFETY INSTRUCTIONS All instructions described should be carefully read • and followed. • These instructions are precautions to prevent the risks of serious injury or death of the user, and any damages to property. MARKINGS WARNING indicates high possibility of WARNING serious injury (*1) or death of the user.

<u>Page 4</u> WARNING Disconnect the power plug while cleaning. Disconnect plug Clean and remove dust on power plug periodically. Clean the plug Do not use if the supply cord is damaged or frayed, or if the power plug has loose connection. Do not use Do not block the openings on the circumstances of the refrigerator.

<u>Page 5</u> WARNING Do not hang or stand on the door. Prohibited! Do not store medicines, chemicals or chemical reagents. Do not store Do not place any heavy objects or liquid containers on the refrigerator. Prohibited! Do not eat any food which has changed color or gives out strange odor.

<u>Page 6</u> CAUTION Use the handle when closing the refrigerator door. Use the handle Secure the doors closed Incorrect Correct (No Good) (Good) CAUTION: Secure the door closed Secure the doors closed Do not leave the door opened for a long period of time and/or do not frequently open and close the doors in short intervals.

Page 7: Installation

INSTALLATION Installation [] Install your refrigerator on a strong and level floor. Turn the adjustable leg and stabilize the refrigerator horizontally. - Adjustable leg right side can be adjust up and down. - Turn adjustable leg clockwise to raise each side of the refrigerator, or turn counter clockwise lower it.

Page 8: Cautions For Operation

If the plug is quickly reconnected, the compressor may not run properly and produce a rattling noise. REFRIGERATOR DETAILS AND PARTS GR-A28MS, GR-A25MS As figure for GR-A28MS, GR-A25MS Twist GR-B22HU As figure for GR-B22HU GR-B31MU As figure for GR-B31MU GR-A28MU GR-A25MU GR-A25MS GR-A25MS GR-A25MS GR-A25MS GR-A25MS GR-B31MU GR-B22MP...

<u>Page 9</u> Fill the Ice Tray with water up to the water level line. If the To remove ice, twist the Ice Tray as shown in the figure. water exceeds the water level line, it will freeze over and becomes hard to remove. GR-B31MU GR-A28MU GR-A25MU GR-A28HSZ...

Page 10: Troubleshooting

TROUBLESHOOTING The refrigerator does not get cold at all. The refrigerator does not get cold enough. Is the door being opened and closed too frequently in short time? 30 cm 12 0 cm (inches) at top, 10 cm 4 5 cm 2 rear side Food in the refrigerator compartment freezes.

Page 11: Periodic Maintenance

HOW TO REMOVE ACCESSORY PARTS Meat Pan Pockets Refrigerator Shelf Freezer Shelf and Crisper Shelf until limit wide ,Lightly lift up the shelf then pull it out. Pull it out. Vegetable Crisper until limit wide PERIODIC MAINTENANCE Outside Surfaces Door Packing Interior Plastic Units...

Page 12 EMQD-B...

This manual is also suitable for:

Gr-a28muGr-a28msGr-a25muGr-a25msGr-b22mpGr-a28hsz ... Show all