



# Toshiba 1000 SEREIS Brochure & Specs

1000 series



1  
2

--

•

Bookmarks

--

[Download this manual](#)

### Quick Links



UNINTERRUPTIBLE POWER SYSTEMS

**TOSHIBA**  
1000 SERIES

Extend

Extend





Intelligent Charge W

**TOSHIBA**

Wide Input Frequency Win



[Next Page](#)

1  
[2](#)

## Related Manuals for Toshiba 1000 SEREIS

### [Laptop Toshiba 1000-S157 User Manual](#)

1000-s157 user's guide (246 pages)

### [Controller Toshiba V Series User Manual](#)

Integrated controller, loop controller (158 pages)

### [Laptop TOSHIBA Satellite 1000 Series User Manual](#)

Toshiba satellite portable personal computer (126 pages)

### [Laptop Toshiba Satellite 1000 User Manual](#)

Toshiba satellite 1000 notebook (126 pages)

### [UPS Toshiba 1000 SERIES User Manual](#)

(64 pages)

### [UPS Toshiba 1000 Series User Manual](#)

Reliability in motion single phase 1000/1200 va (60 pages)

### [UPS Toshiba RELIABILITY IN MOTION 1000 Series User Manual](#)

Single phase 1000 va to 3000 va uos (54 pages)

### [UPS Toshiba UT1A1A010C6 User Manual](#)

User guide (51 pages)

### [UPS Toshiba 1000 Series Installation Instructions](#)

Toshiba power supply user manual (4 pages)

### [UPS Toshiba 1000 Series Specification](#)

Ups rack-mount 2u rail kit (2 pages)

### [UPS Toshiba 1500 Series Operation Manual](#)

(32 pages)

### [UPS Toshiba 1600EP Series Operation Manual](#)

Battery cabinet system single phase - 3.6/6.0 kva (22 pages)

### [UPS Toshiba 1600 Series Instruction Manual](#)

Single phase - 2.4/3.6/6/8 kva plus (49 pages)

### [UPS Toshiba 1600XPi Series Installation And Operation Manual](#)

Single phase - 3.6/5.2/6/8/10/14/18/22 kva (140 pages)

### [UPS Toshiba 1700 Series User Manual](#)

Uninterruptible power system single phase 1.5/2.0/2.4 kva (43 pages)

### [UPS Toshiba 1400SE Series Operation Manual](#)

Single phase - .6/.8/1.0/1.2/1.5/2.0/2.4 kva, single phase - .6/.8/1.0/1.5 kva plus (41 pages)

## Summary of Contents for Toshiba 1000 SEREIS

[Page 1](#) UNINTERRUPTIBLE POWER SYSTEMS 1000 Series 1000 VA to 3000 VA UPS Extende □ True On-Line Double Conversion UPS Extende □ Auto-Restart and Cold Start Features □ Programmable Load Shed Receptacles □ Intelligent Charger with Rapid Charge in Only 4 Hours to 90% □...

[Page 2](#) IEC 320 (4/4) 0 to 40 C (32 to 104 11500 ft (3500 m) Above Sea Level Three Years on Electronics Two Years Full Replacement on Battery (See Toshiba warranty policy for full details.) MOTORS CONTROLS Available Through: UT1A1A020C6 UT1A1A030C6...

This manual is also suitable for:

[Ut1a1a010c6](#)[Ut1a1a015c6](#)[Ut1a1a020c6](#)[Ut1a1a030c6](#)[Ut1e1e010c6](#)[Ut1e1e015c6](#) ... [Show all](#)