



# Instructions Importantes Concernant La Sécurité - Toshiba UNINTERRUPTIBLE POWER SYSTEM 1600XP Installation And Operation Manual

Single phase - 3.6/6/8/10/14/18/22 kva



1

2

3

4

5

6

Table Of Contents

7

8

9

10

11

12

13

14


15

16

17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90



•

[Table of Contents](#)

•

## Bookmarks







CAUTION

CAUTION **TOSHIBA**  
Leading Innovation >>>

CAUTION

to be performed by Qualified Personnel Only:

1.



Verify that the UpS is off and that the power is disconnected from the power source.

2.

remove watches, rings or other metal objects.

3.



Use tools with insulated handles to prevent inadvertent shorts.

4.



wear rubber safety gloves and boots.

5.

do not place tools or any metal parts on top of batteries.

6.

determine if the battery is inadvertently grounded. if inadvertently grounded, remove source of ground.



# INSTRUCTIONS IMPORTANTES CONCERNANT LA SÉCURITÉ



## CONSERVER CES INSTRUCTIONS

Cette notice contient des instructions importantes concernant la sécurité.

### ATTENTION




### ATTENTION



4

misuse of this equipment may result in human injury and equipment damage. in no event will toshiba Corporation be responsible or liable for either indirect or consequential damage or injury that may result from the misuse of this equipment.



do not open or mutilate the batteries. released electrolyte is harmful to the eyes and skin and could also be toxic.

## WARNING

Contact with any part of a grounded battery can result in electrical shock.


the likelihood of shock will be reduced if such grounds are removed prior to installation or maintenance.

Une battery peut présenter un risque de choc électrique, de brûlure par transfert d' énergie.

L' élimination des batteries est règlementée.

Consulter les codes locaux à cet effet.

do not dispose of the battery module in a fire. The batteries inside may explode.



1600Xp Series installation and operation manual

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
9  
10  
11  
12  
13  
14  
15  
16

## Related Manuals for Toshiba UNINTERRUPTIBLE POWER SYSTEM 1600XP

### [UPS Toshiba 1600XP Specifications](#)

Single phase uninterruptible power systems (9 pages)

### [UPS Toshiba 1600XP SERIES Installation And Operation Manual](#)

(140 pages)

### [UPS Toshiba 1600XP SERIES Installation And Operation Manual](#)

1600xp series single phase - 3.6/6/8/10/14/18/22 kva (100 pages)

### [UPS Toshiba 1600XPi Series Installation And Operation Manual](#)

8-22kva battery cabinet (23 pages)

### [UPS Toshiba 1600XP SERIES Installation And Operation Manual](#)

8-22kva battery cabinet (22 pages)

### [UPS Toshiba 1600XP Series Quick Installation Manual](#)

(4 pages)

### [UPS Toshiba 1600EP SERIES Instruction Manual](#)

(58 pages)

### [UPS Toshiba 1600EP Series Operation Manual](#)

Battery cabinet system single phase- 8/10/14/18 kva (16 pages)

### [UPS Toshiba 1600EP Series Operation Manual](#)

Battery cabinet system single phase - 3.6/6.0 kva (22 pages)

### [UPS Toshiba 1600 Series Product Specifications](#)

3.6kva 208/240v in - 208/240/120v out tower hardwire solution (3 pages)

### [UPS Toshiba 1600 Series Product Specifications](#)

Uninterruptible power systems, 3.6kva 240v in - 240v out tower maintenance bypass solution (2 pages)

### [UPS Toshiba 1600EP Series Quick Installation Manual](#)

(4 pages)

### [UPS Toshiba 1600 Series Instruction Manual](#)

Single phase - 2.4/3.6/6/8 kva plus (49 pages)

### [UPS Toshiba 1600XPi Series Installation And Operation Manual](#)

Single phase - 3.6/5.2/6/8/10/14/18/22 kva (140 pages)

### [UPS Toshiba 1500 Plus Series Operation Manual](#)

6/.8/1.0 kva 220v uninterruptible power system (31 pages)

### [UPS Toshiba UT1A1A010C6 User Manual](#)

User guide (51 pages)

## Related Content for Toshiba UNINTERRUPTIBLE POWER SYSTEM 1600XP

### [4200FA Instructions Importantes Concernant](#)

Toshiba 4200FA

### [4200 FA CT Instructions Importantes Concernant](#)

Toshiba 4200 FA CT

[4200FA XT Instructions Importantes Concernant](#)

Toshiba 4200FA XT

[1600XP SERIES Instructions Importantes Concernant](#)

Toshiba 1600XP SERIES

[1000 SERIES Instructions Importantes Concernant](#)

Toshiba 1000 SERIES

[4200FA Instructions Importantes Concernant](#)

Toshiba 4200FA

[RELIABILITY IN MOTION 1000 Series Instructions Importantes Concernant](#)

Toshiba RELIABILITY IN MOTION 1000 Series

[UT1A1A010C6 Instructions Importantes Concernant](#)

Toshiba UT1A1A010C6

This manual is also suitable for:

[1600xp serie1600xp series](#)