



Toshiba RAS-24PKVSG-E Owner's Manual

1
2
3
4
5
6
7

--

•

Bookmarks

[Download this manual](#)

Quick Links



OWNER'S MANUAL

AIR CONDITIONER (SPLIT TYPE)
For general public use

TOSHIBA

Indoor unit

RAS-18, 22, 24PKVSG-E

Outdoor unit

RAS-18, 22, 24PAVSG-E

R32

1120650201 **TOSHIBA**

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba RAS-24PKVSG-E

[Air Conditioner Toshiba RAS-18PAVSG-E Owner's Manual](#)

(168 pages)

[Air Conditioner Toshiba RAS-18PKVSG-E Service Manual](#)

(137 pages)

[Air Conditioner Toshiba RAS-24PAVSG-E Installation Manual](#)

(18 pages)

[Air Conditioner Toshiba RAS-22 Owner's Manual](#)

(7 pages)

[Air Conditioner Toshiba RAS-B22PKVSG-TR Service Manual](#)

(134 pages)

[Air Conditioner Toshiba RAS-B22PKVSG-E Installation Manual](#)

(22 pages)

[Air Conditioner Toshiba RAS-18PACVG -T Owner's Manual](#)

Split type (8 pages)

[Air Conditioner Toshiba RAS-24UKX Service Manual](#)

Split wall type air-conditioner (62 pages)

[Air Conditioner Toshiba RAS-24NKHD-E5 Service Manual](#)

Split wall type (74 pages)

[Air Conditioner Toshiba Indoor unit RAS-18, 24SK Series Installation Manual](#)

Air conditioner (split type) (10 pages)

[Air Conditioner Toshiba RAS-B16N3KV2-E1 Owner's Manual](#)

(102 pages)

[Air Conditioner Toshiba RAS-24N3KV2-A Service Manual](#)

(129 pages)

[Air Conditioner Toshiba RAS-13BKV-E Service Manual](#)

Split type (106 pages)

[Air Conditioner Toshiba RAS-10N3KV2-A1 Owner's Manual](#)

(8 pages)

[Air Conditioner Toshiba RAS-24S3KHS-EE Owner's Manual](#)

(8 pages)

[Air Conditioner Toshiba RAS-B05CKVG-EE Owner's Manual](#)

(12 pages)

Summary of Contents for Toshiba RAS-24PKVSG-E

[Page 1](#) OWNER'S MANUAL ENGLISH ENGLISH AIR CONDITIONER (SPLIT TYPE) For general public use Indoor unit RAS-18, 22, 24PKVSG-E Outdoor unit RAS-18, 22, 24PAVSG-E 1120650201...

[Page 2: Precautions For Safety](#)

PRECAUTIONS FOR SAFETY Read the precautions in this manual This appliance is filled with R32. carefully before operating the unit. ● Keep this manual where the operator can easily find it. ● Read the precautions in this manual carefully before operating the unit. ●...

[Page 3](#) PRECAUTIONS FOR SAFETY ● Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. ● The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).

[Page 4](#) REMOTE CONTROL INDOOR UNIT DISPLAY 1 Eco (White) 1 Infrared signal emitter 2 Hi-Power (White) 2 Start/Stop button 3 Timer (White) 3 Mode select button (MODE) 4 Operation mode 4 Temperature button (TEMP) - Cool (Blue) 5 Fan speed button (FAN) - Heat (Orange) 6 Swing louver button (SWING) 7 Set louver Up-Down button (FIX X)

[Page 5](#) TEMPORARY OPERATION ECO OPERATION To automatically control room to save energy (except in DRY and FAN ONLY In case of the misplaced or discharged remote control ● Pressing the RESET button, the unit can start or mode) stop without using the remote control. Press : Start and stop the operation.

[Page 6](#) OPERATION AND PERFORMANCE REMOTE CONTROL A-B SELECTION 1. Three-minute protection feature: To prevent the unit from being To separate using of remote control for each indoor unit in case of 2 air activated for 3 minutes when suddenly restarted or switched to ON. conditioners are installed nearby.

[Page 7](#) 1120650201...

This manual is also suitable for:

Ras-22pkvsg-eRas-18pkvsg-eRas-18pavsg-eRas-22pavsg-eRas-24pavsg-ePkgv24