

Accessory Parts - Toshiba RAS- B22PKVSG-E Installation Manual

1
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22

--

•

Table of Contents

•

Bookmarks



No.

1

3

5

Toshiba new IAQ filter × 2

7

Flat head wood screw × 2

9

Installation Manual × 1

"

Flat head wood screw × 1

No.

\$

Air filters

Clean every 2 weeks.

1. Open the air inlet grille.



2. Remove the air filters.

3. Vacuum or wash and then dry them.

4. Reinstall the air filters and close the air inlet grille.

Filter

ACCESSORY PARTS

Indoor Unit			
No.	Part name	No.	
①	 Installation Plate × 1	②	Wirele
③	 Battery × 2	④	Remo

Maintenance & Shelf-life

Clean every 3-6 months when dust tuck or covers the fi lter.

1. Recommend to use vacuum to clean by sucking the dusts which stick or dip inside the fi lter or use the blower to blow the dust go out through the fi lter.

2. If necessary to use water to clean, simply use the plain water to wash the fi lter, dry with the sun light for 24 hours or until it is completely dry. Nevertheless, use hair drier to dry it. However, washing with water, it may reduce the performance of the fi lter.

3. Replace every 2 years or sooner. (contact your dealer to purchase new fi lter) (P/N : RB-A620DE)

Note:

Filter life depends on the level of impurities in your operating environment. Higher levels of impurities may require more frequent cleaning and replacement. In all cases, we recommend an additional set of fi lters to improve the purifying and deodorizing performance of your air conditioner.

ACCESSORY PARTS
ACCESSORY PARTS

Part name
Installation Plate × 1
Battery × 2
Part name
Drain nipple × 1
Indoor Unit







No.
2
4
6
8
!

Outdoor Unit

No.
%
5
Part name
Wireless remote control × 1
Remote control holder × 1
Mounting screw × 6
Owner's Manual × 1
Screw × 2
Battery cover × 1
Part name
Cap water proof × 2

EN
Filter

ACCESSORY PARTS

No.	Part name	No.	
①	 Installation Plate × 1	②	Wirele
③	 Battery × 2	④	Remo
⑤	 Toshiba new IAQ filter × 2	⑥	Mc
⑦	 Flat head wood screw × 2	⑧	Ow
⑨	 Installation Manual × 1	⑩	
⑪	 Flat head wood screw × 1	⑫	B

Outdoor Unit

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
4
5
6
7
8
9
10
11

Related Manuals for Toshiba RAS-B22PKVSG-E

[Air Conditioner Toshiba RAS-18PAVSG-E Owner's Manual](#)

(168 pages)

[Air Conditioner Toshiba RAS-B22PKVSG-TR Service Manual](#)

(134 pages)

[Air Conditioner Toshiba RAS-18PKVSG-E Service Manual](#)

(137 pages)

[Air Conditioner Toshiba RAS-24PAVSG-E Installation Manual](#)

(18 pages)

[Air Conditioner Toshiba RAS-24PKVSG-E Owner's Manual](#)

(7 pages)

[Air Conditioner Toshiba RAS-18N3KV2-E Service Manual](#)

Air conditioner split type (108 pages)

[Air Conditioner Toshiba RAS-18N3KV2 Series Installation Manual](#)

(23 pages)

[Air Conditioner Toshiba RAS-B16N3KV2-E1 Owner's Manual](#)

(102 pages)

[Air Conditioner Toshiba RAS-18N3KV2-E1 Installation Manual](#)

(276 pages)

[Air Conditioner Toshiba RAS-B22N3KV2-E1 Installation Manual](#)

(23 pages)

[Air Conditioner Toshiba RAS-18J2KVSG-E Service Manual](#)

Indoor/outdoor unit, r32 inverter (144 pages)

[Air Conditioner Toshiba RAS-18J2KVSG-E Installation Manual](#)

(478 pages)

[Air Conditioner Toshiba RAS-24J2AVSG-E Owner's Manual](#)

(192 pages)

[Air Conditioner Toshiba RAS-B18G3KVSG-E Installation Manual](#)

(20 pages)

[Air Conditioner Toshiba RAS-24E2KVG-E Owner's Manual](#)

Inverter r32 or r410a, for general public use, indoor/outdoor unit (7 pages)

[Air Conditioner Toshiba RAS-B24B2KVG-E Installation Manual](#)

(14 pages)

Related Content for Toshiba RAS-B22PKVSG-E

[RAS-B10S4KVDG-E Accessory And Installation Parts](#)

Toshiba RAS-B10S4KVDG-E

[RAV-GM1601AT8P-E Accessory Parts](#)

Toshiba RAV-GM1601AT8P-E

[RAV-HM301SDTY-E Accessory Parts](#)

Toshiba RAV-HM301SDTY-E

[RAS-B10S4KVPG-E Accessory And Installation Parts](#)

Toshiba RAS-B10S4KVPG-E

[RAV-GM561ATP-E1 Accessory Parts](#)

Toshiba RAV-GM561ATP-E1

[RAS-B24B2KVG-E Accessory Parts](#)

Toshiba RAS-B24B2KVG-E

[RAV-GM1601ATP-E Accessory Parts](#)

Toshiba RAV-GM1601ATP-E

[MMY-MAP0806FT8P-E Accessory Parts](#)

Toshiba MMY-MAP0806FT8P-E

This manual is also suitable for:

[Ras-18pkvsg-eRas-b24pkvsg-eRas-18pavsg-eRas-22pavsg-eRas-24pavsg-e](#)