

Table Of Contents - Asus PRIME B360-PLUS Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28

• PAGE


3

OF 28 GO

•

•

Bookmarks



Contents

[Safety information](#)

..... iv

[About this guide](#)

..... iv

[Package contents](#)

..... vi

[PRIME B360-PLUS specifications summary](#)

..... vi

Chapter 1:

[Before you proceed](#)

.....	1-1
Motherboard overview	
.....	1-1
Central Processing Unit (CPU)	
.....	1-8
System memory	
.....	1-9
Chapter 2: BIOS setup program	
.....	2-1
EZ Mode	
.....	2-2
Advanced Mode	
.....	2-3
Exit menu	
.....	2-4
Appendix	
Notices	
.....	A-1
ASUS contact information	
.....	A-4
Product introduction	
BIOS information	

[Previous Page](#)
[Next Page](#)

1
2
3
4
5
6
7

Quick Links:

[Prime B360-Plus Specifications Summary](#)

[Motherboard Overview](#)

[System Memory](#)

[Bios Setup Program](#)

Related Manuals for Asus PRIME B360-PLUS

[Motherboard Asus Prime B360-PLUS Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H370-PLUS Manual](#)

(36 pages)

[Motherboard Asus PRIME H370-PLUS Quick Start Manual](#)

(2 pages)

[Motherboard Asus ROG STRIX B360-G GAMING Manual](#)

(76 pages)

[Motherboard Asus PRIME B360M-C User Manual](#)

(27 pages)

[Motherboard Asus ROG STRIX B360-H GAMING Manual](#)

(74 pages)

[Motherboard Asus TUF B360M-PLUS Gaming Quick Start Manual](#)

(2 pages)

[Motherboard Asus TUF B360M-PLUS GAMING/BR Manual](#)

(28 pages)

[Motherboard Asus ROG STRIX B360-I GAMING Manual](#)

(84 pages)

[Motherboard Asus ROG STRIX B360-I GAMING Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME B360M-A Manual](#)

(28 pages)

[Motherboard Asus PRIME B360M-A Manual](#)

(30 pages)

[Motherboard Asus PRIME B360M-A Quick Start Manual](#)

(2 pages)

[Motherboard Asus ROG STRIX B360-F GAMING Manual](#)

(82 pages)

[Motherboard Asus PRIME B360M-K Manual](#)

(27 pages)

[Motherboard Asus PRIME B360M-D Manual](#)

(27 pages)

Related Content for Asus PRIME B360-PLUS

[PRIME Z270-K Table Of Contents](#)

Asus PRIME Z270-K

[Z170-P Table Of Contents](#)

Asus Z170-P

[Prime H270-PRO Table Of Contents](#)

Asus Prime H270-PRO

[PRIME Z270-P Table Of Contents](#)

Asus PRIME Z270-P

[PRIME Z370-P Table Of Contents](#)

Asus PRIME Z370-P

[970 PRO GAMING/AURA Table Of Contents](#)

Asus 970 PRO GAMING/AURA

[Pro WS X570-ACE Table Of Contents](#)

asus Pro WS X570-ACE

[PRIME Z390-P Table Of Contents](#)

Asus PRIME Z390-P

This manual is also suitable for:

Prime h370-plus