



Asus ROG ZS660KL User Manual

1

2

3

Table Of Contents

4

5

6

7

8

9

10

11

12

13

14


15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92



•

[Table of Contents](#)

•

Bookmarks

[Download this manual](#)

Quick Links



ZS600KL

User Guide



REPUBLIC OF
GAMERS

Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus ROG ZS660KL

[Cell Phone Asus ROG PHONE ZS660KL User Manual](#)

(90 pages)

[Cell Phone Asus REPUBLIC OF GAMERS ROG Phone II User Manual](#)

(89 pages)

[Cell Phone Asus ROG PHONE ZS600KL User Manual](#)

(90 pages)

[Telephone Asus ZB553KL User Manual](#)

(106 pages)

[Telephone Asus Zenfone Z01KD User Manual](#)

(28 pages)

[Telephone Asus Go ZB500KL User Manual](#)

(32 pages)

[Telephone Asus ZB551KL Training & Trouble Shouting Manual](#)

Board level (69 pages)

[Telephone Asus ZD553KL Service Manual](#)

(55 pages)

[Telephone Asus X007D User Manual](#)

(86 pages)

[Telephone Asus E9995 User Manual](#)

(29 pages)

[Telephone Asus Eee Videophone AiGuru SV1T User Manual](#)

Internet video phone (34 pages)

[Telephone Asus ASUS_Z01FD User Manual](#)

(54 pages)

[Telephone Asus AiGuruSV1T User Manual](#)

Internet video phone (34 pages)

[Telephone Asus AiGuru S2 Manual](#)

Wireless skype phone (106 pages)

[Telephone Asus AiGuru U1 User Manual](#)

Usb phone for skype (38 pages)

[Telephone Asus P320 Service Manual](#)

(33 pages)

Summary of Contents for Asus ROG ZS660KL

[Page 1](#) ZS600KL User Guide...

[Page 2](#) Use only AC adapters and cables approved by ASUS for use with this device. Refer to the rating label on the bottom of your device and ensure that your power adapter complies with this rating.

[Page 3](#) NOTE: For more legal and e-labelling information, check on your device from Settings > About > Legal information / Regulatory labels. ZenTalk Fans Forum (http://www.asus.com/zentalk/global_forward.php) NOTE: The app descriptions shown in this manual are for reference purposes only, and may not exactly match what you see on your

device.

[Page 4: Table Of Contents](#)

Clearing the browsing data	34	Gmail	35	Google Calendar	36
Creating events	36	Editing or removing events	36	Editing or removing reminders	37
Creating reminders	37	File Manager.....	38	The Cloud	39
ASUS WebStorage	39	Game Center	40	Aura lighting	40...

[Page 5](#)

Keeping in touch Call in style	41	Dual SIM feature	41		
Making calls	43	Receiving calls	45	Other call options	46
Answering another call	47	Recording calls	47	Managing contacts	48
Contacts Settings	48	Setting up your profile	48	Adding contacts	49
Marking your favorite contacts	50	Social networking with your contacts	51	Send messages and more	52...

[Page 6](#)

Travel and Maps Weather	66	Launching the Weather app	66	Weather home screen	67
Clock	68	World Clock	68	Alarm clock	69
Stopwatch	69	Timer	70	Zen Everywhere Special Zen Tools	71
Sound Recorder	71	Mobile Manager	73	Bluelight Filter	74
AirTriggers	75	Memory Cleaner	76	Maintain your Zen...	

[Page 7: Basics](#)

ROG Phone and its connected external storage devices. NOTE: Availability of ASUS ZenUI apps vary per region and ROG Phone model. Swipe up from the lower part of your Home screen to check the apps available on your ROG Phone.

[Page 8: Get Your Rog Phone Ready](#)

- DO NOT use a metallic protective frame/case on your ROG Phone.
- DO NOT cover the antenna area with your hands or other objects while using some functions such as making calls or using the mobile data connection.
- We recommend that you use ASUS-compatible screen protectors. Using non-ASUS-compatible screen protectors may cause your ROG Phone's sensor to malfunction.

NOTES: • The USB Type-C port supports USB 2.0 transfer rate. The Side Mount connector Type-C port supports USB 3.1 Gen1 transfer rate.

[Page 9: Aeroactive Cooler Features](#)

AeroActive Cooler features Use the AeroActive Cooler to keep your ROG Phone working at a high frequency during heavy workloads by providing a better thermal solution, and offering the ultimate user experience. Audio jack USB Type-C port Aura light NOTE: Connect your AeroActive Cooler to the Side Mount connector of your ROG Phone. To install AeroActive Cooler: 1.

[Page 10](#)

To prevent connector damage, ensure to use a standard nano SIM card without a SIM adapter or NOTE: the use of a cutter. CAUTION! Be extra careful when handling a nano SIM card. ASUS is not responsible for any data loss or damage incurred to your nano SIM cards. To install a Nano SIM card: 1.

[Page 11](#)

Removing a nano SIM card CAUTION! Be extra careful when handling a nano SIM card. ASUS is not responsible for any data loss or damage incurred to your nano SIM cards. To remove a nano SIM card: 1. Push a pin into the hole on the Nano SIM card tray to eject it. Remove the Nano SIM card(s) from the card slot(s).

[Page 12](#)

- While charging, your ROG Phone can become warm. This is normal, however, if your device becomes unusually hot, disconnect the USB Type-C cable from your device and send the device, including the AC power adapter and cable to an ASUS-qualified service personnel.
- To prevent any damage to your ROG Phone, AC adapter, or USB Type-C cable. Ensure that the USB Type-C cable, AC adapter, and your device are connected properly before charging.

[Page 13](#)

USB Type-C port * DO NOT insert a USB Type-C cable to this port. NOTES: • We recommend that you charge your ROG phone through one USB Type-C port at a time. • Only the Side Mount connector has Display Port functionality. • If you connect USB Type-C OTG or charging devices to both of the USB Type-C ports on your ROG phone, the Side Mount connector

will become the master and the charging current or OTG device on the bottom port will be limited.

[Page 14](#) **IMPORTANT!** • When using your ROG Phone while it is plugged to a power outlet, the grounded power outlet must be near to the unit and easily accessible. • When charging your ROG Phone through your computer, ensure that you plug the USB Type-C cable to your computer's USB port. • Avoid charging your ROG Phone in an environment with ambient temperature of above 35 C (95 • DO NOT charge your ROG phone underwater or when the USB connector is wet. • Charge your ROG Phone for eight (8) hours before using it in battery mode for the first time. • The status of battery charge is indicated by the following icons: Not Charging Charging Full...

[Page 15](#) Using NFC NOTE: NFC is only available in selected regions/countries. You can use NFC in the following three scenarios: Reader mode: Your phone reads information from a contactless card, NFC tag, or other NFC devices. Place the NFC area of your phone on the contactless card, NFC tag, or NFC device. Card Emulation mode: Your phone can be used like a contactless card.

[Page 16](#) Turning your ROG Phone on or off Turning your device on To turn your device on, press and hold the power button until your device vibrates and starts up. Turning your device off To turn your device off: 1. If your screen is turned off, press the power button to turn it on. If your screen is locked, unlock the device screen.

[Page 17: Starting For The First Time](#)

Follow the onscreen instructions to select your language, set up your mobile network, Wi-Fi and security features, and sync accounts. Use your Google or ASUS account to set up your device, if you do not have a Google or ASUS account yet, go ahead and create one.

[Page 18: Using The Touchscreen](#)

Using the touchscreen Use these gestures on the touchscreen to launch apps, access some settings, and navigate your ROG Phone. Launching apps or selecting items Do any of the following: • To launch an app, simply tap on it. • To select an item such as in File Manager app, simply tap on it. Moving or deleting items Do any of the following: • To move an app or widget, tap and hold then drag it to the location where you want it to be.

[Page 19](#) Moving through pages or screens Do any of the following: • Swipe your finger to the left or to the right to switch between screens or to flip through a Gallery of images. • Scroll your finger up or down to go through web pages or list of items. Zooming in Spread apart your two fingers on the touch panel to zoom in an image in Gallery or Maps, or zoom in a web page. Chapter 1: Basics...

[Page 20](#) Zooming out Bring together your two fingers on the touch panel to zoom out an image in Gallery or Maps, or zoom out of a web page. NOTE: You may not be able to zoom in/out of some web pages as these pages may have been designed specifically to fit your mobile screen.

[Page 21: There's No Place Like Home](#)

There's no place like Home There's no place like Home Zen Home features Home screen Get reminders of important events, app and system updates, weather forecasts, and text messages from people who really matter to you, right from your Home screen. Swipe down this area once to display System notifications Swipe down this area twice to display Quick settings Tap to open Google Search page...

[Page 22: Quick Settings](#)

Quick settings The Quick settings panel provides a one-tap access to some of the wireless features and settings of your ROG Phone. Each of these features are represented by an icon. To launch the Quick settings panel, swipe down twice from the top of your screen. NOTE: An orange icon indicates that the feature is currently enabled while a gray icon indicates a disabled feature.

[Page 23: Notifications](#)

Notifications From the notifications panel, you can see the latest updates done and system changes made on your ROG Phone. Most of these changes are data and system-related. To

launch the notifications panel, swipe down from the top of your screen. Tap to open Settings
Swipe down to switch to the Quick Settings panel • S wipe the notification to the left or right to...

[Page 24: Personalizing Your Home Screen](#)

Personalizing your Home screen Stamp your own personality on your Home screen. Select an attractive design as your wallpaper, and add widgets for a quick review of important info. You can also add more pages so you can add and quickly access or view more apps or widgets on your Home screen. To launch the Manage Home screen, tap and hold an empty area on your Home screen.

[Page 25: Wallpapers](#)

Wallpapers Let your apps, icons, and other Zen elements sit on an attractively designed wallpaper. You may add a translucent background tint to your wallpaper for readability and clarity. You can also select an animated wallpaper to make your screen come alive. Tap to select where you want to apply the wallpaper Tap to edit the wallpaper Tap to select an image from Gallery...

[Page 26: Setting Up The Date And Time](#)

Editing your Home screen You can extend your Home screen, select a scroll effect, change the icon and font, adjust the size and color of the icon and font, and align the icons to the top or bottom of your screen. 1.

[Page 27: Lock Screen](#)

Lock Screen By default, the lock screen appears after turning on your device and while waking it up from sleep mode. From the lock screen, you can proceed to your device's Android® system by swiping on your touch screen panel. Your device's lock screen can also be customized to regulate access to your mobile data and apps.

[Page 28: Fingerprint Id Sensor](#)

Fingerprint ID sensor Fingerprint ID sensor prevents others from using your ROG Phone without your permission. You can use your fingerprint to unlock your device, access your phone calls and data. When you set up your fingerprint ID, you also need to set up your screen lock method for device startup. Starting your ROG Phone for the first time To set up your fingerprint ID when using your ROG Phone for the first time: 1.

[Page 29: Setting Up Fingerprint Id From Settings](#)

Setting up fingerprint ID from Settings To set up your fingerprint ID from Settings: 1. Ensure that the fingerprint scanner and your finger are clean and dry. 2. Launch the Settings screen by doing any of the following: • Launch Quick Settings then tap •...

[Page 30: Face Unlock](#)

Face Unlock Face unlock prevents others from using your ROG Phone without your permission effortlessly. You can light up your ROG Phone's screen and look at it to unlock your device, access your phone's home screen in one second. When you set up your face unlock, you also need to set up your screen lock method for device startup.

[Page 31](#) Select how you want to display your notifications on the lock screen, then tap Done.
Chapter 2: There's no place like Home...

[Page 32](#) Tap Next and follow the instructions to register your face. When finished, tap Done.
NOTES: • Show your mouth, nose and opened eyes while using face unlock feature. • Wearing sunglasses or insufficient light will lead to failure of face unlock. Chapter 2: There's no place like Home...

[Page 33: Work Hard, Play Harder](#)

Work hard, play harder Work hard, play harder Chrome Chrome for Android lets you enjoy the same fast, secure and stable web browsing experience as that on the desktop Chrome. Sign in to your Google account to sync tabs, bookmarks, and browsing history across all your devices.

[Page 34: Sharing Pages](#)

Sharing pages Share interesting pages from your ROG Phone to others via an email account, cloud storage account, Bluetooth, or other ROG Phone apps. 1. Launch Chrome. 2. From a web page, tap > Share... 3. Tap the account or app that you want to use as medium in sharing the page. Bookmarking pages Bookmark your favorite pages or websites so you can go back and browse them again.

[Page 35: Gmail](#)

Gmail Use Gmail to set up your Google account to get into Google-related services and apps as well as receive, send, and browse emails right from your ROG Phone. You can also set up other email accounts such as Yahoo or your work email account via Gmail. IMPORTANT! Your ROG Phone must be connected to a Wi-Fi or mobile network so you can add Staying an email account or send and receive emails from added accounts.

[Page 36: Google Calendar](#)

Google Calendar Bring your schedule to life and keep track of all your important events or reminders. Events that you create or edit will automatically sync with all Google Calendar versions that you've logged into. Creating events To create an event: 1.

[Page 37: Creating Reminders](#)

Creating reminders To create a reminder: 1. From the Home screen, Google > Calendar. then tap Reminder. 2. Tap 3. Enter your reminder name and tap DONE. 4. Set the date and time for the reminder. You may set the reminder as an all-day or recurring reminder.

[Page 38: File Manager](#)

File Manager Using File Manager allows you to easily locate and manage your data on the internal storage of your ROG Phone and its connected external storage devices. To launch File Manager, swipe up from the lower part of your Home screen then tap File Manager. Tap to access the internal, external, network, and cloud storage Tap to search for a file...

[Page 39: The Cloud](#)

Cloud account such as ASUS WebStorage, Drive, OneDrive, and Dropbox. ASUS WebStorage Register for or sign in to ASUS WebStorage and get free cloud storage. Automatically upload newly captured photos for instant sharing, sync files among different devices, or share files via your ASUS WebStorage account.

[Page 40: Game Center](#)

Game Center Game Center displays the information of CPU, GPU, used memory and storage, allows you to adjust the fan speed, enable or disable Aura lighting and configure game settings. Aura lighting Slide Aura lighting to ON and tap to configure the light effect. Chapter 3: Work hard, play harder...

[Page 41: Keeping In Touch](#)

Keeping in touch Keeping in touch Call in style Dual SIM feature The dual SIM feature of your ROG Phone lets you manage the settings of the installed Nano SIM cards. With this feature, you can enable/disable Nano SIM cards, assign SIM names, or set one as a preferred network.

[Page 42](#) Assigning a preferred SIM card Assign a SIM card as your preferred SIM for voice calls, SMS messages, and data services. SIM card for voice calls When you make a call, your ROG Phone automatically uses the preferred SIM card to connect the call.

[Page 43: Making Calls](#)

Making calls Your ROG Phone offers you many ways to make a call. Call your friends from your contacts list, smart dial to quickly place a call, or enter a speed-dial number to call your frequently-called contact. NOTE: Organize your contacts in the Contacts app. For details, see Managing contacts.

[Page 44](#) Auto-dialing an extension number You can insert a short or long pause after dialing the main number, then the extension number is dialed automatically. 1. From the Phone app, enter the main number. 2. To insert a pause, tap and hold * until a comma (,) appears. 3.

[Page 45: Receiving Calls](#)

Calling your favorite contacts When you add a contact to your Favorites list, you can quickly call the contact from the Phone app. 1. Launch the Contacts app. 2. Tap Groups > Favorites to display your Favorites list, then tap your favorite contact whom you want to call.

[Page 46: Other Call Options](#)

Redialing your last-called number To redial your last-called number: 1. From the Phone app, tap Recents to display your call logs. 2. Tap the call button to display your last-called number, then tap the call button again to redial the number. 3.

[Page 47: Answering Another Call](#)

Answering another call While you are talking on your ROG Phone, you can hear a beeping sound, indicating of another incoming call. Tap Answer on the touch screen to receive an incoming call while on an active call. Recording calls Your ROG Phone allows you to record a conversation for future reference or information.

[Page 48: Managing Contacts](#)

You can also sync your contacts with your email or social network accounts, link contacts' info for easy access in one place, or filter the contacts you want to keep in touch with. To launch the Contacts app, swipe up from the lower part of your Home screen then tap ASUS > Contacts.

[Page 49: Adding Contacts](#)

Adding contacts Add contacts to your device, corporate, Google, or other email accounts and fill in more important contact information such as contact numbers, email addresses, special events for VIPs, and more. 1. Launch the Contacts app then tap 2. Select Device. NOTES: • You can also save the contact to your SIM card or an email account.

[Page 50: Marking Your Favorite Contacts](#)

Set your frequently-called contacts as your favorites to be able to call them quickly from the Phone app. 1. Swipe up from the lower part of your Home screen then tap ASUS > Contacts. 2. Select the contact that you want to mark as a favorite.

[Page 51: Social Networking With Your Contacts](#)

Create your list of blocked contacts or numbers to avoid receiving any unwanted calls or messages. Your blocked calls and messages will be saved to the Block List archive. 1. Swipe up from the lower part of your Home screen then tap ASUS > Contacts then tap >...

[Page 52: Send Messages And More](#)

Syncing your social network account Sync your social network account to add the social network accounts of your contacts to your ROG Phone. 1. Do any of the following to launch the Settings app: • Launch Quick Settings then tap •...

[Page 53: Fun And Entertainment](#)

Fun and entertainment Fun and entertainment Using a headset Have the freedom to do other things while you're in a call or enjoy listening to your favorite music, using a headset. Connecting the audio jack Insert the 3.5mm headset jack into the audio port of your device. WARNING! • Do not insert other objects into the audio jack port.

[Page 54: Google Play Music](#)

Google Play Music With Google Play Music, you can stream your favorite music, create playlists, or listen to the radio. You can also store up to 50,000 music files to the cloud for free. You can also subscribe to Google Play Music for unlimited and ad-free access to millions of music files that you can add to your own music library.

[Page 55: Your Precious Moments](#)

Your precious moments Your precious moments Capture moments Launching the Camera app Capture images and record videos using your ROG Phone's Camera app. Refer to any of the steps below to open the Camera app. From the home screen Using the volume key While your ROG Phone is on sleep mode, double-click the volume key to wake it up and immediately launch

the Camera app.

[Page 56](#) Camera home screen Your ROG Phone's camera is equipped with auto-scene detection and auto-image stabilizer features. It also features a video stabilization function that helps prevent shakiness while video recording. Tap the icons to start using your camera and explore the image and video features of your ROG Phone.

[Page 57](#) Advanced camera features Explore new ways of capturing images or videos and make captured moments extra special using the advanced camera features of your ROG Phone. IMPORTANT! Apply the settings first before taking images. Available features may vary per model. Beauty Have fun during and after taking photos of your family and friends using the Beauty feature of your ROG Phone.

[Page 58](#) Panorama Capture images from various angles using Panorama. Images captured from a wide angle perspective are automatically stitched together using this feature. Capturing panoramic photos From the Camera app's home screen, swipe to the right then tap Panorama. Tap the shutter button then pan your ROG Phone horizontally (to the left or right) or vertically (upward or downward) to capture the scenery.

[Page 59: Using The Gallery](#)

From Gallery, you can display images in a slideshow or tap to view the selected image or video file. To launch Gallery, Swipe up from the lower part of your Home screen then tap ASUS > Gallery. Viewing the photo location Enable the location access on your ROG Phone, and get the location details on your photos.

[Page 60: Editing Images](#)

Editing images The Gallery also features its own image editing tools that you can use to enhance images saved on your ROG Phone. 1. From the Gallery screen, tap the folder where the files are located. 2. After opening the folder, tap the image you want to edit. 3.

[Page 61: Staying Connected](#)

Staying connected Staying connected Mobile network When there's no available Wi-Fi network that you can connect to, you can enable your mobile network's data access for Internet connection. Enabling the mobile network 1. Do any of the following to launch the Settings screen: •...

[Page 62: Connecting To A Wi-Fi Network](#)

Connecting to a Wi-Fi network 1. On the Settings screen, tap Wi-Fi to display all detected Wi-Fi networks. 2. Tap a network name to connect to it. For a secured network, you may be prompted to key in a password or other security credentials. NOTES: • Your ROG Phone automatically reconnects to the network that you connected with previously.

[Page 63: Pairing Your Rog Phone To A Bluetooth® Device](#)

Pairing your ROG Phone to a Bluetooth® device Before using the Bluetooth feature of your ROG Phone in full scale, you have to pair it first with the Bluetooth device. The ROG Phone automatically stores the pairing connection of the Bluetooth device.

[Page 64: Tethering](#)

Tethering When Wi-Fi service is not available, you can use your ROG Phone as a modem or turn it into a Wi-Fi hotspot to get Internet access on your laptop, tablet, and other mobile devices. IMPORTANT! Most mobile service providers may require a data plan for you to be able to use the tethering function.

[Page 65: Bluetooth Tethering](#)

USB Tethering Enable USB tethering on your ROG Phone and share its Internet connection with other devices. Connect your ROG Phone to another device with a USB cable. From the Settings screen, tap Connections > Hotspot & Tethering, then slide USB tethering to ON to enable tethering.

[Page 66: Travel And Maps](#)

Travel and Maps Travel and Maps Weather Get real-time weather updates straight from your

ROG Phone using the weather app. Using Weather, you can also check other weather details from around the world. Launching the Weather app From your Home screen, tap the weather icon to launch the Weather app. Chapter 8: Travel and Maps...

[Page 67: Weather Home Screen](#)

Weather home screen Set up and get your current location's weather updates as well as other parts of the world. Tap to search for a city's weather info Tap to get the area's current weather info, refresh the weather info, edit the location list, or configure the weather settings Swipe up to see other weather information.

[Page 68: Clock](#)

Clock Customize the time zone settings of your ROG Phone, set alarms, and use your ROG Phone as a stop watch using the Clock app. Launching Clock Launch the Clock app using either of the following options: • Swipe up from the lower part of your Home screen then tap Clock. •...

[Page 69: Alarm Clock](#)

Alarm clock Tap ALARM to access the alarm clock settings of your ROG Phone. Tap to open the alarm settings. Tap this to set a new alarm time. Stopwatch Tap STOPWATCH to use your ROG Phone as a stopwatch. Tap this button to start running the stopwatch feature. Chapter 8: Travel and Maps...

[Page 70: Timer](#)

Timer You may set multiple timer options for your ROG Phone. To do this, follow the steps below: Setting the timer 1. Tap TIMER to access the timer feature of your ROG Phone. Tap this to key in the time for the timer. Tap this button to start running the timer.

[Page 71: Zen Everywhere](#)

Record audio files using your ROG Phone by enabling the Sound Recorder app. Launching Sound Recorder To launch Sound Recorder, swipe up from the lower part of your Home screen then tap ASUS > Sound Recorder. Tap to customize the Sound Recorder settings...

[Page 72](#) Pausing a recording During a paused recording, you can choose to resume, delete, or save the recording. Tap to delete the recording Tap to resume the recording Tap to save the recording Recording List From the Recording List, you can play, rename, share, or delete a saved audio recording file. To view your recording list, tap from the Sound Recorder main screen.

[Page 73: Mobile Manager](#)

Mobile Manager provides an integrated interface for several apps that are designed to optimize device performance, manage the phone power, storage usage and system notifications. To launch the ASUS Mobile Manager app, swipe up from the lower part of your Home screen then tap Mobile Manager.

[Page 74: Bluelight Filter](#)

Bluelight Filter Bluelight Filter provides a mild paper-like display that reduces eye strain for a comfortable reading experience on your ROG Phone. To enable Bluelight Filter: • From the Quick settings panel, tap on the Bluelight Filter icon. Tap to enable bluelight filter Chapter 9: Zen Everywhere...

[Page 75: Airtriggers](#)

AirTriggers The exclusive AirTriggers feature provides two extra virtual hotkeys when you play games on your ROG Phone for optimal experience. To enable AirTriggers: • From the Quick settings panel, tap on the AirTriggers icon. Tap to enable AirTriggers Chapter 9: Zen Everywhere...

[Page 76: Memory Cleaner](#)

Memory Cleaner Memory cleaner provides boosted memory performance. To enable Memory Cleaner: • From the Quick settings panel, tap on the Memory Cleaner icon. Tap to enable Memory Cleaner Chapter 9: Zen Everywhere...

[Page 77: Maintain Your Zen](#)

Maintain your Zen Maintain your Zen Keeping your device up-to-date Keep your ROG Phone in the loop of Android system updates and upgraded apps and features. Updating your system 1. Swipe up from the lower part of your Home screen then tap Settings. 2.

[Page 78: Securing Your Rog Phone](#)

2. From the Reset window, you can: Network settings reset: This feature restores Wi-Fi passwords, and other network • settings. • App preferences reset: This feature facilitates restoration of backed up settings and data when you reinstall an app. • Factory data reset: Erases all data on phone.

[Page 79](#) Key in at least four numbers to set a PIN. IMPORTANT! Ensure to remember the PIN that you created to unlock your device. Pattern Slide your finger on the dots and create a pattern. IMPORTANT! You can create a pattern with a minimum of four dots. Ensure to remember the pattern that you created to unlock your device.

[Page 80](#) Password Key in at least four characters to create a password. IMPORTANT! Ensure to remember the password that you created to unlock your device. Setting your ROG Phone identity Know your ROG Phone's identity such as serial number, IMEI (International Mobile Equipment Identity) number, or model number.

[Page 81: Appendix](#)

- Do not remove the non-detachable Li-polymer battery as this will void the warranty.
- Avoid charging in extremely high or low temperature. The battery performs optimally in an ambient temperature of +5 °C to +35 °C.
- Do not remove and replace the battery with a non-approved battery.
- Use only ASUS battery. Using a different battery may cause physical harm/injury and may damage your device.
- Do not remove and soak the battery in water or any other liquid.
- Never try to open the battery as it contains substances that might be harmful if swallowed or allowed to come into contact with unprotected skin.
- Do not remove and short-circuit the battery, as it may overheat and cause a fire. Keep it away from jewelry or metal objects.

[Page 82](#) • To avoid fire or burns, do not disassemble, bend, crush, or puncture the battery. NOTES: • Risk of explosion if battery is replaced by an incorrect type. • Dispose of used battery according to the instructions. The charger • Use only the charger supplied with your ROG Phone. • Never pull the charger cord to disconnect it from the power socket. Pull the charger itself. Caution Your ROG Phone is a high quality piece of equipment. Before operating, read all instructions and cautionary markings on the (1) AC Adapter. • Do not use the ROG Phone in an extreme environment where high temperature or high humidity exists. The ROG Phone performs optimally in an ambient temperature between 0 °C (32 °F) and 35 °C (95 °F).

[Page 83: Notices](#)

WiFi products that are marketed in US must be fixed to US-operated channels only. The responsible party within the USA per 47 CFR Part 2.1077(a)(3): ASUS COMPUTER INTERNATIONAL (America) Address: 48720 Kato Rd., Fremont, CA 94538, USA Telephone: +1-510-739-3777 RF Exposure Information (SAR) This device has been tested and meets applicable limits for Radio Frequency (RF) exposure.

[Page 84](#) To reduce exposure to RF energy, use a hands-free accessory or other similar option to keep this device away from your head and body. Carry this device at least 15 mm away from your body to ensure exposure levels remain at or below the as-tested levels. Choose the belt clips, holsters, or other similar body-worn accessories which do not contain metallic components to support operation in this manner.

[Page 85](#) This device may not cause interference; and This device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux normes CNR d'Industrie Canada applicables aux appareils radio exempts de licence. Son utilisation est sujette aux deux conditions suivantes : Cet appareil ne doit pas créer d'interférences nuisibles, et Cet appareil doit tolérer tout type d'interférences, y compris celles susceptibles de provoquer un fonctionnement non souhaité...

[Page 86](#) <http://www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf08792.html>. CAN ICES-3(B)/NMB-3(B) This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter, except tested

built-in radios.

[Page 87](#) Simplified EU Declaration of Conformity Hereby, ASUSTek Computer Inc. declares that the radio equipment ASUS_Z01QD is in compliance with Directive 2014/53/EU. Full text of EU declaration of conformity is available at <https://www.asus.com/support/>. (Search for ZS600KL) RF Output Table Items...

[Page 88](#) RF Exposure Information This ASUS product has been tested and meets applicable European SAR limits. The SAR limit is 2.0 W/kg in countries that set the limit averaged over 10 grams of tissue. The specific maximum SAR values for this device are as follows: •...

[Page 89](#) Rule. ASUS Recycling/Takeback Services ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm...>

[Page 90](#) I/O ports are located. Green ASUS notice ASUS is devoted to creating environment-friendly products and packaging to safeguard consumers' health while minimizing the impact on the environment. The reduction of the number of the manual pages complies with the reduction of carbon emission.

[Page 91: Index](#)

- setting up fingerprint ID from Settings 30 - receiving 45 - Setting up fingerprint ID from Settings 29 - recording 47 - Starting your ASUS phone for the first time - see also Contacts 48 - see Call logs 45 - locate finger print scanner 28...

[Page 92](#) - moving through pages or screens 19 - zooming in 19 - zooming out 20 Lock screen 27 - customizing 27 - see also Securing your ASUS phone 78 Wallpapers 25 - animated wallpaper 25 - wallpaper and background tint 25 Weather 66...

This manual is also suitable for:

[Rog zs600k](#)