



# **TOSHIBA**

Toshiba TCB-LK2801DP-UL Installation Manual

Air conditioner filter kit




1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12

--

•

## Bookmarks

Available languages



The language selection bar consists of three horizontal buttons. The top button is light blue and contains the text 'EN'. The middle button is dark blue and contains the text 'FR'. The bottom button is red and contains the text 'ES'. The buttons are separated by thin white lines and are set against a light gray background.

## Quick Links

[Download this manual](#)



1

AIR CONDITIONER

Filter kit **TOSHIBA**

Model: **Carrier** TCB-LK2801DP-UL

## 1. Adaptation model

Model name

TCB-LK2801DP-UL

## 2. Accessories





2  
2  
8  
4  
18  
1  
2  
2  
1  
3.1\*(60)



# **TOSHIBA**

---

## *Carrier*

[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Toshiba TCB-LK2801DP-UL

### [Air Conditioner Accessories Toshiba TCB-SC642TLE Installation Manual](#)

Central remote controller for split system air conditioner (181 pages)

### [Air Conditioner Accessories Toshiba TCB-SIR41UYP-UL Operation Manual](#)

Occupancy sensor kit (8 pages)

### [Air Conditioner Accessories Toshiba TCB-SIR41UYP-UL Installation Manual](#)

Occupancy sensor kit (8 pages)

### [Air Conditioner Accessories Toshiba RBC-UM11PGE Installation Manual](#)

Ceiling panel (36 pages)

### [Air Conditioner Accessories Toshiba Carrier TCB-SGMH2802KU-Y Installation Manual](#)

Snow hood (2 pages)

### [Air Conditioner Accessories Toshiba TCB-KBOS3E Installation Manual](#)

Optional connector kit (2 pages)

### [Air Conditioner Accessories Toshiba TCB-SIR33UP-E Operation Manual](#)

Occupancy sensor kit (4 pages)

### [Air Conditioner Accessories Toshiba TCB-SIR33UP-E Installation Manual](#)

Occupancy sensor kit (2 pages)

### [Air Conditioner Accessories Toshiba TCB-TDL0141SDY-E Owner's Manual](#)

3dw diffusor (7 pages)

### [Air Conditioner Accessories Toshiba Carrier RBC-AX33UYP-UL Operation Manual](#)

Wireless receiver kit (48 pages)

## Summary of Contents for Toshiba TCB-LK2801DP-UL

**Page 1** Thank you for purchasing the Filter kit for air conditioner. AIR CONDITIONER Before starting the installation work, please read this manual carefully and Filter kit install the product properly. Model: TCB-LK2801DP-UL 1. Adaptation model Model name Adaptation model TCB-LK2801DP-UL MMD-AP072\*HP-UL, MMD-AP096\*HP-UL 2. Accessories Below parts are included.

### **Page 2: How To Install**

4. How to install 1. Peel off the tape fi xing the fi lter rail. 4. Install (2) Filter frame. And check if the claw of the fi lter rail is not taken off. (2) Filter frame (6) Screws  $\varnothing 13/64'' \times 0.3''$  (M5  $\times$  8) (4pcs) (2) Filter frame Tape Tape...

**Page 3** 5. External Pressure Loss Characteristic When you use these "Filter kit", pressure-loss characteristics depends on Air Flow. Filter kit, Pressure Loss Characteristics 0.24 0.20 0.16 0.12 0.08 0.04 1059 1413 1766 2119 2472 2825 3178 3531 Air Flow (CFM)

### **Page 4: Manuel D'installation**

Merci d'avoir acheté ce kit de fi ltre pour climatiseur. CLIMATISEUR Avant de démarrer les travaux d'installation, veuillez lire attentivement le présent Kit de fi ltre manuel et installer le produit correctement. Modèle: TCB-LK2801DP-UL 1. Modèle d'adaptation Modèle du modèle Modèle d'adaptation TCB-LK2801DP-UL MMD-AP072\*HP-UL, MMD-AP096\*HP-UL 2. Accessoires

Les pièces ci-dessous sont incluses.

### [Page 5: Installation](#)

4. Installation 1. Pelez la bande adhésive du rail du fi ltre. 4. Installez (2) le cadre du fi ltre. Et vérifi ez que la griffe du rail du fi ltre n'est pas retirée. (2) Cadre du fi ltre (6) Vis Ø13/64" × 0,3" (M5 × 8) (4) (2) Cadre du fi...

[Page 6](#) 5. Caractéristiques de perte de pression externe Lors de l'utilisation de ce « Kit de fi ltre », les caractéristiques de perte de pression dépendent du débit d'air. Kit de fi ltre, Caractéristiques de perte de pression 0,24 0,20 0,16 0,12 0,08 0,04...

### [Page 7: Manual De Instalación](#)

AIRE ACONDICIONADO Antes de comenzar el trabajo de instalación, lea este manual cuidadosamente e instale el Kit de fi ltro producto correctamente. Modelo: TCB-LK2801DP-UL 1. Modelo de adaptación Nombre del modelo Modelo de adaptación TCB-LK2801DP-UL MMD-AP072\*HP-UL, MMD-AP096\*HP-UL 2.

[Page 8](#) 4. Colocación 1. Retire la cinta que fi ja el riel del fi ltro. 4. Instale (2) Bastidor de fi ltro. Y compruebe si la garra del riel del fi ltro no está despegada. (2) Bastidor de fi ltro (6) Tornillos Ø13/64" × 0,3" (M5 × 8) (4 piezas) (2) Bastidor de fi...

[Page 9](#) 5. Característica de pérdida de presión externa Cuando se utilizan estos "kit de fi ltros", las características de pérdida de presión dependen del fl ujo de aire. Kit de fi ltro, características de pérdida de presión 0,24 0,20 0,16 0,12 0,08 0,04 1059...