

Bookmarking Frequently-Accessed Sites; Accessing Bookmarked Sites - Sanyo au W22SA Basic Manual

1

2

3

4

5

6

7

Table Of Contents

8

9

10

11

12

13

14


15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



Bookmarking Frequently-Accessed Sites

Display the site to bookmark and press R (e).

The Browser Menu appears.

Use j to select "New bookmark" and press



C (X).

The screen for registering the title and URL appears.

Press R (w).

The currently-displayed site is bookmarked.

Some sites cannot be bookmarked.

Information

Up to 100 sites can be bookmarked.



Accessing Bookmarked Sites

Press E while the standby screen is displayed.

The EZ Menu appears.

Use j to select "Favorite Site" and press c (x).

A list of bookmarks appears.

Use j to select a site and press c (u).


The selected site appears.



70

EZ Menu

□□□□ □□□□
 □□□□ □□□□□□□□
 □□□□□□
 □□□□□□□□□□
 □□□□ □□□□□□□□
 □□ □□ □□□
 □□□□□□ □□□□□□□□□□



□□□□
 □□□□□□□□△□□□□□□□□
 □□□□□□□□
 □□□□
 □□□□□□□□□□
 □□□□□□□□□□ □□
 □□□□□□□□ □□□□

1

□□□□□□□□□□



Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
69
70
71
72
73
74
75
76

Related Manuals for Sanyo au W22SA

[Cell Phone Sanyo A5514SA Basic Manual](#)

(104 pages)

[Cell Phone Sanyo A5514SA Operating Instructions Manual](#)

(30 pages)

[Cell Phone Sanyo A5527SA Basic Manual](#)

(92 pages)

[Cell Phone Sanyo A1303SA Operating Instructions Manual](#)

(22 pages)

[Cell Phone Sanyo SANYO Innuendo User Manual](#)

(140 pages)

[Cell Phone Sanyo Katana User Manual](#)

Sanyo katana: user guide (217 pages)

[Cell Phone Sanyo Katana User Manual](#)

Sanyo katana: users guide (256 pages)

[Cell Phone Sanyo W52SA User Manual](#)

(78 pages)

[Cell Phone Sanyo PLS-200 User Manual](#)

Sanyo pls-200: users guide (166 pages)

[Cell Phone Sanyo SCP-5500 Operating Manual](#)

Dual-band /tri-mode (87 pages)

[Cell Phone Sanyo SCP-7300 User Manual](#)

Dual band/tri mode phone (81 pages)

[Cell Phone Sanyo SCP-6600 User Manual](#)

(133 pages)

[Cell Phone Sanyo Incognito User Manual](#)

Sanyo incognito: user guide (129 pages)

[Cell Phone Sanyo Cell Phone User Manual](#)

Sprint pcs vision phone (256 pages)

[Cell Phone Sanyo SCP-5500 Specifications](#)

Sanyo scp-5500: specifications (2 pages)

[Cell Phone Sanyo Katana II User Manual](#)

Sanyo phone user guide (207 pages)

Related Content for Sanyo au W22SA

[W52SA Bookmarking Frequently-Accessed Site](#)

Sanyo W52SA

[W63SA Bookmarking Frequently-Accessed Site](#)

Sanyo W63SA

[W54SA Bookmarking Frequently-Accessed Site](#)

Sanyo W54SA

[W64SA Bookmarking Frequently-Accessed Site](#)

Sanyo W64SA

[W61SA Bookmarking Frequently-Accessed Site](#)

Sanyo W61SA

[A5514SA Registering Frequently-Accessed Sites](#)

Sanyo A5514SA