



# Local Adaptor For On/Off Controller (Sha-KI4Ug(B)) - Sanyo MINI ECO-i SPW-CR365GXH56B Service Manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68

69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118

119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168

169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218



219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252



•

[Table of Contents](#)

- 

Troubleshooting

•

## Bookmarks





## 8. Local Adaptor for ON/OFF Controller (SHA-KL4UG(B))

### Safety Precautions

Read these Safety Precautions before beginning installation or electrical work, and perform the work only in the correct manner.

Precautions in this manual are given in the form of "Warnings" or "Cautions." Both types of precautions contain important information related to your safety, the safety of users, and the correct operation, installation or maintenance of the air conditioning system. Be sure to carefully observe all relevant precautions.

This symbol refers to a hazard or unsafe practice

which can result in severe personal injury or death.

This symbol refers to a hazard or unsafe practice

which can result in personal injury or product or

CAUTION

property damage.

When installation work is completed, perform a test run and check that no trouble occurs. Also be sure to explain the methods for using the product to



the customer, based on the contents of the Operation Manual. In addition, request that the customer keep and conveniently store the "Information for the Person in Charge of Installation (Electrical) Work and Servicing " together with the Operation Manual.

**WARNING**

Request installation and electrical work only from the dealer or a qualified air conditioning specialist.

Attempting to carry out installation work on your own, and doing so incorrectly, may result in electrical shock, fire, or other hazards.

Installation procedures must be performed correctly, carefully following the instructions in this document.

Failure to do so may result in electrical shock, fire, or other hazards.


Electrical work must be performed by a qualified electrician. It must be performed in accordance with technical standards related to electrical equipment, interior wiring regulations, local codes, and the contents of these instructions. Be sure to use a dedicated power supply circuit.

Insufficient power circuit capacity or improper electrical work may result in electrical shock or fire.

Use only the designated cables for wiring, and connect them securely.

Fasten cables so that no external force is applied to the terminal connections.

Insufficient connections or cable fastening may result in heat generation, fire, or other hazards.



**CAUTION**

Depending on the installation location, it may be necessary to install an earth leakage breaker. Failure to do so may result in electrical shock or fire.

Do not install in kitchens, workshops, or other locations where there is oil mist in the air.

Do not install next to windows or in other locations exposed to direct sunlight or in direct contact with outside air.

Do not install near an elevator, automatic door, industrial sewing machine, or other devices that can be expected to produce electrical noise.

### Accessories for Local Adapter

No.

Supplied parts

Qty.  
Fastening screws,  
Tapping screws 4 x 8

1

Binding strap

2

No.

Supplied parts

Terminals (M3)

4

3

2

### Installing the Local Adapter

<Note 1>



Avoid twisting the inter-unit control wiring or the input/output wiring together with power or other wiring, and avoid running them in the same metal conduit. Doing so can cause malfunction.

11

Install the local adapter at a location away from any sources of electrical noise.

<Note 2>

Install a noise filter or take other appropriate action if electrical noise affects the power supply circuit of the unit.

<Note 3>

7 - 127

Mini ECO-i System





[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1

...

186

187

188

189

Quick Links:

[Address Settings \(Outdoor Units\)](#)

[Remote Controller Test Run Settings](#)

[Alarm Display](#)

[Outdoor Unit Control Pcb](#)

## Chapters

[Table of Contents](#) 4

[Remote Controller Functions](#) 15

[Service Checker](#) 47

[Remote Control Functions](#) 61

[Control System Sha-Kt256Bg](#) 170

[Schedule Timer \(Sha-Tm64Ag\(B\)\)](#) 214

## Related Manuals for Sanyo MINI ECO-i SPW-CR365GXH56B

[Air Conditioner Sanyo ECOi C0705DXHN8 Brochure & Specs](#)

2 and 3 pipe electric vrf systems (10 pages)

[Air Conditioner Sanyo SPW-T253G56 Service Manual](#)

Split system air conditioner (71 pages)

[Air Conditioner Sanyo SPW-X253G56 Service Manual](#)

Split system (72 pages)

[Air Conditioner Sanyo SPW-CR365GXH56 Technical Data Manual](#)

Mini eco-i system (346 pages)

[Air Conditioner Sanyo Mini ECO-i SPW-ASR74GXH56\(A/B\) Installation Instructions Manual](#)

System air conditioner (49 pages)

[Air Conditioner Sanyo SPW-C1155DXHN8 Technical Data & Service Manual](#)

2-way eco-i multi system (242 pages)

[Air Conditioner Sanyo 2-WAY ECO-i SPW-C0705DXHN8 Service Manual](#)

Multi system (143 pages)

[Air Conditioner Sanyo SPW-X253GH56 Service Manual](#)

Split system (105 pages)

[Air Conditioner Sanyo SPW-U253GH56 Service Manual](#)

Split system air conditioner (108 pages)

[Air Conditioner Sanyo SPW-T253GH56 Service Manual](#)

Split system (106 pages)

[Air Conditioner Sanyo SPW-D253GH56 Service Manual](#)

Split system (108 pages)

[Air Conditioner Sanyo SPW-C0705DZH8 Technical Data Manual](#)

3-way eco-i multi system 5 series (703 pages)

[Air Conditioner Sanyo SPW-C483GYH8 Service Manual](#)

Eco multi system (235 pages)

[Air Conditioner Sanyo SPW-C256VH Technical Data & Service Manual](#)

4-way air discharge semi-concealed wall-mounted ceiling-mounted concealed-duct (517 pages)

[Air Conditioner Sanyo SPW-CR1503GDYH8 Technical Data & Service Manual](#)

W-eco multi system series (377 pages)

[Air Conditioner Sanyo SPW-FTR124EH56 Installation And Operation Manual](#)

Dc inverter air conditioner for refrigerant r410a (32 pages)

## Related Content for Sanyo MINI ECO-i SPW-CR365GXH56B

[SPW-XR253GH56 Service Functions Of Remote Controller](#)

Sanyo SPW-XR253GH56

[SPW-CR363GVH8 Service Functions Of Remote Controller](#)

Sanyo SPW-CR363GVH8

[SPW-CR1503GDYH8 Optional Controller](#)

Sanyo SPW-CR1503GDYH8

[Big PACi 18 Series Precautions On Simultaneous Installation Of Wired Remote Controller And Wireless Remote Controller](#)

Sanyo Big PACi 18 Series

[SPW-C483GYH8 Service Functions Of Remote Controller](#)

Sanyo SPW-C483GYH8

[SPW-C0705DZH8 System Controller / Sha-Kc64Agb](#)

Sanyo SPW-C0705DZH8

[SPW-CR365GXH56 System Controller / Sha-Kc64Ag](#)

Sanyo SPW-CR365GXH56

[SPW-C256VH Optional Controller \(Remote Controller\)](#)

Sanyo SPW-C256VH

This manual is also suitable for:

[Mini eco-i spw-cr485gxh56b](#)[Mini eco-i spw-cr605gxh56b](#)[Mini eco-i spw-cr365gx56b](#)[Mini eco-i spw-cr485gx56b](#)[Mini eco-i spw-cr605gx56b](#)[Mini eco-i spw-cr365gxh8b](#) ... [Show all](#)