

Digital Io Port Configuration - Asus AAEON COM-SKHB6 User Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

Table Of Contents

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76

--

•

•

Bookmarks



3.4.7 Digital IO Port Configuration

Options

DIO PORT

Set DIO as In/Out.

Output Level

Set Output level.

Chapter 3 - AMI BIOS Setup

Input

Output

Low

High




Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
44
45
46
47
48
49
50
51

Related Manuals for Asus AAEON COM-SKHB6

[Control Unit Asus AAEON COM-SKUC6 User Manual](#)

Com express module (100 pages)

[Control Unit Asus Aaeon COM-SKUC6 User Manual](#)

Com express module (99 pages)

[Control Unit Asus AAEON COM-WHUC6 User Manual](#)

Com express module (110 pages)

[Control Unit Asus AAEON COM-BYTC2 User Manual](#)

Com express module (91 pages)

[Control Unit Asus AAEON COM-BT-A30 User Manual](#)

Com express module (98 pages)

[Control Unit Asus AAEON COM-TGHB6 User Manual](#)

(88 pages)

[Control Unit Asus AAEON COM-TGUC6 User Manual](#)

Com express module (103 pages)

[Control Unit Asus AAEON COM-ADNC6 User Manual](#)

Com express module (89 pages)

[Control Unit Asus Aaeon NanoCOM-APL User Manual](#)

Com express module (77 pages)

[Control Unit Asus ThunderboltEX 3-TR User Manual](#)

(14 pages)

[Control Unit Asus TPM-SPI Quick Start Manual](#)

14-1 pin (4 pages)

[Control Unit Asus AAEON MXM-ACMA User Manual](#)

(26 pages)

[Control Unit Asus AAEON MIPICSI Camera RVP Converter Kit User Manual](#)

Up expansion module (47 pages)

[Control Unit Asus Aaeon NanoCOM-TGU User Manual](#)

Com express module (95 pages)

[Control Unit Asus AAEON ASDM-L-CFS User Manual](#)

Smart display module (82 pages)

[Control Unit Asus Aaeon NIM-S26B Quick Installation Manual](#)

Network interface module (23 pages)

Related Content for Asus AAEON COM-SKHB6

[AAEON COM-BT-A30 Advanced: Dynamic Digital Io Configuration](#)

Asus AAEON COM-BT-A30

[AAEON COM-ADNC6 Gpio Port Configuration](#)

Asus AAEON COM-ADNC6

[AAEON COM-BYTC2 Advanced: Serial Port Configuration](#)

Asus AAEON COM-BYTC2

[AAEON ASDM-L-CFS Pch-Io Configuration](#)

Asus AAEON ASDM-L-CFS

[AAEON PER-C40L 2.3.1 Sfp Port Connector](#)

Asus AAEON PER-C40L

[AAEON NIM-S13A Sfp 8-Port Connector \(Cn2\)](#)

Asus AAEON NIM-S13A

[AAEON NIM-S26A Sfp+ 10G 4-Port Connector \(Cn4 - Cn7\)](#)

Asus AAEON NIM-S26A

[Aaeon NIM-S26B Qsfp 40G 2-Port Connector \(M1 & M2\)](#)

Asus Aaeon NIM-S26B