Air Discharge Chamber For Top Discharge; Wind Shield For "Cl" Model - Sanyo C2432A Installation Instructions Manual

19	
20	
21	
22	
23	
24	
25	
26	
27	
28	
29	
30	
31	
32	
33	
34	
35	
36	
37	
38	
39	
40	
41	
42	
43	
44	
45	
46	
47	
48 49	
49 50	
20	
-	

Table of Contents

•

Bookmarks

•



2-1. Air Discharge Chamber for Top Discharge


Install the **difficult scheme chamber in the field when**: it is difficult to keep a space of minimum 2 ft. between the air-discharge outlet and the obstacle. the air-discharge outlet is facing the sidewalk and discharged hot air can annoy the passers-by. Refer to Fig. 2-4.

2-2. Wind Shield for "CL" Model

It is recommended to use wind shields for "CL" model (Fig. 2-5). "CL" model is designed to use in low outdoor temperature conditions.


General

When the outdoor unit is installed in a position exposed to strong wind (like seasonal winds with low air



temperature in winter), wind shield must be installed on the outdoor unit.

This unit is q the outdoor unit runs at low speed when the air conditioner is operated at low outdoor air temperatures. When the outdoor unit is exposed to strong wind, the system pressure drops because of the freeze protector. For outer dimensions of wind shield, please see Fig. 2-6. 22-5/16" 23-5/16" CL3032, 3632 Wind shield (air discharge side) Recommended outer Imensions of wind shield (field supply) 11-13/16" 1-7/32" 9-27/32" 5-5/32" 1352_C_I 9 S4359249 Air discharge 0426_C_I Fig. 2-4 Front 0935_C_I Fig. 2-5 21-13/16" 9-27/32" 21-13/16" CL2432 Fig. 2-6 5-5/32" 0936_C_I





Previous Page Next Page

Quick Links: Table of Contents General Indoor Unit Outdoor Unit Remote Control Unit

Related Manuals for Sanyo C2432A

Air Conditioner Sanyo 24KLS32A Specification Sheet Sanyo ductless split system air conditioners specification sheet (3 pages) Air Conditioner Sanyo 24XS32A Submittal Sheet Indoor/outdoor ceiling recessed (4-way) air conditioner (3 pages) Air Conditioner Sanyo XS4232 Technical Data And Service Manual (66 pages) Air Conditioner Sanyo KS2432A Technical Data And Service Manual (64 pages) Air Conditioner Sanyo KS2432A Service Manual Split system (63 pages) Air Conditioner Sanyo KS3032 Service Manual Split system air conditioner (56 pages) Air Conditioner Sanyo C3032 Service Manual Split system air conditioner (54 pages) Air Conditioner Sanyo KS2432 Instruction Manual Split system air conditioner; wall-mounted type ceiling-mounted type recessed type cool/fan model (24 pages) Air Conditioner Sanyo KS2432A Instruction Manual Cool/dry model (24 pages) Air Conditioner Sanyo KS2462R Instruction Manual Sanyo split system air conditioner instruction manual ks2462r (24 pages) Air Conditioner Sanyo KS2432A Instruction Manual (24 pages) Air Conditioner Sanyo KS2432 Instruction Manual Split system air conditioner cool/fan model (24 pages) Air Conditioner Sanyo C2432 Installation Instructions Manual Split system air conditioner (17 pages) Air Conditioner Sanyo 24KS62R Specifications Ductless split system air conditioners (3 pages) Air Conditioner Sanyo 36TS32A Datasheet Ceiling suspended air conditioner (3 pages) Air Conditioner Sanyo KS2432A Instruction Manual (1 page)

Related Content for Sanyo C2432A

ECO-i AHX0752 Rcs-Sh80Aab.wl For 4-Way Air Discharge Semi-Concealed (X Type) Sanyo ECO-i AHX0752 SPW-CR363GVH8 Way Air Discharge Semi-Concealed Type Sanyo SPW-CR363GVH8 SAP-KV94GJ Air Discharge Sanvo SAP-KV94GI SPW-CR1503GDYH8 Way Air Discharge Semi-Concealed Type Sanvo SPW-CR1503GDYH8 Big PACi 18 Series 4-Way Air Discharge Semi-Concealed Type Sanvo Big PACi 18 Series SPW-C256VH Air Discharge Chamber For Top Discharge Sanyo SPW-C256VH SPW-CR365GXH56 Air Discharge Chamber For Top Discharge Sanyo SPW-CR365GXH56 KS2432A Air Discharge Chamber For Top Discharge Sanyo KS2432A

This manual is also suitable for:

Ks2432Ks2432aKs3032Cl2432aXs3632Ts3632 ... Show all