



# Wi-Fi Antennas Installation - Asus TUF GAMING H770-PRO WIFI Manual



1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46

--

•

[Table of Contents](#)

•

## Bookmarks







## 1.6

### Wi-Fi antennas installation

#### Installing the ASUS Wi-Fi antennas

Connect the bundled ASUS Wi-Fi antennas connectors to the Wi-Fi ports at the back of the chassis.

- Ensure that the ASUS Wi-Fi antennas are securely installed to the Wi-Fi ports.

- Ensure that the antennas are at least 20 cm away from all persons.

The illustration above is for reference only. The I/O port layout may vary with models, but the Wi-Fi antennas installation procedure is the same for all models.

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
26  
27  
28  
29  
30  
31  
32  
33

Quick Links:

[Motherboard Overview](#)

[System Memory](#)

[Installation](#)

[Bios Setup Program](#)

## Related Manuals for Asus TUF GAMING H770-PRO WIFI

[Motherboard Asus TUF GAMING H770-PRO WIFI Quick Start Manual](#)

(2 pages)

[Motherboard Asus TUF GAMING H770-PRO WIFI Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H770-PLUS D4 Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H770-PLUS D4 Manual](#)

(38 pages)

[Motherboard Asus H81M-C User Manual](#)

H81m-c user's manual (74 pages)

[Motherboard ASUS H81T User Manual](#)

(73 pages)

[Motherboard Asus H110M-A Manual](#)

(55 pages)

[Motherboard Asus H110-PLUS Manual](#)

(26 pages)

[Motherboard Asus TUF H310-PLUS GAMING Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-A R1.0 Instruction Manual](#)

(29 pages)

[Motherboard Asus H310I-IM-A R2.0 Manual](#)

Industrial motherboard (59 pages)

[Motherboard Asus PRIME H310M-K Manual](#)

(27 pages)

[Motherboard Asus PRIME H410I-PLUS Manual](#)

(30 pages)

[Motherboard Asus PRIME H610M-D Instruction Manual](#)

(31 pages)

[Motherboard Asus PRIME H510M-A R2.0 Manual](#)

(34 pages)

[Motherboard Asus H110M-C/HDMI Manual](#)

(27 pages)

## Related Content for Asus TUF GAMING H770-PRO WIFI

[TUF GAMING B660-PLUS WIFI Wi-Fi Antennas Installation](#)

Asus TUF GAMING B660-PLUS WIFI

[TUF GAMING B660M-PLUS WIFI Wi-Fi Antennas Installation](#)

Asus TUF GAMING B660M-PLUS WIFI

[PRIME B760M-AJ Notices For Non Wi-Fi Model](#)

Asus PRIME B760M-AJ

[Z790-AYW OC WIFI Wi-Fi Moving Antenna Installation](#)

Asus Z790-AYW OC WIFI

[Pro Q670M-CE Notices For Non Wi-Fi Model](#)

Asus Pro Q670M-CE

[PRIME B760M-F D4 Notices For Non Wi-Fi Model](#)

Asus PRIME B760M-F D4

[PRIME A620-PLUS WIFI6 Wi-Fi Moving Antenna Installation](#)

Asus PRIME A620-PLUS WIFI6

[Z790 GAMING WIFI7 Wi-Fi Antenna Installation](#)

Asus Z790 GAMING WIFI7