



Asus MA-25 - Coax To 2.5G Ethernet Adapter Quick Start Guide

Contents

- 1 Your package includes
- 2 A quick look at your MA-25
- 3 LED indications
- 4 Installing your MA-25
 - 4.1 Using MoCA Protected Setup (MPS)
- 5 Using Extended Band D switch
- 6 Documents / Resources
 - 6.1 Download manual

Your package includes

- ASUS MA-25 Coax to Ethernet Adapter
- Ethernet Cable
- Coax Cable
- F-type Male to F-type Male 90° Angle Connector
- Screw and Anchor
- Quick Start Guide

- Warranty Card

A quick look at your MA-25

1. MoCA 2.5 Extended Band D switch
Mode 1(4CH): 1,275 ~ 1,675MHz
Mode 2(5CH): 1,125 ~ 1,625MHz
2. COAX IN F-type Female connector
3. MPS Security button
4. 12VDC DC-IN port
5. RJ-45 port for 2.5Gbase-T Ethernet

LED indications

MoCA LED: MoCA link status

Solid white

MoCA is connected.

Blinking white

MA-25 is transmitting or receiving data via MoCA connection.

ETH LED: Ethernet status

Solid white

MA-25 is connected to Ethernet.

Blinking white

MA-25 is transmitting or receiving data via Ethernet connection.

Security LED: MoCA Security is enabled/ disabled.

Solid white

MoCA security is enabled.

Off

MoCA security is disabled.

Installing your MA-25

MoCA Adapter 1

Connect the MoCA Adapter 1 to your router, Mesh router or modem.

- Router
- Mesh router
- Modem

MoCA Adapter 2

Connect the MoCA Adapter 2 to your Mesh node or devices.

- Mesh node
- PC/Laptop
- Streaming TV
- NAS/NVR

Using MoCA Protected Setup (MPS)

NOTE: If you want to add the MA-25 to an existing MoCA 2.5 Network with different security/privacy settings, MPS is required.

To use MPS:

1. Trigger the MPS pairing mode on any device in the existing MoCA network.
2. Press the MPS button on the MA-25 to join the network.

Using Extended Band D switch

If you are using DOCSIS 3.1 coexisting with the MoCA network, choose Mode 1 to avoid interference; if not, stay on Mode 2.

Documents / Resources

Download manual

Here you can download full pdf version of manual, it may contain additional safety instructions, warranty information, FCC rules, etc.

[Download Asus MA-25 - Coax To 2.5G Ethernet Adapter Quick Start Guide](#)

Need Assistance?

Do you have a question about the MA-25 that isn't answered in the manual? Leave your question here.

■ ■

Stay updated with the latest solutions
Submit your question

Related Manuals for Asus MA-25

[Adapter Asus MW100 User Manual](#)

Wireless smart plug (22 pages)

[Adapter Asus USB-BT500 Quick Start Manual](#)

Bluetooth 5.0 usb adapter (17 pages)

[Adapter Asus 54Mbps User Manual](#)

54mbps usb wireless lan adapter (48 pages)

[Adapter Asus WL-167G V3 User Manual](#)

1-lf-asu 802.11n usb2.0 (13 pages)

[Adapter Asus USB-N10 Nano User Manual](#)

Asus 802.11n network adapter (for 802.11 b/g/n wireless networks) (30 pages)

[Adapter Asus XG-C100C Quick Start Manual](#)

10g pci-e network adapter (2 pages)

[Adapter Asus cs10 Chromebit Quick Start Manual](#)

(16 pages)

[Adapter Asus WL-167g Quick Start Manual](#)

54mbps usb wireless lan adapter (196 pages)

[Adapter Asus USB-N14 User Manual](#)

Dual-band wireless-ac600 usb adapter (26 pages)

[Adapter Asus USB-N14 Quick Start Manual](#)

Wireless n-300 usb adapter (2 pages)

[Adapter Asus USB-BT500 Quick Start Manual](#)

Bluetooth 5.0 usb adapter (48 pages)

[Adapter Asus Vivo DualBay User Manual](#)

(12 pages)

[Adapter Asus USB-BT211 Mini Bluetooth Dongle Quick Start Manual](#)

Mini usb bluetooth adapter (31 pages)

[Adapter Asus PIKE 2308 User Manual](#)

Lsisas raid card (62 pages)

[Adapter Asus PL-E56P Quick Start Manual](#)

1200 mbps wi-fi homeplug av1200 powerline adapter kit (2 pages)

[Adapter Asus EA-N66 Quick Start Manual](#)

Dual-band wireless-n ethernet adapter (45 pages)

[Save Article as PDF](#)