Safety Information - Asus PRIME H770-PLUS D4 Manual

```
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
```

Table of Contents







Safety information Electrical safety To prevent electrical shock hazard, disconnect the power cable from the electrical outlet before relocating the system. When adding or removing devices to or from the system, ensure that the power

for the devices are unplugged before the signal cables are connected. If possible,

disconnect all power cables from the existing system before you add a device.

cables

Before connecting or removing signal cables from the motherboard, ensure that all power

cables are unplugged.

Seek professional assistance before using an adapter or extension cord. These devices

could interrupt the grounding circuit.

Ensure that your power supply is set to the correct voltage in your area. If you are not sure about the voltage of the electrical outlet you are using, contact your local power

company.

If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.

Operation safety

Before installing the motherboard and adding components, carefully read all the manuals

that came with the package.

Before using the product, ensure all cables are correctly connected and the power cables

are not damaged. If you detect any damage, contact your dealer immediately.

To avoid short circuits, keep paper clips, screws, and staples away from connectors,

slots, sockets and circuitry.

Avoid dust, humidity, and temperature extremes. Do not place the product in any area

where it may become wet.

Place the product on a stable surface.

If you encounter technical problems with the product, contact a qualified service technician or your retailer.

Your motherboard should only be used in environments with ambient temperatures

between 0°C and 40°C.

.

Button/Coin Batteries Safety Information

İν

WARNING

KEEP OUT OF REACH OF CHILDREN Swallowing can lead to chemical burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.

Table of Contents

Quick Links:		
Prime H770-Plus D4 Specifications Summa	ary	
Motherboard Overview		
Installation		

Related Manuals for Asus PRIME H770-PLUS D4

Motherboard Asus PRIME H770-PLUS D4 Quick Start Manual

(2 pages)

Motherboard Asus TUF GAMING H770-PRO WIFI Manual

(46 pages)

Motherboard Asus TUF GAMING H770-PRO WIFI Quick Start Manual

(2 pages)

Motherboard Asus TUF GAMING H770-PRO WIFI Quick Start Manual

(2 pages)

Motherboard ASUS H97-PRO GAMER User Manual

(86 pages)

Motherboard Asus H97M-PLUS Manual

(20 pages)

Motherboard Asus h170-pro Manual

(92 pages)

Motherboard Asus H110M-K Instruction Manual

(25 pages)

Motherboard Asus H110M-E D3 Instruction Manual

(55 pages)

Motherboard Asus H81M-CT Manual

(63 pages)

Motherboard Asus Prime H510M User Manual

(34 pages)

Motherboard Asus PRIME H310M-E R2.0 Manual

(28 pages)

Motherboard Asus PRIME H410M-K Manual

(28 pages)

Motherboard Asus H110M-E/M.2 Manual

(26 pages)

Motherboard Asus H110M-C/HDMI Manual

(27 pages)

Motherboard Asus H110M-K X Manual

(27 pages)

Related Content for Asus PRIME H770-PLUS D4

Pro Q670M-CE Safety Information

Asus Pro Q670M-CE

Pro Q670M-CE D4 Safety Information

Asus Pro Q670M-CE D4

PRIME B760M-F D4 Safety Information

Asus PRIME B760M-F D4

PRIME A620-PLUS WIFI6 Safety Information

Asus PRIME A620-PLUS WIFI6

Z790 GAMING WIFI7 Safety Information

Asus Z790 GAMING WIFI7

PRIME X299-A Series Safety Information

Asus PRIME X299-A Series

A620M-AYW WIFI Safety Information

Asus A620M-AYW WIFI

PRIME H610T2-CSM D4 Safety Information

Asus PRIME H610T2-CSM D4