

Dimensions Of Air-Discharge Chamber; Dimensions Of Outdoor Unit With Air-Discharge Chamber (Field Supply) - Sanyo Mini ECO-i SPW-ASR74GXH56(A/B) Installation Instructions Manual

System air conditioner

1

2

3

4

5

Table Of Contents

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49

•

[Table of Contents](#)

•

Bookmarks



05-194
5/27/05
5:06 PM

2-6. Dimensions of Air-Discharge Chamber

Reference diagram for air-discharge chamber (field supply)
STK-DRE140A for SPW-CR365/485/605GX(H)56


- 1
Unit front, air discharge chamber
- 2
Unit left side, air discharge chamber
- 3
Unit right side, air discharge chamber
- 4
Reinforcement brackets, 4 locations






2-7. Dimensions of Outdoor Unit with Air-Discharge Chamber (field supply)

SPW-CR365/485/605GX(H)56 with STK-DRE140A

68
Wind
direction
Wind



direction
 Page 20
 2
 29.5
 240
 Rectangular
 hole
 Rectangular
 hole
 25
 170
 660
 Wind direction
 13
 13
 544
 940
 Wind
 direction
 Wind
 direction
 3
 4
 1
 569
 544
 25
 110
 13
 300
 Wind direction
20
 240
 29.5
 Rectangular
 hole
 Rectangular
 hole
 Unit: mm
 Wind direction
 Unit: mm



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
17
18
19
20
21
22
23
24

Quick Links:

[Important](#)

[Table of Contents](#)

[General](#)

[Indoor Unit](#)

[Outdoor Unit](#)

[Meaning of Alarm Messages](#)

Related Manuals for Sanyo Mini ECO-i SPW-ASR74GXH56(A/B)

[Air Conditioner Sanyo SPW-CR365GXH56 Technical Data Manual](#)

Mini eco-i system (346 pages)

[Air Conditioner Sanyo SPW-X483GH56 Installation Instruction](#)

Eco multi system air conditioner (91 pages)

[Air Conditioner Sanyo 2-WAY ECO-i SPW-C0705DXHN8 Service Manual](#)

Multi system (143 pages)

[Air Conditioner Sanyo PW-UMR184EXH56 Installation And Operation](#)

[Manual](#)

Eco-i system air conditioner (36 pages)

[Air Conditioner Sanyo ECO G SGP-EGW190M2G2W Brochure & Specs](#)

Gas driven vrf m series (9 pages)

[Air Conditioner Sanyo SPW-C1155DXHN8 Technical Data & Service Manual](#)

2-way eco-i multi system (242 pages)

[Air Conditioner Sanyo ECOi C0705DXHN8 Brochure & Specs](#)

2 and 3 pipe electric vrf systems (10 pages)

[Air Conditioner Sanyo MINI ECO-i SPW-CR365GXH56B Service Manual](#)
(252 pages)

[Air Conditioner Sanyo SPW-X253G56 Service Manual](#)

Split system (72 pages)

[Air Conditioner Sanyo SPW-X253GH56 Service Manual](#)

Split system (105 pages)

[Air Conditioner Sanyo SPW-T253GH56 Service Manual](#)

Split system (106 pages)

[Air Conditioner Sanyo SPW-D253GH56 Service Manual](#)

Split system (108 pages)

[Air Conditioner Sanyo SPW-C483GYH8 Service Manual](#)

Eco multi system (235 pages)

[Air Conditioner Sanyo Big PACi 18 Series Technical Data & Service Manual](#)

Big pack i dc inverter (275 pages)

[Air Conditioner Sanyo SPW-CR1503GDYH8 Technical Data & Service Manual](#)

W-eco multi system series (377 pages)

[Air Conditioner Sanyo SPW-XR254EH56 Installation And Operation Manual](#)

Dc inverter air conditioner (40 pages)

Related Content for Sanyo Mini ECO-i SPW-ASR74GXH56(A/B)

[ECO-i AHX0752 Rcs-Sh80Aab.wl For 4-Way Air Discharge Semi-Concealed \(X Type\)](#)

Sanyo ECO-i AHX0752

[SPW-CR363GVH8 Way Air Discharge Semi-Concealed Type](#)

Sanyo SPW-CR363GVH8

[SAP-KV94GJ Air Discharge](#)

Sanyo SAP-KV94GJ

[SPW-CR1503GDYH8 Way Air Discharge Semi-Concealed Type](#)

Sanyo SPW-CR1503GDYH8

[Big PACi 18 Series 4-Way Air Discharge Semi-Concealed Type](#)

Sanyo Big PACi 18 Series

[SPW-C256VH Dimensions Of Air-Discharge Chamber](#)

Sanyo SPW-C256VH

[SPW-CR365GXH56 Dimensions Of Air-Discharge Chamber Reference Diagram For Air-Discharge Chamber \(Field Supply\) Stk-Dre140A For Spw-Cr365/485/605Gx\(H\)56\(A/B\)](#)

Sanyo SPW-CR365GXH56

[KS2432A Air Discharge Chamber For Top Discharge](#)

Sanyo KS2432A

This manual is also suitable for:

[Mini eco-i spw-asr94gXH56\(a/b\)](#)[Mini eco-i spw-asr124gXH56\(a/b\)](#)[Mini eco-i spw-ldr94gXH56\(a/b\)](#)[Mini eco-i spw-ldr124gXH56\(a/b\)](#)[Mini eco-i spw-ldr184gXH56\(a/b\)](#)[Mini eco-i spw-ldr254gXH56\(a/b\)](#) ... [Show all](#)