



Asus Pro WS W480-ACE - LGA 1200 ATX Intel Motherboard Quick Start

Contents

1 Motherboard Layout

2 Step 1 - Install the CPU

3 Step 2 - Install the CPU fan

4 Step 3 - Install memory modules

5 Step 4 - Install storage devices

5.1 M.2 devices

5.2 SATA devices

6 Step 5 - Install expansion card(s)

7 Step 6 - Install system panel connectors

8 Step 7 - Install ATX power connectors

9 Step 8 - Connect input/output devices

10 Step 9 - Power on the system and install operating system and drivers

11 Documents / Resources

11.1 References

11.2 Download manual

Motherboard Layout

Step 1 - Install the CPU

Step 2 - Install the CPU fan

Step 3 - Install memory modules

Step 4 - Install storage devices

M.2 devices

SATA devices

Step 5 - Install expansion card(s)

Step 6 - Install system panel connectors

Step 7 - Install ATX power connectors

Step 8 - Connect input/output devices

Step 9 - Power on the system and install operating system and drivers

<http://www.asus.com/support/>

Documents / Resources

References

[Official Support | ASUS Global](#)

Download manual

Here you can download full pdf version of manual, it may contain additional safety instructions, warranty information, FCC rules, etc.

[Download Asus Pro WS W480-ACE - LGA 1200 ATX Intel Motherboard Quick Start](#)

Need Assistance?

Do you have a question about the Pro WS W480-ACE that isn't answered in the manual?

Leave your question here.



Stay updated with the latest solutions

Submit your question

Related Manuals for Asus Pro WS W480-ACE

[Asus PRIME H610M-CS D4 - Motherboard Quick Start Guide](#)

(article)

[Asus EX-H610M-V3 D4 - Motherboard Quick Start Guide](#)

(article)

[Asus A320M-C - Motherboard Manual](#)

(article)

[Asus A55BM-E - Motherboard Manual](#)

(article)

[Asus A58M-E - Motherboard Manual](#)

(article)

[Asus A55BM-K - Motherboard Manual](#)

(article)

[Motherboard Asus 90MB1310-M0EAY0 Manual](#)

(72 pages)

[Motherboard Asus WS C246M PRO Manual](#)

(126 pages)

[Motherboard Asus WS C246 PRO Manual](#)

(102 pages)

[Motherboard Asus WS C246 DC User Manual](#)

(96 pages)

[Motherboard Asus WS Z390 PRO Manual](#)

(120 pages)

[Motherboard Asus Pro WS 621-64L SAGE Series Manual](#)

(130 pages)

[Motherboard Asus WS C422 DC Manual](#)

(104 pages)

[Motherboard Asus WS X299 PRO Series Manual](#)

(142 pages)

[Motherboard Asus WS C422 PRO/SE Manual](#)

(128 pages)

[Motherboard Asus WS C422 PRO Manual](#)

(128 pages)

[Motherboard Asus WS C621E SAGE Series Manual](#)

(122 pages)

[Motherboard Asus Pro WS W680-ACE User Manual](#)

(86 pages)

[Motherboard Asus Z790 GAMING WIFI7 Manual](#)

(70 pages)

[Motherboard Asus WS X299 SAGE Manual](#)

(126 pages)

[Save Article as PDF](#)