



# Toshiba RC-10JRNH Instruction Manual

Toshiba mechanical rice cooker / warmer



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16

• PAGE

1



- 

[Table of Contents](#)

- 

Troubleshooting

•

## Bookmarks

[Download this manual](#)

## Quick Links





Toshiba Mechanical Rice Cooker / Warmer

# Instruction Manual

Model

1.0L Type

RC-10JRNH

1.8L Type

RC-18JRNH

**TOSHIBA**



Thank you for purchasing Toshiba rice cooker. All pictures in this manual are



subject to material objects, and are only used for function display reference. Please read the instruction manual and use it correctly for your own safety.

● Before using, please read "Safeguards" and "Please follow the instructions". After reading, please keep the instruction manual at a place where any person

● **TOSHIBA** who is going to use this cooker can find and see it.

For household use

## Contents



<a href="#">IMPORTANT SAFEGUARDS</a> .....	1
<a href="#">PRODUCT SPECIFICATION</a> .....	2
<a href="#">GETTING STARTED</a> .....	3
<a href="#">OPERATION INSTRUCTIONS</a> .....	4
<a href="#">PRECAUTIONS</a> .....	5
<a href="#">TROUBLE SHOOTING</a> .....	6

[Next Page](#)

1  
2  
3  
4  
5

# Chapters

English 1

□□ 9

## Related Manuals for Toshiba RC-10JRNH

[Rice Cooker Toshiba RC-10NMF Instruction Manual](#)

Electric rice cooker/warmer (13 pages)

[Rice Cooker Toshiba RC-10NMF Instruction Manual](#)

Electric rice cooker/warmer (13 pages)

[Toshiba RC-10NMF, RC-18NMF, RC-10NMF, RC-18NMF, RC-10NMF, RC-18NMF - Toshiba Electric Rice Cooker/Warmer Manual](#)

(article)

[Rice Cooker Toshiba RC-10NMF Instruction Manual](#)

Electric rice cooker/warmer (17 pages)

[Rice Cooker Toshiba RC-10RHI Instruction Manual](#)

Electric rice cooker/warmer (13 pages)

[Rice Cooker Toshiba RC-10JR1NP Instruction Manual](#)

Mechanical rice cooker / warmer, 1.0l/1.8l type (8 pages)

[Rice Cooker Toshiba RC-18DR1NMY Instruction Manual](#)

Electric rice cooker (23 pages)

[Toshiba RC-18DR1NMY, RC-10DH1NMY, RC-18DH1NMY - ELECTRIC RICE COOKER Manual](#)

(article)

[Rice Cooker Toshiba RC-10NAF Series Instruction Manual](#)

Electric rice cooker/warmer (24 pages)

[Rice Cooker Toshiba RC-10IRPH Instruction Manual](#)

Microcomputer induction rice cooker (55 pages)

[Rice Cooker Toshiba RC-10IRPMY Instruction Manual](#)

(14 pages)

[Toshiba RC-10IRPMY - 1.0L Microcomputer Induction Rice Cooker Manual](#)

(article)

[Rice Cooker Toshiba RC-10ISSHK User Manual](#)

Electric rice cooker (58 pages)

[Rice Cooker Toshiba RC-10IH1TAU\(N\) User Manual](#)

Electric rice cooker (23 pages)

[Rice Cooker Toshiba RC-18DH1NP Instruction Manual](#)

Electric rice cooker/warmer (20 pages)

[Rice Cooker Toshiba RC-18ISPH Manual](#)

(28 pages)

# Summary of Contents for Toshiba RC-10JRNH

## [Page 1: Table Of Contents](#)

OPERATION INSTRUCTIONS.... 4 PRECAUTIONS .....5 TROUBLE SHOOTING ..... 6 Thank you for purchasing Toshiba rice cooker.All pictures in this manual are ● subject to material objects,and are only used for function display reference. Please read the instruction manual and use it correctly for your own safety.

## [Page 2: Important Safeguards](#)

IMPORTANT SAFEGUARDS When using electrical appliances, basic safety Caution precautions should be followed including the following: 1. This appliance is not - farm houses; intended for use by - by clients in hotels, persons (including motels and other children) with reduced residential type physical, sensory or environments;...

## [Page 3: Product Specification](#)

PRODUCT SPECIFICATION Thank you for purchasing the TOSHIBA rice cooker, please read this instruction manual carefully before using. Keep it cautiously after reading for future reference. At first use, there might be an odor from plastic, etc. This odor will disappear after using .

## [Page 4: Getting Started](#)

GETTING STARTED 1. Before using the appliance for the first time, clean the parts of the rice cooker thoroughly. Make sure all the parts are completely dry before you start using the appliance. 2. To prevent the damage of the non-stick coating in the inner pot, use a separate container to wash the rice.

[Page 5](#) Cooking The "WARM" lamp is illuminated after plugging into the outlet. The Rice Cooker are entering the cooking process until you have pressed the "COOK". Otherwise, the Rice Cooker will still in warming process (Please be sure that you have pressed the "Cooking"...

## [Page 6: Precautions](#)

PRECAUTIONS The inner pot cannot be heated on any other furnace, otherwise it can be deformed easily . The cooked rice start to keep warm, it is not suitable for eating immediately and it will more soft and delicious if let it stewing for 15 minutes.

## [Page 7: Trouble Shooting](#)

TROUBLE SHOOTING Malfunction Causes Solution Inspect whether the switch, plug and socket Circuit of electric rice cooker is Heating plate is connector, fuse and leading wire of power supply not connected to power supply. not hot. are in good condition and insert the plug reliably The light 1.

[Page 8](#) All the contents in this material have been subjected to carefully check. For any mistake and omission in printing or misunderstanding the contents, the TOSHIBA keeps the right of interpretation.

[Page 9](#) 1.0L RC-10JRNH 1.8L RC-18JRNH 1. 2. 3. 4. 5. 6. ● ●...

## [Page 10: 1. 2. 3. 4. 5. 6.](#)

1. 3. 4. 5. 6.

## [Page 11: \(kg\) \(mm\) 500-595 RC-10JRNH 1-5.5 255\\*240\\*254 220-240V~ 50/60Hz 650-774 RC-18JRNH](#)

"RC" RC-10JRNH 1-5.5 255\*240\*254 220-240V~ 50/60Hz 650-774 RC-18JRNH

**Page 12:**

1. 2. 3. 4. 5. 6. 7. 8. 9. 0.18 150 • 3

**Page 13:**

“WARM” “COOK” “COOK” 15 “WARM” “COOK”

**Page 14:**

15 12 \*

**Page 15:**

1. 2. 1. 2. 1. 1. 2. 2. 4. 4. 5. 5. 1. 2. 3.

**Page 16**

...

This manual is also suitable for:

Rc-18jrnH