

Bios Menu Screen - Asus Pro H410T Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17


18
19
20
21
22
23
24
25
26
27
28

•

•

Bookmarks

--



•
•
•
•

2.2

BIOS menu screen

Menu bar

Main

BIOS Information

BIOS Version



Build Date and Time
ME Firmware Version
PCH Stepping
Processor Information
Brand String
CPU Speed
Total Memory
Memory Frequency

System Date
System Time
Access Level
Security

Sub-menu item

2-2

The BIOS Setup screens shown in this section are for reference purposes only, and may not exactly match what you see on your screen.

Visit the ASUS website at www.asus.com to download the latest BIOS file for this motherboard.

If the system becomes unstable after changing any BIOS setting, load the default settings to ensure system compatibility and stability. Select the Load Optimized Defaults item under the Exit menu or press hotkey F5.

If the system fails to boot after changing any BIOS setting, try to clear the CMOS and reset the motherboard to the default value. See section Motherboard overview for information on how to erase the RTC RAM.

0401 x64
07/07/2020
14.5.11.1105
A0
Intel(R) Core(TM)
i7-10700K @ 3.80GHz
3800 MHz
4096MB
2133MHz

[Wed 03/18/2020]

[21:25:25]

Administrator



Configuration fields
Menu items

Choose the system default
language



Enter: Select
+/-: Change Opt.

F1:

F2:

F5:

F10: Save & Exit

ESC: Exit

Chapter 2: BIOS Information

General Help

: Select Screen

:

Select Item

General Help

Previous Values

Optimized Defaults

Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
17
18
19
20
21
22
23
24

Related Manuals for Asus Pro H410T

[Motherboard Asus Pro H410T Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRO H310M-R R2.0 WI-FI Manual](#)

(27 pages)

[Motherboard Asus PRO H310M-R R2.0 WI-FI/CSM Quick Start Manual](#)

(2 pages)

[Motherboard Asus Pro H410M-C Manual](#)

(30 pages)

[Motherboard Asus Pro H610M-C Manual](#)

(32 pages)

[Motherboard Asus Pro H510M-C Manual](#)

(32 pages)

[Motherboard Asus Pro H610T Manual](#)

(32 pages)

[Motherboard Asus P8Z68-V PRO/GEN3 Manual](#)

Fully pci-express 3.0 ready, intel z68 motherboard. (146 pages)

[Motherboard ASUS M4A89GTD PRO Series User Manual](#)

M4a89gtd pro series (132 pages)

[Motherboard Asus Pro Q470M-C Manual](#)

(30 pages)

[Motherboard Asus Pro Q670M-C Manual](#)

(34 pages)

[Motherboard Asus Pro A520M-C Manual](#)

(28 pages)

[Motherboard Asus Pro B660M-C D4 Manual](#)

(34 pages)

[Motherboard Asus PRO A320M-R WI-FI Instructions Manual](#)

(28 pages)

[Motherboard Asus Pro Q570M-C Manual](#)

(32 pages)

[Motherboard Asus Pro A520M-C II Manual](#)

(30 pages)

Related Content for Asus Pro H410T

[P5KPL-E Bios Menu Screen](#)

Asus P5KPL-E

[PRIME H510T2-CSM R2.0 Bios Menu Screen](#)

Asus PRIME H510T2-CSM R2.0

[B250M-C PRO Bios Menu Screen](#)

Asus B250M-C PRO

[PRIME H610M-C/PS D4 Bios Menu Screen](#)

Asus PRIME H610M-C/PS D4

[Pro A520M-C II Bios Menu Screen](#)

Asus Pro A520M-C II

[Pro Q570M-C Bios Menu Screen](#)

Asus Pro Q570M-C

[Pro B760M-C Bios Menu Screen](#)

Asus Pro B760M-C

[WS C621E SAGE Series Bios Menu Screen](#)

Asus WS C621E SAGE Series

This manual is also suitable for:

[Pro h410t/csm90mb1580-m0eayc](#)