

TOSHIBA

Toshiba TWP-N1861UUFKW Instruction Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18


19
20
21
22

•

Bookmarks

[Download this manual](#)

Quick Links



TOSHIBA

IF

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba TWP-N1861UUFKW

[Water Filtration Systems Toshiba TWP-N1890UK\(W\) Instruction Manual](#)

(30 pages)

[Water Filtration Systems Toshiba TWP-TSR76THK Instruction Manual](#)

Ro tabletop water purifier (28 pages)

[Water Filtration Systems Toshiba TWP-TSR75SHKW Instruction Manual](#)

Ro tabletop water purifier (14 pages)

Summary of Contents for Toshiba TWP-N1861UUFKW

[Page 12](#) Instruction Manual Water Purifier TWP-N1861UUFK(W) Please read the manual carefully before operating the water purifier. Retain it for future reference.

Page 13	1. Safety Instruction-----	
	1-1 Safety Instructions-----	1-2
	Packing List-----	4
	Introduction-----	4
		2-1 Name of parts-
		2-2 Water treatment process
	diagram-----	2-3 How to use-----
		3. Cleaning and maintenance-----
		3-1 Trouble shooting -----
		3-2 Maintenance steps-----
		4. Filter introduction-----
	4-1 Filter introduction-----	8
	4-2 Filter change-----	9

[Page 14](#) 1-1 Safety Instructions parts It may cause damage to the purifier.

[Page 15](#) damage.

[Page 16](#) °C liter...

[Page 17: Product Introduction](#)

1-2 Packing List Water Purifier Instruction Faucet adapter 1/4 PE pipe (1set) Manual(1 copy) (optional) (1PC) (3m) Packing box Inlet ball Snap ring(8PC) Faucet(1PC) valve(1PC) 2. Product Introduction 2-1 Name of parts Top cover Filter Main engine 2-2 Water treatment process diagram Tap water connection Drinking water outlet Integral composite liter...

[Page 18](#) 2-3 How to use Notes: The installation shall be conducted by professional in local sell on commission and service site. Installation 1. Take out the product from packaging box and 2. Take the three-way ball valve out put it under water groove in the kitchen. and install it on tap pipe.

[Page 19: Cleaning And Maintenance](#)

First use instruction Cautions Installation shall be carried out by professionals from local sell on commission and service site. The installation master shall install, use and debug the whole machine according to the maintenance procedures. Starting up 1. Open the three-way ball valve. 2.

[Page 20](#) Issues Reason Trouble shooting The liter is blocked. □ The liter need washing or exchanging □ Water yield decreases The liter is not be exchanged in time, □ The liter need exchanging abnormally □ then out of services Not opening the ball valve completely □...

[Page 21](#) 5. Change the liter. If liter needs to be changed, 6. Connect to water source to make

product ask for users' suggestions rstly. out ow water normally. Check whether there are water leak in each connections with dry tissue. Tissue 7.

[Page 22: Technical Parameters](#)

4-2 Filter change 1. First close three-way ball valve. 2. Open top cover and take out the lter, then change it and press it tightly, nally put top cover back. Close water inlet ball valet 5. Technical Parameters 5-1 Basic parameter TWP-N1861UUFK(W) Model Rated quantity of pure...

This manual is also suitable for:

[Twp-n1861uufk](#)