



Sanyo Moonlight RMT-U100 Manual and Code List

Contents

- 1 TO THE OWNER
- 2 Installing The Batteries
- 3 OPERATING KEYS LOCATIONS
- 4 OPERATING KEYS DESCRIPTIONS
- 5 PROGRAMMING THE REMOTE
- 6 VCR Codes Chart
- 7 TV Codes Chart
- 8 Cable Converter Box Codes Chart
- 9 Special Operating Conditions
- 10 Operating Tips and Troubleshooting Hints
- 11 Documents / Resources
 - 11.1 [Download manual](#)

TO THE OWNER

Welcome to the World of Sanyo

You made an excellent choice for Performance, Reliability, Value, and Styling.

The RMT-U100 replaces three separate remote controls. This simplifies the operation of your home entertainment system. This remote will operate your Video Cassette Recorder, Television, and

Cable Converter Box. Simply program it according to the directions in this owner's manual. Then press the proper function key (*VCR*, *TV*, or *CABLE*) to operate each product.

The Sanyo Universal Remote Control features large glow-in-the-dark basic operating keys. It also has function keys that light when a key is pressed. This indicates the active mode. You never need to wonder which component the remote is controlling. Just observe which mode key lights. That's the answer.

The RMT-U100 universal remote control comes with keys that are preset to operate your Video Cassette Recorder, regardless of the mode you have selected.

BEFORE YOU BEGIN

Installing The Batteries

1. Remove the battery cover by pressing the tab and tilting the cover upward.
2. Install two AA batteries as shown. Be sure to match the / signs on the batteries with the / marks inside the case.



Note: Do Not mix new and used batteries or mix different types of batteries together.

SPENT OR DISCHARGED BATTERIES MUST BE RECYCLED OR DISPOSED OF PROPERLY IN COMPLIANCE WITH ALL APPLICABLE LAWS. FOR DETAILED INFORMATION, CONTACT YOUR LOCAL COUNTY SOLID WASTE AUTHORITY.

OPERATING KEYS LOCATIONS

Keys on this remote control operate functions similar to those on your original remote controls. For specific key operation, such as *Recall* or *Display*, refer to the original owner's manuals for your equipment.

OPERATING KEYS DESCRIPTIONS

1. Mode Keys - Use these keys to program the remote and to select the operating mode (VCR, TV, or CABLE).
2. Video Mode Key - In the TV mode, this key selects the program source: TV or A/V jacks. In VCR mode, this key functions as the TV/VCR key. This key has no function in Cable mode.
3. Number Keys - Use these keys to directly select channels on your VCR, TV, or Cable Converter Box.
4. Recall Key - Press to switch between two channels.
5. Menu Key - Use this key with the  and  keys to adjust the features of a Sanyo TV on - screen menu system.
6. Mute Key - Press once to turn off the volume. Press again to restore the volume.
7. VCR Keys - These keys control Fast Forward (FF), Rewind (REW), Play, Record, Stop, and Pause functions of your VCR. They operate in all three modes.
8. Reset Key - Press this key twice to restore factory settings on

a Sanyo TV.

9. Sleep Key - Use this key to set the Sleep Timer on your TV.
10. Caption Key - Press to select the caption mode: OFF, C1, C2, T1, T2 or QUIKCAP on a Sanyo TV.
11. Channel () and Volume () Keys - Press to scan through the channels and to adjust the volume.
12. Display Key - Press to display the Channel Number on the Screen.

PROGRAMMING THE REMOTE

1. Find your equipment's brand codes in the charts. After programming is confirmed, enter codes in spaces provided on back of remote and below.
2. Press and hold the *VCR*, *TV* or *CABLE* key while entering the two-digit code number. The mode key will flash 5 times.
3. Repeat Step 2 for each piece of equipment you have (VCR, TV, and/or Cable Converter Box).

If you enter an incorrect code number, repeat Step 2.

After entering a code number check the Power and Channel operation. If these functions operate properly, programming is complete. If not, reprogram using another code if available.

VCR Codes Chart

TV Codes Chart

Cable Converter Box Codes Chart

Special Operating Conditions

- The *Caption*, *Menu*, and *Reset* keys will operate only Sanyo televisions. This is true even when you program the remote to operate another brand of TV or when you select the VCR or Cable mode.
- The *Display*, *Sleep*, *Vol+*, *Vol-*, *Mute* and *Recall* keys operate TV functions regardless of the mode selected.
- The *Video* key has no function in the Cable mode.
- The *Recall* key has no function in the VCR and Cable modes.
- Refer to the original owner's manual for specific operation of certain functions, such as; *Sleep* and *Recall*.

Operating Tips and Troubleshooting Hints

- To operate each product (VCR, TV, or Cable Box), you must first press the proper mode key (*VCR*, *TV*, or *CABLE*).
- Some manufacturers use different types of remote controls. If your brand lists several codes, try the code listed first. If necessary, reprogram with each number until you find the correct code.
- There may be VCRs, TVs, and Cable Boxes that this remote cannot operate and some models may operate only partially.
- The remote control must be reprogrammed after batteries are replaced.
- Remove the batteries if the remote will not be used for a month or more. Weak batteries may leak, causing damage to the remote control. (Normal battery life is roughly six months.)
- This remote control uses an invisible (infrared) light beam to operate the equipment. Objects between the VCR, TV, or Cable Converter Box and the remote can block this light beam. Therefore, the remote control must be pointed directly at the front of the VCR, TV or Cable Converter Box.
- This remote control cannot add features to your equipment. They must have been originally provided by your manufacturer.
- If the remote fails to operate any of your equipment replace the batteries. Be sure they are installed correctly.

If you have any questions please call toll-free 1-800-877-5032

Documents / Resources

Download manual

Here you can download full pdf version of manual, it may contain additional safety instructions, warranty information, FCC rules, etc.

[Download Sanyo Moonlight RMT-U100 Manual and Code List](#)

Need Assistance?

Do you have a question about the RMT-U100 Moonlight that isn't answered in the manual? Leave your question here.

■ ■

Stay updated with the latest solutions
Submit your question

Related Manuals for Sanyo RMT-U100 Moonlight

[Sanyo Moonlight RMT-U110 - Multimedia Remote Control Manual](#)

(article)

[Sanyo RMT-U230 - 6-Function Backlit Multimedia Remote Control Manual](#)

(article)

[Remote Control Sanyo RMT-U100 Moonlight Owner's Manual](#)

Sanyo universal remote owner's manual (2 pages)

[Remote Control SANYO RMT-U340 Owner's Manual](#)

6-function multimedia remote control (2 pages)

[Remote Control Sanyo RMT-U340 Owner's Manual](#)

6-function multimedia remote control (2 pages)

[Remote Control Sanyo RMT-U340A Owner's Manual](#)

6-function multimedia remote control (2 pages)

[Remote Control SANYO Moonlight RMT-U110 Owner's Manual](#)

Multimedia remote control (2 pages)

[Remote Control SANYO Glow Keys RMT-U130 Owner's Manual](#)

3-function multimedia remote control (2 pages)

[Remote Control SANYO Starlight RMT-U220 Owner's Manual](#)

Multimedia remote control (2 pages)

[Remote Control SANYO RMT-U230 Owner's Manual](#)

6-function backlit multimedia remote control (2 pages)

[Remote Control Sanyo RMT-U200 Owner's Manual](#)

(5 pages)

[Remote Control Sanyo RCS-TM80BG Instruction Manual](#)

(17 pages)

[Remote Control Sanyo RCS KR1 EG Instruction Manual](#)

Control system for spw air conditioner system's (8 pages)

[Remote Control Sanyo RCS-KR1EG Installation Manual](#)

Sanyo remote controller installation manual (2 pages)

[Remote Control Sanyo STK-RCS-7TWSUA Technical & Service Manual](#)

Sanyo wired remote controller technical & service manual (29 pages)

[Remote Control Sanyo VSP-8500 Instruction Manual](#)

System controller (56 pages)

[Remote Control Sanyo RCS-KR1EG Instruction Manual](#)

Simplified remote controller for split system air conditioner (2 pages)

[Remote Control Sanyo ECO-i RCS-TM80BG Datasheet](#)

Standard wired remote: for use on all eco-i indoor units (1 page)

[Remote Control Sanyo RCS-KR1EG Instruction Manual](#)

Simplified remote controller for split system air conditioner (2 pages)

[Remote Control Sanyo RCS-KS2432AWD Installation Instructions](#)

(4 pages)