

Supported File Formats For Usb Mode; Video File Formats; Picture File Formats; Audio File Formats - Toshiba 24 WD2A Series Operating Instructions Manual

1
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45

--

•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



Supported File Formats for USB Mode

Video File Formats

Extension		
.mpg, .mpeg, .dat, .vob		
.ts, .trp, .m2ts		
.avi		
.m4, .m4a, .m4v, .mov, .qt,		
.3gp, .3g2, .3gpp		
.mkv		
.flv		
.ogm, .ogg		
.asf, .wmv		

.rm, rmvb		
.wm		
.m		
MP		
.ts,		
Baseline		
.jpg, .jpeg		
Progressive		
RGB 1/4/8/16/24/32 bit		
.bmp		
RLE 4/8 bit		
Grayscale, 24/32 bit per pixel		
.png		
Interlace format		
Progressive		
Lossy compression VP8 key frame version number support 0~3		
.webp		
Lossless compression		

ension
rmat

.m		
.m		
.ac3		
.ac3		
.aac		
.AAC		
.wma		
.WMA		
.amr		
.AMR-NB, .AMR-WB		
.wav		
. MPEG La, .AAC, .PCM		
.flac		
. FLAC		

MPEG1/2, H.264, VC1		
MP		
MP		
MP		

Sorenson Sp. MPEG4, H.264

MP

MP

RV

VP

HE

English - 28 -

H.264: 1080Px2@30fps - 50Mbps, 1080P@60fps

50Mbps Other: 1080P@60fps - 50Mbps

8192 x 8192

3000 x 3000

8192 x 8192

(**) Limited Models Only

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
26
27
28
29
30
31
32
33

Quick Links:

[Table of Contents](#)

[Tv Control Switch & Operation](#)

[Remote Control](#)

[Troubleshooting & Tips](#)

Troubleshooting

[Teletext Services](#) 27

[Connecting Bluetooth Devices \(**\)](#) 33

[DVD Troubleshooting](#) 42

Related Manuals for Toshiba 24 WD2A Series

[LCD TV Toshiba 32 LK3A Series Operating Instructions Manual](#)

(38 pages)

[LCD TV Toshiba 24 LL Series Operating Instructions Manual](#)

(37 pages)

[LCD TV Toshiba 39L28 Series Operating Instructions Manual](#)

(37 pages)

[TV Toshiba 32 L28 Series Quick Start Manual](#)

(9 pages)

[LCD TV Toshiba 40L28 Series Operating Instructions Manual](#)

(37 pages)

[LCD TV Toshiba 24 L28 Series Operating Instructions Manual](#)

(37 pages)

[LCD TV Toshiba 32W2863DA Operating Instructions Manual](#)

(36 pages)

[TV Toshiba 24D153*D Quick Start Manual](#)

Led backlight lcd tv (116 pages)

[TV Toshiba 24D1633DB Operating Instructions Manual](#)

With remote control (12 pages)

[TV Toshiba 24W3753DB Operating Instructions Manual](#)

Colour television with remote control (37 pages)

[TV Toshiba 24 WN3D Series Operating Instructions Manual](#)

(47 pages)

[TV Toshiba 24W1753DB Operating Instructions Manual](#)

Colour television with remote control (29 pages)

[TV Toshiba 49L1763DA Operating Instructions Manual](#)

Colour television with remote control (31 pages)

[TV Toshiba 24/32 WL2C Series Operating Instructions Manual](#)

(50 pages)

[TV Toshiba 32/42/43 L21 Series Operating Instructions Manual](#)

(52 pages)

[TV Toshiba 24WL3A63DB Quick Start Manual](#)

(16 pages)

Related Content for Toshiba 24 WD2A Series

[50UA2063DG Supported File Formats For Usb Mode](#)

Toshiba 50UA2063DG

[32W1863DG Supported File Formats For Usb Mode](#)

Toshiba 32W1863DG

[42 L21 Series Supported File Formats For Usb Mode](#)

Toshiba 42 L21 Series

[32 LA3E Series Supported File Formats For Usb Mode](#)

Toshiba 32 LA3E Series

[43 QG5E Series Supported File Formats For Usb Mode](#)

Toshiba 43 QG5E Series

[43UA6B63DA Supported File Formats For Usb Mode](#)

Toshiba 43UA6B63DA

[WA3B63DG Supported File Formats For Usb Mode](#)

Toshiba WA3B63DG

[24 WN3D Series Supported File Formats For Usb Mode](#)

Toshiba 24 WN3D Series

This manual is also suitable for:

[32 wd2a series24 wl2a series24 wk3a series32 wk3a series32 lk3a series32 ll2b series](#) ... [Show all](#)