

TOSHIBA

Toshiba KT-15DRRH User Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18



•

Bookmarks



[Download this manual](#)

Quick Links





TOSHIBA

□□: KT-15DRRH



Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba KT-15DRRH

[Kettle Toshiba KT-15DRRS User Manual](#)

(10 pages)

[Kettle Toshiba KT-17DR1NMY User Manual](#)

Electric jug kettle (8 pages)

[Kettle Toshiba KT-17SHNH User Manual](#)

(18 pages)

[Kettle Toshiba KT-17SH1NMY User Manual](#)

(8 pages)

[Kettle Toshiba KT-17DRNH Manual](#)

(18 pages)

[Kettle Toshiba KT-17DRRS User Manual](#)

(10 pages)

[Kettle Toshiba KT-15DRTHK User Manual](#)

(24 pages)

Summary of Contents for Toshiba KT-15DRRH

[Page 1](#) 製品の概要: KT-15DRRH の特徴と仕様...

[Page 2](#) 安全に関する注意事項 ● 本体が熱いときは触らない。常に ● Do not touch the body of the kettle when it is hot. Always ● 本体を握るときはハンドルを握る。 ● Always ensure the lid is closed when in use. Failure to ●...

[Page 3](#) ● 本製品の破損や故障、電源コードまたは電源プラグが破損した場合、使用を中止し、専門家の助けを求めよ。 ● If any part of this appliance is damaged or malfunctioned in any way, or the connecting cord or mains plug is broken, do not continue to use it. Seek expert assistance. ● 8歳以上の子どもが使用できる。 ● "This appliance can be used by children aged from 8 years old and over..."

[Page 4](#) ● 本製品の破損や故障、電源コードまたは電源プラグが破損した場合、使用を中止し、専門家の助けを求めよ。 ● If any part of this appliance is damaged or malfunctioned in any way, or the connecting cord or mains plug is broken, do not continue to use it. Seek expert assistance. ● "This appliance can be used by children aged from 8 years old and over..."

[Page 5](#) 製品の底面に収納スペースがあります。使用しないときは、製品をこの収納スペースに収納してください。 ● storage cavity in the base of the unit. When not in use, the kettle should be stored on its base out of the reach of children and pets. *必ず製品の底面に収納してください。...

[Page 6](#) 沸騰スイッチと自動遮断機能 ● 沸騰しているときにスイッチを押し続けると、スイッチが本体から飛び出し、破損する可能性があります。 ● Boil Switch with Auto Cut-Out When boiling water, do NOT hold the switch down or steam will be ejected from the lid and you may damage the automatic switch off mechanism. Always ensure that the ON/OFF switch is clear of obstructions, readily operable and free from any liquid...

[Page 7](#) 電源コードの収納 ● 電源コードを収納するための収納スペースがあります。 ● STORAGE Excess cord can be stowed by feeding the cord into the storage cavity in the base of the unit. When not in use, the kettle should be stored on its base out of the reach of children and pets.

[Page 8](#) PRELIMINARIES Unpack your kettle and any accessories carefully. Retain the packaging so that you can transport the appliance safely. If you dispose of it please do so with regard to any recycling regulations in your area. Before using your kettle: Check that the voltage marked on the rating plate under the kettle or the base matches your...

[Page 9](#) Before first use or after storage: 220-240V~ KT-15DRRH 1.23kg 1.5L 1800-2150W 50/60Hz Fill the kettle with fresh water. Boil the water. Pour away the boiled water. Repeat this two or three times. The kettle is now ready for use.

[Page 10: Electric Kettle](#)

ELECTRIC KETTLE MODEL: KT-15DRRH...

[Page 11: Safety Guide](#)

SAFETY GUIDE Please follow all the safety precautions listed below for safety and to reduce the risk of injury or electrical shock. ● Do not touch the body of the kettle when it is hot. Always hold the appliance by the handle when using it. ●...

[Page 12](#) SAFETY GUIDE ● If any part of this appliance is damaged or malfunctions in any way, or the connecting cord or mains plug is broken, do not continue to use it. Seek expert assistance. ● "This appliance can only be used by children aged from 8 years and above and persons with reduced physical sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning..."

[Page 13](#) SAFETY GUIDE This appliance is intended to be used in household and ● similar applications such as: -Staff kitchen areas in shops, office and other working environments; -farm houses; -by clients in hotels, motels and other residential type environments; -In bed and breakfast type environments. If the supply cord is damaged, it must be replaced by the ●...

[Page 14](#) Filter Body Power base (Stand)

[Page 15: Operation](#)

USING YOUR KETTLE PRELIMINARIES Unpack your kettle and any accessories carefully. Retain the packaging so that you can transport the appliance safely. If you dispose of it please do so with regard to any recycling regulations in your area. Before using your kettle: Check that the voltage marked on the rating plate under the kettle or the base matches your mains voltage.

[Page 16: Using Your Kettle](#)

USING YOUR KETTLE the switch down to switch the kettle on. The power switch will illuminate showing the kettle is in operation. When the water has reached the correct temperature, the power switch will switch off. You can stop the boiling at any time by lifting the switch up. To re-boil, press the switch again.

[Page 17](#) USING YOUR KETTLE Boil Switch with Auto Shut-Out When boiling water, do NOT hold the switch down or steam will be ejected from the lid and you may damage the automatic shut off mechanism. Always ensure that the ON/OFF switch is clear of obstructions, readily operable and is not prevented from switching off.

[Page 18](#) Excess cord can be stowed by feeding the cord into the storage cavity in the base of the unit. When the kettle is not in use, it should be stored on its base and out of the reach of children and pets. 220-240V~ KT-15DRRH 1.23kg 1800-2150W 1.5L 50/60Hz...