

Sanyo Moonlight RMT-U110 -Multimedia Remote Control Manual

Contents

- 1 TO THE OWNER
- 2 BEFORE YOU BEGIN
- **3 PROGRAMMING THE REMOTE CONTROL**
- **4 OPERATING KEYS FUNCTIONS CHART**
- 5 Code List
- 6 Operating Tips and Troubleshooting Hints
- 7 Documents / Resources
 - 7.1 References
 - 7.2 Download manual

TO THE OWNER

Welcome to the World of Sanyo You made an excellent choice for *Performance*, *Reliability*, *Value*, and *Styling*.

BEFORE YOU BEGIN

Installing The Batteries

1. To remove the battery cover, press the tab and tilt cover

upward.

2. Install two "AA" batteries as shown. Be sure to match the / signs on the batteries with the / marks inside the case.

Note: Do Not mix new and used batteries or mix different types of batteries together.

NOTE: SPENT OR DISCHARGED BATTERIES MUST BE RECYCLED OR DISPOSED OF PROPERLY IN COMPLIANCE WITH ALL APPLICABLE LAWS. FOR DETAILED INFORMATION, CONTACT YOUR LOCAL COUNTY SOLID WASTE AUTHORITY.

PROGRAMMING THE REMOTE CONTROL

- Find your VCR, TV, Cable Box, and DVD brand codes in the charts.
 Note: The most common code for each brand is listed first.
- 2. Press and hold the VCR, TV, or AUX mode key while entering the three-digit code number. The mode key will flash 5 times if the code was accepted. The VCR and TV modes will accept only each mode's specific code type. If you enter an invalid code, the mode key will light, but it will not flash, repeat Step 2. The AUX mode will accept all code types, but only one at at time.
- 3. Perform Step 2 for each piece of equipment you have. After entering a code number check the Power and Channel

operations. If these functions operate properly, programming is complete. If not, try reprogramming the remote control using another code, if available. After programming is confirmed, enter your codes in the spaces provided below and on the back of your multimedia remote control.

OPERATING KEYS FUNCTIONS CHART

The keys on this remote control operate functions similar to those of your original remote controls.

Refer to your original owner's manuals for specific key and features operation.

Television Codes

Code List

Operating Tips and Troubleshooting Hints

• To operate each product (VCR, TV, Cable Converter Box, or DVD), you must first program the remote control; then press the proper mode key (VCR, TV, or AUX) to select an operating mode. The VCR and TV modes are preprogrammed with Sanyo codes.

- The AUX mode can be programmed to operate a Cable Converter Box, a DVD, or another VCR or TV.
- If your brand of equipment has several codes listed, try different codes until you find the correct one. The most common code number is listed first.
- There may be VCRs, TVs, Cable Converter Boxes, and DVDs that this remote control cannot operate. Some models may operate only partially.
- Code numbers will remain in memory for five minutes as you replace batteries.
- Remove batteries from the remote control if it will not be used for a month or more. Weak batteries may leak and damage the remote control.
- This remote control uses an invisible (infrared) beam of light to operate the equipment. Objects between the equipment and the remote control can block the beam of light. Therefore, the remote control must be pointed directly at the equipment you want to operate.
- This remote control *cannot* add features to your equipment. They must have been originally provided by your equipment's manufacturer.
- If the remote control fails to operate any of your equipment replace the batteries. Be sure batteries are installed correctly.

Visit our website at <u>www.sanyoctv.com</u> for assistance.

Documents / Resources

References

<u>sanyoctv.com - This website is for sale! - sanyoctv Resources</u> <u>and Information.</u>

Download manual

Here you can download full pdf version of manual, it may contain additional safety instructions, warranty information, FCC rules, etc.

Download Sanyo Moonlight RMT-U110 - Multimedia Remote Control Manual

Need Assistance?

Do you have a question about the Moonlight RMT-U110 that isn't answered in the manual? Leave your question here.

Stay updated with the latest soluti

Related Manuals for Sanyo Moonlight RMT-U110

Sanyo Moonlight RMT-U100 Manual and Code List (article) Sanyo RMT-U230 - 6-Function Backlit Multimedia Remote Control **Manual** (article) Remote Control SANYO Moonlight RMT-U110 Owner's Manual Multimedia remote control (2 pages) Remote Control Sanyo RMT-U100 Moonlight Owner's Manual Sanyo universal remote owner's manual (2 pages) Remote Control Sanyo RMT-U340 Owner's Manual 6-function multimedia remote control (2 pages) Remote Control SANYO RMT-U340 Owner's Manual 6-function multimedia remote control (2 pages) Remote Control Sanyo RMT-U340A Owner's Manual 6-function multimedia remote control (2 pages) Remote Control SANYO Glow Keys RMT-U130 Owner's Manual 3-function multimedia remote control (2 pages) Remote Control SANYO Starlight RMT-U220 Owner's Manual Multimedia remote control (2 pages) Remote Control SANYO RMT-U230 Owner's Manual 6-function backlit multimedia remote control (2 pages) Remote Control Sanyo RMT-U200 Owner's Manual (5 pages) Remote Control Sanyo RCS-TM80BG Instruction Manual (17 pages) Remote Control Sanyo RCS KR1 EG Instruction Manual Control system for spw air conditioner system's (8 pages) Remote Control Sanyo RCS-KR1EG Installation Manual Sanyo remote controller installation manual (2 pages) Remote Control Sanyo STK-RCS-7TWSUA Technical & Service Manual Sanyo wired remote controller technical & service manual (29 pages) Remote Control Sanyo VSP-8500 Instruction Manual System controller (56 pages) Remote Control Sanyo RCS-KR1EG Instruction Manual Simplified remote controller for split system air conditioner (2 pages) Remote Control Sanyo ECO-i RCS-TM80BG Datasheet Standard wired remote: for use on all eco-i indoor units (1 page) Remote Control Sanyo RCS-KR1EG Instruction Manual Simplified remote controller for split system air conditioner (2 pages) Remote Control Sanyo RCS-KS2432AWD Installation Instructions (4 pages)